

# JUMO AQUIS touch P

Modular Multichannel Measuring Device for  
Liquid Analysis with Integrated Controller and  
Paperless Recorder  
Type 202580



**OneTemp**<sup>®</sup> pty ltd  
MEASURE | CONTROL | RECORD  
[www.onetemp.com.au](http://www.onetemp.com.au)  
1300 768 887

Operating Manual



20258000T90Z001K000

V3.00/EN/00607974

**Caution!**

If the device or a sensor connected to it fails abruptly, it is likely that a dangerous overdose has occurred!  
For this case, appropriate precautionary measures must be taken.

**NOTE!**

Read this operating manual before putting the device into service.  
Keep the operating manual at a location that is readily accessible to all users.

<b>1</b>	<b>Safety information</b>	<b>13</b>
1.1	Warning symbols	13
1.2	Indicative symbols	13
1.3	Intended use	14
1.4	Qualification of personnel	14
<b>2</b>	<b>Acceptance of goods, storage, and transport</b>	<b>15</b>
2.1	Checking the delivery	15
2.2	Important information about storage and transport	15
2.3	Returning goods	15
2.3.1	Accompanying letter for repair	15
2.3.2	Protection against electrostatic discharge (ESD)	16
2.4	Disposal	16
<b>3</b>	<b>Device Description</b>	<b>17</b>
3.1	Brief description	17
3.2	Block diagram	19
3.3	Device setup	20
<b>4</b>	<b>Identifying the device version</b>	<b>21</b>
4.1	Nameplate	21
4.2	Order details	22
<b>5</b>	<b>Mounting</b>	<b>27</b>
5.1	Notes	27
5.2	Dimensions	28
5.3	Panel insertion	30
<b>6</b>	<b>Electrical connection</b>	<b>33</b>
6.1	Installation notes	33
6.2	Connecting cables	35
6.2.1	Preparing coaxial cables for pH/redox electrodes	35
6.2.2	Conductor cross-sections for base unit and power supply unit	37
6.2.3	Conductor cross-sections for optional boards	38
6.3	Galvanic isolation	39

---

# Content

---

6.4	Connection diagram .....	40
6.4.1	Overview of connections .....	40
6.4.2	Analog inputs base unit .....	42
6.4.3	Analog inputs optional boards .....	44
6.4.4	Analog outputs .....	53
6.4.5	Binary inputs .....	54
6.4.6	Digital outputs, power supply unit board .....	55
6.4.7	Digital outputs, optional boards .....	56
6.4.8	Mains power connection .....	57
6.4.9	Voltage supply outputs .....	58
6.4.10	Interfaces .....	59
<b>7</b>	<b>Startup .....</b>	<b>65</b>
7.1	Initial startup .....	65
7.2	Digital sensors .....	66
7.2.1	Initial startup .....	66
7.2.2	Restarting .....	70
7.3	Function test .....	71
7.3.1	Checking the optional boards .....	71
7.3.2	Checking sensors and inputs/outputs .....	71
<b>8</b>	<b>Operation .....</b>	<b>73</b>
8.1	Operating concept .....	73
8.1.1	Passwords and user rights .....	73
8.1.2	Display and control elements .....	75
8.1.3	Menu structure .....	76
8.1.4	Entry of text and numbers .....	82
8.2	Device menu .....	84
8.2.1	Logon/Logoff .....	87
8.2.2	User level .....	88
8.2.3	Functional level .....	89
8.2.4	Device information .....	91
8.2.5	Service .....	92

---

8.2.6	Calibrating the touchscreen .....	93
8.2.7	Digital sensors .....	93
8.3	Alarm/Event list .....	98
8.3.1	Alarm list .....	99
8.3.2	Event list .....	102
8.4	Memory Manager (USB flash drive) .....	104
8.5	Operating the controllers .....	107
8.5.1	Automatic control mode .....	108
8.5.2	Controller in the manual mode .....	110
8.5.3	Hold mode .....	111
8.5.4	Optimizing controllers .....	112
8.6	Operation of the data monitor/recording function .....	113
8.6.1	Data monitor/recording function control elements .....	114
8.6.2	History function .....	117
8.7	Online visualization .....	118
<b>9</b>	<b>Parameterization .....</b>	<b>123</b>
9.1	Date and time .....	123
9.2	Parameter Sets (Controller parameter) .....	124
9.3	Setpoint values .....	127
9.4	Manual values .....	127
<b>10</b>	<b>Configuration .....</b>	<b>129</b>
10.1	Important information .....	129
10.2	Basic settings .....	130
10.3	Display .....	131
10.3.1	Generally .....	131
10.3.2	Screen .....	132
10.3.3	Colors .....	132
10.4	Operating loop .....	133
10.4.1	General screens .....	133
10.4.2	Detailed screens .....	134
10.5	Analog inputs .....	135

---

# Content

---

10.5.1	Base unit temperature inputs .....	135
10.5.2	Universal inputs of base unit and optional boards .....	137
10.5.3	pH/Redox/NH <sub>3</sub> analysis inputs .....	140
10.5.4	CR/Ci analysis inputs (conductive/inductive conductivity) .....	142
10.5.5	CR/Ci measuring ranges .....	143
10.6	Analog outputs of base unit and optional boards .....	146
10.7	Digital inputs of base unit and optional boards .....	147
10.8	Digital outputs of base unit and optional boards .....	148
10.9	Digital sensors .....	149
10.9.1	Generally .....	149
10.9.2	Configuration .....	150
10.9.3	Sensor alarms .....	155
10.9.4	CIP/SIP definition (JUMO digiLine pH only) .....	158
10.9.5	Calibration timer .....	158
10.10	Limit monitoring and alarms .....	159
10.10.1	Limit value monitoring .....	159
10.10.2	Alarms for analog signals and digital sensors .....	159
10.10.3	Digital signal alarms .....	162
10.11	Calibration timer .....	163
10.11.1	Configuration of the calibration timers .....	163
10.12	Controller .....	164
10.12.1	Configuration of the controllers .....	164
10.12.2	Controller inputs .....	168
10.12.3	Disturbance feedforward control .....	169
10.12.4	Self-optimization .....	170
10.13	Setpoint value configuration .....	171
10.14	Timers .....	172
10.14.1	Control timer .....	174
10.15	Washtimer .....	175
10.16	Counters .....	176
10.17	Ethernet .....	177
10.18	Serial interfaces .....	178

---

10.19	Formula .....	179
10.20	Logic formula .....	180
10.21	Manual values (configuration) .....	180
10.22	External analog inputs .....	181
10.23	External digital inputs .....	182
10.24	Flow Rate .....	182
<b>11</b>	<b>Retrofitting optional boards .....</b>	<b>185</b>
11.1	Inserting optional boards .....	185
11.2	Ci base calibration .....	188
<b>12</b>	<b>Calibration in general .....</b>	<b>193</b>
12.1	Notes .....	193
12.2	General information .....	193
12.2.1	General procedure for calibration .....	193
12.3	Calibration logbook .....	195
<b>13</b>	<b>Calibrating a pH measuring chain .....</b>	<b>199</b>
13.1	Important information .....	199
13.2	General information .....	199
13.2.1	Calibration methods for pH sensors .....	199
13.2.2	Calibration default settings for pH sensors .....	200
13.3	pH Calibration routines .....	203
13.3.1	Zero-point calibration .....	203
13.3.2	Two-point and three-point calibration .....	205
<b>14</b>	<b>Calibrating redox sensors .....</b>	<b>207</b>
14.1	Important information .....	207
14.2	General information .....	207
14.2.1	Calibration methods for Redox sensors .....	207
14.2.2	Calibration default settings for Redox sensors .....	208
14.3	Redox calibration routines .....	209
14.3.1	Zero-point calibration .....	209
14.3.2	Two-point Calibration .....	211

---

# Content

---

<b>15</b>	<b>Calibrating ammonia sensors</b>	<b>213</b>
15.1	Notes	213
15.2	General information	213
15.2.1	Calibration methods for ammonia sensors	213
15.2.2	Calibration default settings for ammonia sensors	213
15.3	Ammonia calibration routines	214
15.3.1	Zero-point calibration	214
<b>16</b>	<b>Calibrating CR conductivity sensors</b>	<b>215</b>
16.1	Notes	215
16.2	General information	215
16.2.1	Calibration methods for CR conductivity sensors (conductive)	215
16.2.2	Calibration default settings for CR conductivity sensors	216
16.3	CR calibration routines	218
16.3.1	Calibrating the relative cell constant	218
16.3.2	Calibrating the temperature coefficient	220
<b>17</b>	<b>Calibrating Ci conductivity sensors</b>	<b>223</b>
17.1	Important information	223
17.2	General information	223
17.2.1	Calibration methods for Ci conductivity sensors (inductive)	223
17.2.2	Calibration default settings for Ci conductivity sensors	224
17.3	Ci calibration routines	227
17.3.1	Calibrating the relative cell constant	227
17.3.2	Calibrating the temperature coefficient	229
17.3.3	Calibrating the TC-Curve	231
<b>18</b>	<b>Calibrating universal inputs</b>	<b>233</b>
18.1	Important information	233
18.2	General information	233
18.2.1	Calibration methods for universal inputs	233
18.2.2	Universal inputs calibration default settings	235
18.3	Universal input calibration routines	237
18.3.1	Zero point/slope calibration (linear scaling)	238

---



18.3.2	Two-point calibration (linear scaling) .....	239
18.3.3	Slope calibration (free chlorine, ph/Temp.-compensated) .....	241
<b>19</b>	<b>Calibrating O-DO sensors .....</b>	<b>243</b>
19.1	Important information .....	243
19.2	General information .....	243
19.2.1	Calibration methods for O-DO sensors .....	244
19.2.2	Calibration default settings for O-DO sensors .....	244
19.3	O-DO calibration routine .....	246
19.3.1	End value calibration .....	246
19.3.2	Two-point Calibration .....	248
<b>20</b>	<b>Calibrating turbidity sensors .....</b>	<b>251</b>
20.1	Important information .....	251
20.2	General information .....	251
20.2.1	Calibration methods for turbidity sensors .....	251
20.2.2	Calibration presets for turbidity sensors .....	252
20.3	Calibration routines for turbidity sensors .....	253
20.3.1	Two-point calibration .....	253
<b>21</b>	<b>PC Setup Program .....</b>	<b>255</b>
21.1	Generally .....	255
21.2	Installing the JUMO PC setup program .....	256
21.2.1	Procedure .....	256
21.3	Logging onto the setup program .....	258
21.3.1	Rights in the setup program .....	259
21.4	QuickStart agent .....	260
21.5	User interface .....	262
21.5.1	Elements of the user interface .....	262
21.5.2	Display protection .....	264
21.5.3	Editing the setup file .....	267
21.6	Menu bar .....	269
21.6.1	File menu .....	269
21.6.2	Data Transfer menu .....	271

---

# Content

---

21.6.3	Extras .....	273
21.6.4	Windows .....	275
21.6.5	Info .....	276
21.7	Connection to device .....	277
21.7.1	Device connections list .....	277
21.7.2	Configuring the connection with the assistant .....	279
21.7.3	Configuring the connection without the assistant .....	286
21.7.4	Searching for a device in the network .....	288
21.8	Setting up the device with the JUMO PC setup program .....	290
21.8.1	Identification .....	290
21.8.2	Configuring and parameterizing .....	292
21.8.3	User list .....	292
21.8.4	Country settings .....	295
21.8.5	Device character set .....	301
21.8.6	User level .....	303
21.8.7	Formula .....	304
21.8.8	Logic formula .....	305
21.8.9	Customer-specific linearization .....	306
21.8.10	Buffer set tables .....	309
21.8.11	Process screens .....	310
21.8.12	E-mail .....	324
21.8.13	<b>SMS gateway</b> .....	<b>325</b>
21.8.14	Web server .....	331
21.9	Diagnostics .....	333
21.9.1	Calibration logbooks .....	333
21.9.2	Digital sensor calibration logbooks .....	333
21.9.3	Digital sensor connection list .....	333
21.10	Online parameters .....	335
21.10.1	Date and time .....	335
21.10.2	Screenshot .....	335
21.10.3	Ethernet .....	336
21.10.4	Enabling of extra codes .....	337

---

21.10.5	Deleting internal measurement data .....	337
21.10.6	Adjusting / Testing .....	338
<b>22</b>	<b>Technical data .....</b>	<b>345</b>
22.1	Analog inputs base unit .....	345
22.1.1	Temperature measuring input (IN 4) .....	345
22.1.2	Temperature measuring input (IN 5) .....	346
22.1.3	Universal input (IN 6) .....	346
22.1.4	Measuring circuit monitoring base unit .....	346
22.2	Analog inputs optional boards .....	347
22.2.1	Universal input (IN 11, IN 12) .....	347
22.2.2	Analysis input: pH/Redox/NH <sub>3</sub> .....	347
22.2.3	Analysis input: CR (resistive conductivity) .....	348
22.2.4	Analysis input: Ci (conductivity, inductive) .....	349
22.2.5	Temperature compensations .....	350
22.2.6	Measuring circuit monitoring, optional boards .....	351
22.3	Analog outputs of base unit and optional boards .....	352
22.4	Binary inputs base unit .....	352
22.5	Binary inputs optional boards .....	352
22.6	Binary outputs, power supply unit board .....	352
22.7	Binary outputs, optional boards .....	353
22.8	Voltage supply outputs, optional board .....	353
22.9	Interfaces .....	354
22.9.1	Serial interface RS485 (base unit ) .....	354
22.9.2	Serial Interface RS422/485 (optional board) .....	354
22.9.3	PROFIBUS-DP (optional board) .....	354
22.9.4	Sampling rate for digital sensors .....	354
22.9.5	Ethernet optional board (10/100Base-T) .....	355
22.9.6	USB interfaces .....	356
22.10	Electrical data .....	357
22.11	Screen Touchscreen .....	357
22.12	Case .....	358
22.13	Functions .....	359

---

# Content

---

22.13.1	Controller channels .....	359
22.13.2	Recording function .....	360
22.13.3	Customer-specific linearization .....	360
22.14	Approvals/approval marks .....	360
<b>23</b>	<b>Annex .....</b>	<b>363</b>
23.1	Troubleshooting and remedies for digital sensors .....	363
23.1.1	Possible faults on sensors with JUMO digiLine electronics .....	363
23.1.2	Possible faults on digital JUMO sensors from product groups 2026xx .....	365
23.2	Planning the cabling for digital sensors .....	367
23.2.1	When supplying the bus from a JUMO AQUIS touch P .....	367
23.2.2	When supplying the bus from a JUMO digiLine hub .....	368

# 1 Safety information

## 1.1 Warning symbols



### **DANGER!**

This symbol indicates that the risk of personal injury from electrocution exists if the appropriate precautionary measures are not taken.



### **WARNING!**

In conjunction with the signal word "Warning", this symbol indicates that the risk of personal injury or death exists if the appropriate precautionary measures are not taken.



### **CAUTION!**

In conjunction with the signal word "Caution", this symbol indicates that the risk of equipment damage or data loss exists if the appropriate precautionary measures are not taken.



### **CAUTION!**

This symbol indicates that components of the device can be destroyed as the result of electrostatic discharge (ESD = ElectroStatic Discharge) if the appropriate precautionary measures are not taken. When returning modules, assemblies, or components from the device, use only the ESD packaging provided.



### **READ THE DOCUMENTATION!**

This symbol, which is attached to the device, indicates that the associated documentation for the device must be observed. This is necessary in order to recognize the nature of the potential danger and take the necessary measures to avoid it.

## 1.2 Indicative symbols



### **NOTE!**

This symbol refers to **important information** about the product, its handling, or additional use.



### **REFERENCE!**

This symbol refers to **additional information** in other sections, chapters or other instructions.



### **DISPOSAL!**

At the end of its service life, the device and any batteries present do not belong in the trash! Please dispose of them as required by regulations and in an **environmentally sound manner**.

# 1 Safety information

---

## 1.3 Intended use

The JUMO AQUIS touch P is designed for measurement, control, and automation tasks in industrial environments as specified in the technical data. Use for any other purpose is considered contrary to the intended use.

⇒ Chapter 22 "Technical data", Page 345

The device has been manufactured in compliance with applicable standards and guidelines as well as applicable safety regulations. Improper use can result in personal injury or property damage.

To avoid risks, the device may be used only as follows:

- For the intended use
- when in good order and condition
- when taking into account the technical documentation provided

Risks resulting from the application may arise, e.g. as the result of missing safety provisions or wrong settings, even when the device is used properly and as intended.

## 1.4 Qualification of personnel

This document contains the information required to ensure use of the unit as intended. It is meant for technically qualified individuals who have been specially trained and have the appropriate know-how in the field of automation technology (measurement and control instrumentation).

Understanding and technically correct observance of the safety instructions and warnings contained in the supplied documentation are prerequisites for safe mounting, installation, and commissioning as well as safety during operation.

Only qualified individuals have the required technical knowledge to interpret and put into practice the safety instructions and warnings used in this documentation in any given situation.

## 2 Acceptance of goods, storage, and transport

---

### 2.1 Checking the delivery

- ensure that the packaging and its contents are undamaged
- check the delivery for completeness against the delivery papers and the order details
- inform the supplier immediately if there is any damage
- retain damaged parts until the situation has been clarified with the supplier

### 2.2 Important information about storage and transport

- store the device in a dry, clean environment
- observe the permissible ambient conditions,  
⇒ Chapter 22 "Technical data", Page 345
- protect the device from shock during transport
- the original packaging offers optimal protection for storage and transport

### 2.3 Returning goods

- if repairs are needed, return the device in clean condition and in its entirety
- use the original packaging when sending the unit back

#### 2.3.1 Accompanying letter for repair

Please include the completed accompanying letter for repair when returning goods. Do not forget to state the following:

- Description of the application
- Description of the error that has occurred

The accompanying letter for repair is linked to [www.jumo.de](http://www.jumo.de) on the Internet under the heading **Service & Support** as follows:

Product Service → Repair Service → Returning a unit

## 2 Acceptance of goods, storage, and transport

---

### 2.3.2 Protection against electrostatic discharge (ESD)



#### **CAUTION!**

Electrostatic charges occur in non-ESD-protected environments. Electrostatic discharge can damage assemblies or components. For transport purposes, use only the ESD packaging provided.

To prevent damage from ESD, electronic assemblies, or components with a high internal resistance must be handled, packaged, and stored in an environment that protects against ESD. Measures that protect against electrostatic discharge and electric fields are described in DIN EN 61340-5-1 and DIN EN 61340-5-2 "Protection of electronic devices from electrostatic phenomena".

When sending back electronic assemblies or components, please note the following:

- Pack sensitive components only in an environment providing protection against ESD. Such workplaces conduct existing electrostatic charges to ground in a controlled manner and prevent electrostatic charge buildup due to friction.
- Use only packaging intended specifically for ESD-sensitive assemblies/components. These must be made from conductive plastics.

No liability is assumed for damage caused by electrostatic discharge (ESD).

## 2.4 Disposal



#### **DISPOSAL!**

At the end of its service life, the device and any replaced parts do not belong in the trash. These items are made from materials that can be reclaimed through "recycling".

Dispose of the device and the packaging material as required by regulations and in an environmentally sound manner!

The country-specific laws and regulations for handling and disposing of waste must be observed!

#### **Disposing of the packaging material**

All packaging material is recyclable.



### 3.1 Brief description

#### Measuring

The JUMO AQUIS touch P provides a central platform for the display and processing of pH value, redox voltage, electrolytic conductivity, resistance of high-purity water, temperature, quantities of disinfecting agents such as free chlorine, total chlorine, chlorine dioxide, ozone, hydrogen peroxide and peracetic acid or even flow rates. Pulse frequency inputs (counters) are available for flow rate measurement. Universal inputs can be used to measure analog measurands using standard signals [0(4) to 20 mA or 0 to 10 V] The unit can measure and manage up to 23 parameters simultaneously.

#### Controlling

Besides numerous simple alarm, limit value or time-controlled switching functions, up to 4 higher-order control loops can be defined in the JUMO AQUIS touch P at the same time. Tried and tested JUMO control algorithms are used for P, PI, PD, and PID control in these applications.

#### Display

A 3.5" TFT color screen with touch function serves to display all parameters as well as operate and setup the device. The plain text operation philosophy virtually eliminates the need for a manual. German, English, and, on request, French are included in the device at the factory as selectable user interface languages (see order details). Using the PC setup program, the language library of the unit can be expanded to as many as 15 languages. It's also possible to display languages that use Chinese and Cyrillic characters. As a result, the device is predestined for global use.

#### Recording

A paperless recorder is integrated for data recording. Up to 8 analog quantities and 6 binary signals are registered and displayed on the screen in a time-dependent curve. Storage is tamper-proof and enables official recording obligations to be fulfilled. The data can be extracted using the JUMO PCC software or to a USB flash drive for evaluation by the JUMO PCA 3000 PC evaluation software.

### 3 Device Description

---

#### Application examples

The modular setup and open structure of the device permits a host of potential applications:

- Municipal and industrial water treatment in wastewater treatment plants
- Process systems
- Drinking and bathing water monitoring
- Pharmaceutical water
- Food and beverage production (CIP/SIP plants)
- Gas scrubbers / air washers
- Cooling tower control
- Ion exchangers
- RO-units (reverse osmosis)
- Power stations and energy plants
- Fish breeding
- Desalination of seawater




**NOTE!**

The device is not suitable for use in a potentially explosive atmosphere.

# 3 Device Description


## 3.2 Block diagram



# 3 Device Description

---

## 3.3 Device setup




- (1) Mounting brackets
- (2) Metal case barrel
- (3) Rear panel with connection terminals (base unit and optional boards)
- (4) Housing front
- (5) LED (voltage supply switched on)
- (6) Touch screen TFT color screen
- (7) USB interfaces

# 4 Identifying the device version

## 4.1 Nameplate

The nameplate on the device enclosure identifies the device version.

### Example of a nameplate



- (1) Datamatrix code
- (2) Information symbol (Read documentation!  
⇒ Chapter 1.1 "Warning symbols", Page 13)
- (3) Part number
- (4) Serial number
- (5) Approval mark
- (6) Voltage supply
- (7) Type key

It is helpful to become familiar with the technical features of the device prior to commissioning. Compare the type code on the nameplate with the order details.  
⇒ „Order details“, Page 22

In the event of technical questions, please have the information from the nameplate available for the member of our support team.

## 4 Identifying the device version

### 4.2 Order details



**NOTE!**

In addition to the standard languages of German, English and, French, 13 additional languages (e.g. Russian, Chinese, Italian etc.) are available. Please use the contact information on the back of this manual to contact JUMO in this regard.

		Slot
<b>(1) Basic type</b>		
202580	JUMO AQUIS touch P	
<b>(2) Version</b>		
8	Standard with factory settings	
9	Customer-specific configuration (specification in plain text)	
<b>(3) Language</b>		
01	German	
02	English	
03	French	
<b>(4) Analysis input 1</b>		<b>IN 7</b>
0	Not used	
1	pH/redox/NH <sub>3</sub>	
2	CR resistive conductivity measurement (2 and 4-pole)	
3	Ci inductive conductivity measurement	
<b>(5) Analysis input 2</b>		<b>IN 8</b>
0	Not used	
1	pH/redox/NH <sub>3</sub>	
2	CR resistive conductivity measurement (2 and 4-pole)	
3	Ci inductive conductivity measurement	
<b>(6) Input/output 1</b>		<b>IN 11, OUT 6/7</b>
00	Not used	
10	Universal input	
11	Relay (changeover contact)	
12	2× relays (normally open contact)	
13	Solid state relay triac 230 V, 1 A	
14	Logic output 0/22 V	
15	2× logic outputs 0/12 V	
16	Analog output	
17	2× solid state relay PhotoMOS®	

## 4 Identifying the device version

<b>(7) Input/output 2</b>		<b>IN 12, OUT 8/9</b>
00	Not used	
10	Universal input	
11	Relay (changeover contact)	
12	2× relays (normally open contact)	
13	Solid state relay triac 230 V, 1 A	
14	Logic output 0/22 V	
15	2× logic outputs 0/12 V	
16	Analog output	
17	2× solid state relay PhotoMOS®	
19	Voltage supply output DC ±5 V, 24 V	
<b>(8) Input/output 3</b>		<b>IN 13/14/15, OUT 10/11</b>
00	Not used	
11	Relay (changeover contact)	
12	2× relays (normally open contact)	
13	Solid state relay triac 230 V, 1 A	
14	Logic output 0/22 V	
15	2× logic outputs 0/12 V	
16	Analog output	
17	2× solid state relay PhotoMOS®	
18	3× binary inputs	
<b>(9) Input/output 4</b>		<b>IN 16/17/18, OUT 12/13</b>
00	Not used	
11	Relay (changeover contact)	
12	2× relays (normally open contact)	
13	Solid state relay triac 230 V, 1 A	
14	Logic output 0/22 V	
15	2× logic outputs 0/12 V	
16	Analog output	
17	2× solid state relay PhotoMOS® <sup>a</sup>	
18	3× binary inputs	
<b>(10) voltage supply</b>		
23	AC 110 to 240 V +10/-15 %; 48 to 63 Hz	
39	AC/DC 24 V +30/-25 %; 48 to 63 Hz	
<b>(11) Interface Com2</b>		<b>COM 2</b>
00	Not used	

## 4 Identifying the device version

08	Ethernet
54	RS422/485 Modbus RTU
64	PROFIBUS-DP
<b>(12) Extra code</b>	
000	without extra code
213	Recording function
214	Math and logic module
962	JUMO digiLine protocol activated

<sup>a</sup> PhotoMOS® is a registered trademark of Panasonic.

Order code:           (1)    (2)    (3)    (4)    (5)    (6)    (7)    (8)    (9)    (10)   (11)  
                           □ / □ - □ - □ - □ - □ - □ - □ - □ - □ - □ - □ /  
 Order example:    202580 / 8 - 01 - 1 - 2 - 10 - 10 - 13 - 13 - 23 - 64 -  
                           (12)  
                           □ , ...<sup>a</sup>  
                           213 , 214

<sup>a</sup> List all desired extra codes separated by commas.

### Scope of delivery

JUMO AQUIS touch P according to order details (including 4× mounting elements)
Panel seal
Mini-DVD with JUMO PC setup program as demo version, Adobe Acrobat Reader, operating manual and data sheet in PDF format, GSD generator and JUMO PCC / PCA3000 as demo version
Installation instructions in 2 volumes B 202580.4



## 4 Identifying the device version

### Accessories

Order code	Type	Part no.
703571 (20258x)/10	Universal input	00581159
703571 (20258x)/213	Activation of the recording function	00581176
703571 (20258x)/214	Activate math and logic module	00581177
703571 (20258x)/11	Binary output relay (changeover contact)	00581160
703571 (20258x)/12	Binary outputs 2× relay (normally open contact)	00581162
703571 (20258x)/13	Solid state relay triac 230 V, 1 A	00581164
703571 (20258x)/14	Logic output 0/22 V	00581165
703571 (20258x)/15	2 Logic outputs 0/12 V	00581168
703571 (20258x)/16	Analog output	00581169
703571 (20258x)/17	Binary outputs 2× solid state relays PhotoMOS® <sup>a</sup>	00581171
703571 (20258x)/54	Serial interface RS422/485 for Modbus RTU and JUMO digiLine	00581172
703571 (20258x)/64	PROFIBUS-DP	00581173
703571 (20258x)/08	Ethernet	00581174
20258x/3	Analysis input Ci for inductive conductivity	00584265
20258x/2	Analysis input CR for resistive conductivity	00584263
20258x/1	Analysis input pH/redox/NH <sub>3</sub>	00584264
20258x/18	Binary inputs 3× potential-free contact	00592962
20258x/19	Voltage supply output DC ±5 V, 24 V	00592963
	USB flash drive 2.0 (2 GB) <sup>b</sup>	00505592
	USB cable, A-connector to Mini-B connector, length 3 m	00506252
	JUMO PC setup program AQUIS touch S/P, (PG202599)	00594355
	JUMO PCA3000/PCC software package <sup>c</sup>	00431884

<sup>a</sup> PhotoMOS® is a registered trademark of Panasonic.

<sup>b</sup> The USB flash drive indicated has been tested and is designed for industrial applications. No liability is assumed for flash drives from other manufacturers.

<sup>c</sup> Communication and evaluation software for stored recording function measurement data

# 4 Identifying the device version

---

## 5.1 Notes



### **DANGER!**

Under no circumstances may the device be installed or removed while under voltage! This poses the risk of electrocution.

Switch-off the entire system beforehand. This work must be performed only by qualified personnel!

The device must never be installed in potentially-explosive areas! There is the risk of an explosion.

### **Mounting site**

When determining the mounting site, it is important to ensure that the device specifications are respected. The relevant tables containing details of case specifications can be found in the chapter entitled "Technical Data". The device must not be exposed to any severe shocks or permanent vibrations. Electro-magnetic fields caused by equipment such as motors or transformers must be avoided!

### **Climatic conditions**

The ambient temperature and the relative humidity at the mounting site must correspond to the technical data.

⇒ Chapter 22 "Technical data", Page 345

### **Installation position**

The device can be installed in any position. However, the viewing angle of the TFT touchscreen should be taken into consideration.

⇒ Chapter 22 "Technical data", Page 345


### **Space requirement**

Ensure adequate access to the region around the cable entry points. The minimum bending radius of the cables must be taken into account!

⇒ Chapter 5.2 "Dimensions", Page 28

# 5 Mounting

## 5.2 Dimensions



### Spacings


For adequate ventilation, the following mounting distances from adjacent equipment must be respected:

- horizontal 35 mm
- vertical 80 mm

When inserting the device, sufficient space for maneuvering the connecting cables must be left behind the case. A Ci-conductivity sensor is connected via a M12 connector adapter. This increases the space requirement with respect to mounting depth (see dimensional drawing below).

# 5 Mounting

## Mounting depth with Ci-conductivity sensor



## 5 Mounting

---

### 5.3 Panel insertion

The device is designed to be inserted in switch cabinets or machine/system walls. The insertion operation is described below.



**NOTE!**

Insertion in a control panel provides protection class IP66. When the JUMO AQUIS touch P is inserted in the wall of control cabinets with a protection class higher than IP66, the protection class of the control cabinet lapses and corresponds to the protection class for control panel insertion (IP66).




**CAUTION!**

Ensure that the control panel provides adequate support for the device. The weight values listed in the technical data must be taken into account to ensure adequate mechanical stability for control panel installation.

⇒ Chapter 22.12 "Case", Page 358

## 5 Mounting



- (1) Metal case barrel of the JUMO AQUIS touch P
- (2) Mounting elements
- (3) Seal from the scope of delivery for the device
- (4) Case front
- (5) Panel/control cabinet

### Procedure

Step	Action
1	Push the panel seal provided (3) from the rear panel of the device over the case barrel to the front panel.
2	Place the device in the cutout provided for this purpose in the control panel (5) as shown in the drawing.
3	Insert the mounting elements (2) into the holders on the case provided for this purpose, as shown on the drawing.
4	Screw the mounting element firmly against the panel so that the case front (4) of the device is tight against the panel (5) and the device is firmly seated.

# 5 Mounting

---



### 6.1 Installation notes



**DANGER!**

Observe the following instructions!

#### Qualification of personnel

- The electrical connection must only be carried out by qualified personnel.

#### Electrical wiring

- When selecting the electrical wiring material as well as when installing and connecting the device electrically, comply with the requirements of DIN VDE 0100 "Low-voltage electrical installations" and the applicable country-specific regulations (e. g. based on IEC 60364).
- The input, output, and power supply lines must be separated from one another spatially and not laid in parallel.
- Select suitable cables for sensors and interfaces (shielded and twisted or coaxial cable). These lines must not be installed near live electrical components or current-carrying wiring.
- Sensor lines must be uninterrupted (not connected via terminal blocks or the like).
- Provide shielding in accordance with the connection diagram on the device.
- In a star wiring configuration, grounding wires must be connected to an equipotential grounding busbar and insulation must be intact. Keep lines as short as possible. Ensure proper potential equalization/bonding.

## 6 Electrical connection

---

### Electrical safety

- Disconnect all phases of the power supplied to the device (power grid, outside power supply sources for relays/solid state relays etc.) If current-carrying components could be touched while work is being performed.
- Fuses for power supply circuits should be rated at no more than 10 A (slow-blow).
- To prevent destruction of device outputs in the event of an external short circuit, short-circuit currents in circuits with relay or semiconductor outputs should be limited through use of appropriate fuses.
- The device is not suitable for installation in potentially explosive areas.
- Besides incorrect installation, wrong settings on the device can adversely affect performance of the connected process. For this reason, independently operating safety devices, e.g. pressure relief valves, temperature limiters/monitors, liquid-metering limiters and overflow prevention devices should be provided and adjustment of them restricted only to train technical personnel. Appropriate safety regulations must be observed in this connection.
- Plug-in screw terminal strips should not be unplugged until after the power has been disconnected.

### References to other information


- The electromagnetic compatibility conforms to the standards and regulations cited in the technical data.
- The specifications for galvanic isolation must be taken into account during planning and electrical installation.  
⇒ Chapter 6.3 "Galvanic isolation", page 39

# 6 Electrical connection

## 6.2 Connecting cables


### 6.2.1 Preparing coaxial cables for pH/redox electrodes

#### Coaxial cable with Shield-Kon® connector<sup>1</sup>




Length	Part number
1.5 m	00085154
5 m	00307298
10 m	00082649

#### Preparing your own coaxial cable




Remove outer sheathing from the cable > Pull back the braided shield



Remove black, semiconducting layer (see image) > Strip insulation off inside conductor > Attach Shield-Kon® connector<sup>1</sup> for shield

<sup>1</sup>.Shield-Kon is a registered trademark of THOMAS & BETTS INTERNATIONAL, Inc., Wilmington Del., US.

## 6 Electrical connection




Use shrink tubing to insulate the braided shield




### NOTE!

The black, semiconducting layer must not touch with the inside conductor! This would short-circuit the signal from the pH electrode.

### Preparing a shielded multiconductor cable




Strip the insulation off the connecting cable and pull back the shield



Attach wire ferrules to the ends of the conductors and a Shield-Kon® connector<sup>1</sup> for shielding

<sup>1</sup>Shield-Kon is a registered trademark of THOMAS & BETTS INTERNATIONAL, Inc., Wilmington Del., US.

## 6 Electrical connection



Use shrink tubing to insulate the shield and Shield-Kon® connector<sup>1</sup>

### 6.2.2 Conductor cross-sections for base unit and power supply unit

The terminals on the base unit and power supply unit are plug-in screw terminals.

Ferrule	Conductor cross section		Length to strip
	minimal	Maximum	
without ferrule			
Power supply unit voltage supply	0.2 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Power supply unit relay switching outputs	0.2 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Base unit	0.14 mm <sup>2</sup>	1.5 mm <sup>2</sup>	7 mm
Ferrule without lip			
Power supply unit voltage supply	0.25 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Power supply unit relay switching outputs	0.25 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Base unit	0.25 mm <sup>2</sup>	1.5 mm <sup>2</sup>	7 mm
with ferrule with lip			
Power supply unit voltage supply	0.25 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Power supply unit relay switching outputs	0.25 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Base unit	0.25 mm <sup>2</sup>	0.5 mm <sup>2</sup>	7 mm
Rigid			
Power supply unit voltage supply	0.2 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Power supply unit relay switching outputs	0.2 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Base unit	0.14 mm <sup>2</sup>	1.5 mm <sup>2</sup>	7 mm

<sup>1</sup>Shield-Kon is a registered trademark of THOMAS & BETTS INTERNATIONAL, Inc., Wilmington Del., US.

## 6 Electrical connection

### 6.2.3 Conductor cross-sections for optional boards

The terminals on optional boards are plug-in screw terminals.

Optional boards for	Ferrule	Conductor cross section		Length to strip
		minimal	Maximum	
Universal inputs	without ferrule	0.14 mm <sup>2</sup>	1.5 mm <sup>2</sup>	7 mm
Analog outputs	with ferrule with lip	0.25 mm <sup>2</sup>	0.5 mm <sup>2</sup>	7 mm
Digital inputs	Ferrule without lip	0.25 mm <sup>2</sup>	1.5 mm <sup>2</sup>	7 mm
Digital outputs PhotoMOS® <sup>a</sup>	Rigid	0.14 mm <sup>2</sup>	1.5 mm <sup>2</sup>	7 mm
Logic outputs				
Voltage supply output				
Analysis inputs pH/Redox/NH <sub>3</sub>	without ferrule	0.2 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Analysis inputs CR <sup>b</sup>	with ferrule with lip	0.25 mm <sup>2</sup>	1.5 mm <sup>2</sup>	7 mm
Analysis inputs Ci <sup>c</sup>	Ferrule without lip	0.25 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm
Digital outputs relay				
Digital outputs triac	Rigid	0.2 mm <sup>2</sup>	2.5 mm <sup>2</sup>	7 mm


<sup>a</sup> PhotoMOS® is a registered trademark of Panasonic.

<sup>b</sup> CR analysis inputs = Analysis inputs for resistive conductivity

<sup>c</sup> Analysis inputs Ci = Analysis inputs for inductive conductivity

# 6 Electrical connection

## 6.3 Galvanic isolation




**Note!**

If sensors that are not electrically isolated are connected to a digital input and supplied by an external power source, potential differences between the internal and external ground can cause problems. Providing the supply voltage from the voltage supply outputs of the JUMO AQUIS touch P is preferable in such cases.

## 6 Electrical connection

### 6.4 Connection diagram

#### 6.4.1 Overview of connections



	Module	Connector terminal	Type
Inputs	Base unit	IN 1 to IN 3	Digital inputs
		IN 4 to IN 5	Temperature inputs
		IN 6	Universal input
	Option-al boards	IN 7 to IN 8	analysis inputs
	–	IN 9 to IN 10	Not available <sup>a</sup>
	Option-al boards	IN 11 to IN 12	Universal inputs
		IN 13 to IN 18	Digital inputs




## 6 Electrical connection

Outputs	Power supply unit	OUT 1 to 2	Digital outputs (relay changeover contact)
	Base unit	OUT 3	Not available <sup>a</sup>
		OUT 4	Analog output
	-	OUT 5	Not available <sup>a</sup>
	Optional boards	OUT 6 to OUT 13	Analog/digital outputs, OUT 8/9 also for voltage supply output DC $\pm 5$ V, 24 V
Interfaces	Base unit	COM 1	RS485
		USB device interface	USB device interface
		USB host interface	USB host interface
	Optional boards	COM 2	Ethernet, PROFIBUS-DP, or RS422/485

<sup>a</sup> Available only on the AQUIS touch S


# 6 Electrical connection

## 6.4.2 Analog inputs base unit



Connector/ terminal	Connection variant	Symbol
IN 4	RTD temperature probe 2-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	RTD temperature probe 3-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
IN 5	RTD temperature probe 2-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	RTD temperature probe 3-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	NTC 2-wire circuit	
	NTC 3-wire circuit	
	Resistance potentiometer A = Start E = End S = Slider	

## 6 Electrical connection




Connector/ terminal	Connection variant	Symbol
IN 6	Standard signal Current 0(4) to 20 mA	+ ———— ○ 9 $I_x$ - ———— ○ 10

# 6 Electrical connection

## 6.4.3 Analog inputs optional boards

### Universal inputs



Slot	Connection variant	Symbol
IN 11 IN 12	RTD temperature probe 2-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	RTD temperature probe 3-wire circuit Pt100, Pt1000 or customer-specific characteristic line	
	Resistance potentiometer A = Start E = End S = Slider	
	Standard signal Voltage 0 to 10 V	
	Standard signal Current 0(4) to 20 mA	

## 6 Electrical connection

---

### pH/Redox/NH3 analysis inputs


There are currently 2 versions of the "pH/Redox/NH3 analysis input" optional board in use. The connection diagram contains the connection terminal layout for both version I and version II. To identify the version of your optional board, compare the connection terminal layout to the following illustrations:




**I** = First version

**II** = Revised version


## 6 Electrical connection



DC  $\pm 5$  V:  
OUT 8/9



Temperature inputs:  
IN 4/5/11



Analysis inputs:  
IN 7/8


Slot	Option/ connec- tion variant	Wire (color) <sup>a</sup>	Potential	Terminal			Symbol		
				DC $\pm 5$ V <sup>b</sup>	Tempera- ture input	Analysis input pH/redox			
						I		II	
IN 7 IN 8	ISFET-pH sensor	A (blue)	DC +5 V	3					
		B (black)	GND with jump- er to F	4					
		C (green)	DC -5 V	5					
		D (white/ black)	Ion-sensi- tive gate			1		1	
		E	Bypass			3		4	
		F (yellow)	Reference			5		5	
		G (white)	Compensa- tion ther- mometer in 3-wire cir- cuit					6	6
		H (red)							
		I (red/ black)							
<p>The RTD temperature probe is used to provide a temperature-compensated pH-value measurement, and can be connected to a temperature input or universal input.<sup>d</sup></p>									

<sup>a</sup> The conductor colors listed refer to JUMO ISFET-pH sensors. The orange-colored conductor is not connected.

<sup>b</sup> The "Voltage supply output DC  $\pm 5$  V, 24 V" optional board (part no.. 00592963) is needed in slot "OUT 8/9" to supply voltage to the JUMO ISFET pH sensor.


## 6 Electrical connection

- <sup>c</sup> The connection diagram for the selected analog input (IN 4/5/11) must be observed when connecting the temperature probe.
- <sup>d</sup> When connecting the temperature probe of JUMO ISFET pH sensors to process connection 615 (NTC 8k55), no customer-specific linearization like that for the JUMO AQUIS 500 pH is needed. The IN 5 temperature input supports connection of 8k55-NTC temperature probes.



Slot	Option/connection variant	Symbol
IN 7 IN 8	<p>pH/Redox</p> <p><b>Asymmetric connection of a combination electrode</b></p> <p>Standard connection variant</p> <p>For temperature compensation, a separate temperature sensor can be connected to an analog input.</p> <p>A = Glass/metal electrode B = Reference electrode</p> <p>Terminal 2 is not connected!</p>	


## 6 Electrical connection



Slot	Option/connection variant	Symbol
IN 7 IN 8	<p>pH/Redox</p> <p><b>Asymmetric connection of a combination electrode with integrated resistance thermometer and Variopin terminal head</b></p> <p>The RTD temperature probe is used to provide a temperature-compensated pH-value measurement, and can be connected to a temperature input or universal input.</p> <p>A = Glass/metal electrode (core)            B = Reference electrode (inner shield)            C = Shield (outer shield)            D = RTD temperature probe            E = RTD temperature probe            F = RTD temperature probe</p> <p>Terminal 2 is not connected!</p>	




## 6 Electrical connection



Slot	Option/connection variant	Symbol
IN 7 IN 8	<p>pH/Redox</p> <p><b>Symmetric connection of a combination electrode</b></p> <p>Symmetric connection is used to reduce interference from stray electromagnetic fields along the sensor cable.</p> <p>A = Glass/metal electrode (core)                      B = Reference electrode (inner shield)                      C = Liquid potential (grounding pin, pipe, or container wall at the measuring point)                      D = Shield (outer shield)</p> <p>Terminal 2 is not connected!</p>	


## 6 Electrical connection



Slot	Option/connection variant	Symbol
IN 7 IN 8	<p>pH/Redox</p> <p><b>Symmetric connection of a combination electrode with integrated resistance thermometer and Variopin terminal head</b></p> <p>Symmetric connection is used to reduce interference from stray electromagnetic fields along the sensor cable. The RTD temperature probe is used to provide a temperature-compensated pH-value measurement, and can be connected to a temperature input or universal input.</p> <p>A = Glass/metal electrode (core)            B = Reference electrode (inner shield)            C = Liquid potential (grounding pin, pipe, or container wall at the measuring point)            D = Shield (outer shield)            E = RTD temperature probe            F = RTD temperature probe            G = RTD temperature probe</p> <p>Terminal 2 is not connected!</p>	


## 6 Electrical connection

### Electrolytic conductivity analysis inputs



Slot	Option/connection variant	Symbol
IN 7 IN 8	<p>Ci optional board (inductive conductivity measurement)            Connection via an M12 plug,            Attach connections for compensation            thermometer (2-wire cable for socket) to a            suitable analog input (2-wire circuit),  <b>The factory-installed wiring must not be changed!</b></p>	
	<p>CR optional board (resistive conductivity measurement)            2-electrode system with 2-wire conductor            Terminal 1 must be connected to the            outer electrode on concentric conductivity sensors.</p> <p>A = Outer electrode            (core color for JUMO types with fixed cable: White)            B = Inner electrode            (core color for JUMO types with fixed cable: Brown)            C = Shield</p>	

## 6 Electrical connection




Slot	Option/connection variant	Symbol
IN 7 IN 8	<p>CR optional board (resistive conductivity measurement)            2-electrode system with 4-wire conductor            (Wiring to minimize the measuring error caused by lead-wire resistance)</p> <p>Terminal 1 must be connected to the outer electrode on concentric conductivity sensors.</p> <p>A/B = Outer electrode            C/D = Inner electrode            E = Shield</p>	
	<p>CR optional board (resistive conductivity measurement)            4-electrode system</p> <p>A = Outer electrode 1 (I hi)            (core color of CR-4P cable for JUMO types: Red)            B = Inner electrode 1 (U hi)            (core color of CR-4P cable for JUMO types: Gray)            C = Inner electrode 2 (U lo)            (core color of CR-4P cable for JUMO types: Pink)            D = Outer electrode 2 (I lo)            (core color of CR-4P cable for JUMO types: Blue)            E = Shield</p>	

## 6 Electrical connection


### 6.4.4 Analog outputs

#### Base unit



Connector/ terminal	Connection variant	Symbol
OUT 4	analog output DC 0 to 10 V or DC 0(4) to 20 mA (configurable)	$\begin{matrix} + & \text{---} & \text{---} & \text{---} & \text{---} & \circ & 3 \\ & & & & & & \\ & & & & & & \\ & & & & & & \\ - & \text{---} & \text{---} & \text{---} & \text{---} & \circ & 4 \end{matrix}$

#### Optional boards




Slot	Option/connection variant	Symbol
OUT 6/7 OUT 8/9 OUT 10/11 OUT 12/13	analog output DC 0 to 10 V or DC 0(4) to 20 mA (configurable)	$\begin{matrix} + & \text{---} & \text{---} & \text{---} & \text{---} & \circ & 1 \\ & & & & & & \\ & & & & & & \\ & & & & & & \\ - & \text{---} & \text{---} & \text{---} & \text{---} & \circ & 2 \end{matrix}$

# 6 Electrical connection

## 6.4.5 Binary inputs

### Base unit



Connector/ terminal	Connection variant	Wire	Potential	Terminal			Symbol	
				DC 24 V <sup>a</sup> OUT 8/9	IN 1	IN 2		IN 3
IN 1 to 3	Digital input (potential-free contact)	A	Potential-free contact		1	3	1	
		B			2	4	2	
	In the digital input configuration, the "Contact" option must be set to "Potential-free contact".							
IN 1 to 3	Digital input (external voltage source)	A	Logic signal +		1	3	1	
		B	Logic signal -		2	4	2	
	In the digital input configuration, the "Contact" option must be set to "Ext. voltage supply".							
IN 1 to 3	Digital input (NPN transistor switching output) <sup>b</sup>	A	Switching signal (collector)		1	3	1	
		B	Sensor -		2	4	2	
		C	Sensor +	1				
		D	Sensor -	2				
In the digital input configuration, the "Contact" option must be set to "Potential-free contact".								
IN 1 to 3	Digital input (NPN transistor switching output) <sup>b</sup>	A	Switching signal (collector)		1	3	1	
		B	Sensor -		2	4	2	
		C	Sensor +	1				
		D	Sensor -	2				
In the digital input configuration, the "Contact" option must be set to "Ext. voltage supply".								

<sup>a</sup> For the voltage supply to sensors with DC 24 V, the optional board for voltage supply (part no. 00592963) must be integrated into the device.

<sup>b</sup> The connection variants for transistor switching outputs (NPN / PNP) are especially important for the flow measurement via impeller sensor (type 406020, part no. 00525530, 00525531) at inputs IN 2 and IN 3 (pulse frequency inputs). However, other sensors with transistor switching output can also be connected.

## 6 Electrical connection

### Optional boards


Connector/ terminal	Connection variant	Symbol
IN 13/14/15 IN 16/17/18	3× binary input (potential-free contact)	

### 6.4.6 Digital outputs, power supply unit board

Connector/ terminal	Connection variant	Symbol
OUT 1 OUT 2	Relay Changeover contact	

# 6 Electrical connection

## 6.4.7 Digital outputs, optional boards



Slot	Option/connection variant	Symbol
OUT 6/7 OUT 8/9 OUT 10/11 OUT 12/13	Relay Changeover contact	
	2× relay N/O contact	
	Solid state relay triac 230 V/1 A	
	2× solid state relay PhotoMOS® <sup>a</sup> 50 V/200 mA	
	Digital output 0/22 V	
	2× binary output 0/12 V	

<sup>a</sup> PhotoMOS® is a registered trademark of Panasonic.




## 6 Electrical connection



### WARNING!

Combining a mains voltage circuit with a protective low-voltage circuit on the option "dual normally open contacts" is not permissible.

### 6.4.8 Mains power connection




Connector/ terminal	Connection variant	Symbol
PWR IN	Mains power input	L1 ———— ○ L1 N ———— ○ N PE ———— ○ PE

# 6 Electrical connection

## 6.4.9 Voltage supply outputs

### Optional board



Slot	Connection variant	Symbol
OUT 8/9	Voltage supply DC 24 V for external transmitters 24 V	+ ———— ○ 1 $U_{=}$ - ———— ○ 2
	Voltage supply DC $\pm 5$ V (e. g. ISFET sensors or digiLine)	+ ———— ○ 3 $U_{=}$ ⊥ ———— ○ 4 - ———— ○ 5

# 6 Electrical connection

## 6.4.10 Interfaces






### NOTE!

When installing the bus cabling for digital sensors, heed the information regarding line length and number of sensors in the Annex.

⇒ Chapter 23.2 "Planning the cabling for digital sensors", page 367



### Base unit interfaces



Connector/ terminal	Connection variant	Symbol
COM 1	RS485	
	<p>digital sensors</p> <p>For connection of a digiLine bus line to operate digital sensors, JUMO offers 5-wire M12 digiLine Master connecting cable. A total of up to 6 sensors with digiLine electronics and digital sensors from the product groups 2026xx can be operated over a digiLine bus. The voltage supplies of DC 5 V and DC 24 V for the sensors on the bus are provided by the voltage supply outputs on the device (optional board). ⇒ Chapter 6.4.9 "Voltage supply outputs", page 58</p> <p>Connecting the M12 digiLine connecting cable:  A = Gray  B = Black  C = Brown  D = Blue  E = Blue (preassembled jumper for connection of the GND terminals for 5 and 24 V)  F = White  G = Shield (black with cable lug for connecting to the grounding)</p>	


## 6 Electrical connection





Connector/ terminal	Connection variant	Symbol
USB device	USB device Type Mini-B (socket)	
USB host	USB host Type A (socket)	


## 6 Electrical connection




### Optional board interfaces




Slot	Connection variant	Terminating resistors	Symbol
COM 2	RS422  terminating resistors with DIP switches on optional board configurable	with terminating resistors    without terminating resistors  	RxD+ ○ 1 RxD- ○ 2 TxD+ ○ 3 TxD- ○ 4
	RS485  terminating resistors with DIP switches on optional board configurable		RxD/TxD+ ○ 3 RxD/TxD- ○ 4

## 6 Electrical connection



Slot	Connection variant	Terminating resistors	Symbol
COM 2	<p>digital sensors</p> <p>Connection to optional board: RS422/485 serial interface</p> <p>For connection of a digiLine bus line, JUMO offers 5-wire M12 digiLine Master connecting cable. Up to 6 sensors with digiLine electronics can be operated over a digiLine bus. The voltage supplies of DC 5 V and DC 24 V for the sensors on the bus are provided by the voltage supply outputs on the device (optional board).</p> <p>⇒ Chapter 6.4.9 "Voltage supply outputs", page 58</p> <p>Connecting the M12 digiLine connecting cable:</p> <p>A = Gray            B = Black            C = Brown            D = Blue            E = Blue (preassembled jumper for connection of the GND terminals for 5 and 24 V)            F = White            G = Shield (black with cable lug for connection to the ground)</p>	<p>with terminating resistors</p>  <p>without terminating resistors</p> 	

## 6 Electrical connection



Slot	Connection variant	Terminating resistors	Symbol
COM 2	PROFIBUS-DP 3 = RxD/TxD-P 5 = DGND 6 = VP 8 = RxD/TxD-N	—	
	Ethernet Type RJ 45 (socket)	—	



### NOTE!

Only 1 serial interface per device can be used for digiLine (see Chapter 10.18 "Serial interfaces", page 178).

A maximum of 6 sensors can be connected to the selected interface.

# 6 Electrical connection

---



**WARNING!**

Prior to startup, ensure that the device has been installed and connected properly and in compliance with the installation instructions. Observe the safety instructions in this description.

⇒ Chapter 1 "Safety information", page 13

**CAUTION!**

A buffer battery is built into the device. Its purpose is to maintain data when the device is switched off or if the voltage supply is interrupted. If the battery approaches the end of its operating life (approximately 7 years) then a battery prealarm will indicate that status. When the battery is empty a battery alarm will indicate that status. The battery must be exchanged before it is empty. The battery must be exchanged by the JUMO Service department! In this case, send in the device!

**CAUTION!**

The touchscreen must not be operated with sharp or pointed objects, as these could damage the protective film and the touchscreen.

### 7.1 Initial startup

Step	Action
1	Switch on the supply voltage to the device and wait until it has booted up.
2	Select the operating language.
3	Log in as user "Master" or "Service" in order to have access to the configuration in the device menu. ⇒ Chapter 8.2.1 "Logon/Logoff", page 87
4	Set the date and time. ⇒ Chapter 9.1 "Date and time", page 123
5	Make the basic settings for the device. ⇒ Chapter 10.2 "Basic settings", page 130
6	Configure the analog and digital inputs you wish to use. ⇒ Chapter 10.5 "Analog inputs", page 135 ⇒ Chapter 10.7 "Digital inputs of base unit and optional boards", page 147
7	Check the hardware functions of the device. ⇒ Chapter 7.3 "Function test", page 71
8	Calibrate any analysis sensors connected to the device. ⇒ Chapter 12 "Calibration in general", page 193
9	The device is now ready for use. You can configure the displays and functions of the device according to your needs.

# 7 Startup

---

## 7.2 Digital sensors

**NOTE!**

For operation of digital sensors, you need the extra code "JUMO digiLine protocol activated" (see Chapter 4.2 "Order details", page 22)

### 7.2.1 Initial startup

#### JUMO sensors with digiLine electronics

**NOTE!**

Only one serial interface of the device can be configured for operation of digital sensors. If your device has 2 serial interfaces (base unit and possibly an optional board), select 1 interface for connection of digital sensors and set its protocol to "Modbus digital sensors".

Thanks to plug & play, startup of sensors with digiLine electronics is very simple. As soon as a sensor with digiLine electronics is connected to the bus, the JUMO AQUIS touch P detects and links it to an available (not yet linked) and suitably configured input for digital sensors. The status of the link can be checked in the assignment table. If, prior to connection of the sensor, no input for digital sensors was configured with a suitable sensor type, this can also be done after connection of the sensor. Automatic linking of the sensor to the input for digital sensor occurs here as well. If several sensors of the same kind need to be put into operation, they must be put into operation individually in succession or the link must be established manually in the device menu.

For a sensor to be linked automatically to an input for digital sensors, the following conditions must be met:

- An available (unlinked) input for digital sensors must be configured for the sensor type of the sensor being connected. This can be checked by viewing the assignment table. All configured inputs for digital sensors are listed there with configuration information and link status.
- The sensor type listed for the configured input for digital sensors must match the type of sensor being connected.
- If "TAG check" is activated in the configuration of linkable inputs for digital sensors, the "Sensor TAG" must match the "TAG number" in the digiLine electronics of the sensor.
- The interface configurations of the digiLine electronics and the JUMO AQUIS touch P must match. A bus scan may adjust an incorrect setting of connected digiLine electronics to the interface setting of the AQUIS touch P (see Chapter 8.2.7 "Digital sensors", page 93). When using digital sensors from the JUMO product groups 2026xx, it is necessary to ensure that the serial interface of the device is set to a baud rate of 9600 (see Chapter 10.18 "Serial interfaces", page 178).

### Viewing the assignment table:

⇒ Chapter 8.2.7 "Digital sensors", page 93

### Manual linking:

⇒ Chapter "Procedure for manual linking of sensors", page 96

### Configuring the inputs for digital sensors:

⇒ Chapter 8.2.7 "Digital sensors", page 93

The following table describes the startup procedure for an individual JUMO sensor with digiLine electronics.

Step	Action
1	Log in as user "Master" or "Service" in order to have access to the configuration in the device menu. ⇒ Chapter 8.2.1 "Logon/Logoff", page 87
2	Ensure that the serial interface being used for operation of digital sensors is configured correctly. The protocol must be set to "Modbus digital sensors".
3	Open the configuration of the digital sensors, select an available output for digital sensors and enter the type information for the sensor being connected.  Open the configuration of the digital sensors: Device Menu > Configuration > Digital Sensors 1 to 6 > General
4	Open the assignment table for the digital sensors and check whether an entry exists for the input for digital sensors that was just configured. The line number must match the number of the input for digital sensors and the assignment table entry must show the status "Installation". The status is visualized by symbols in the right column of the assignment table.  Open the assignment table: Device Menu > Digital Sensors  ⇒ Chapter 8.2.7 "Digital sensors", page 93
5	Connect the sensor with digiLine electronics to the bus.
6	Check whether the assignment table entry has changed from "Installation" to "linked". If this is not the case after a waiting period of about 10 seconds, linking has failed. In such a case, check the correctness of the configuration and bus cabling (see Chapter 23.1 "Troubleshooting and remedies for digital sensors", page 363). For diagnosis, it is helpful to display more information about the assignment table entry. To display the information, press the "Info" button. This opens a text window in which, among other things, the most recent bus fault is displayed.  ⇒ Chapter 8.2.7 "Digital sensors", page 93

# 7 Startup

## Digital JUMO sensors from the product groups 2026xx






### NOTE!

Only one serial interface of the device can be configured for operation of digital sensors. If your device has 2 serial interfaces (base unit and possibly an optional board), select 1 interface for connection of digital sensors and set its protocol to "Modbus digital sensors" and the baud rate to "9600".

JUMO sensors with a digital interface from the product groups 2026xx can communicate with the JUMO AQUIS touch P over the digiLine bus just like JUMO sensors with digiLine electronics. However, they do not support plug & play and must be put into operation in another way. The following table describes the startup procedure for an individual digital JUMO sensor from the product groups 2026xx.

Step	Action
1	Log in as user "Master" or "Service" in order to have access to the configuration in the device menu. ⇒ Chapter 8.2.1 "Logon/Logoff", page 87
2	Ensure that the serial interface being used for operation of digital sensors is configured correctly.  The required settings are: <ul style="list-style-type: none"><li>• Protocol: Modbus digital sensors</li><li>• Baud rate: 9600</li></ul>
3	In the configuration, select an available input for digital sensors and enter the type information in the "General" folder of the sensor being connected.  Open the menu: Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > General  ⇒ Chapter 7.2 "Digital sensors", page 66
4	Open the assignment table for digital sensors in the device menu.  Open the assignment table: Device Menu > Digital Sensors  ⇒ Chapter 8.2.7 "Digital sensors", page 93
5	Localize the entry whose number (1 to 6) matches that selected in step 1 and in the configured input for digital sensors.

Step	Action
6	<p>Check whether this entry has the status "Installation". If this is not the case, check the configuration of the selected input for digital sensors.</p> <p>Example of view showing the status of assignment table entries:</p>  <p>⇒ Chapter 8.2.7 "Digital sensors", page 93</p>
7	Connect the sensor to the digiLine bus.
8	Highlight the prepared assignment table entry (status "Installation") by tapping it.
9	<p>Open the "Link" submenu and highlight the assignment table entry that was just created by tapping it.</p>  <p>⇒ Chapter 8.2.7 "Digital sensors", page 93</p>
10	<p>Using the "Scan Button", start a sensor scan and wait until the sensors scan is completed. If the sensor was detected, it will appear in the list of this menu with its status.</p>  <p>⇒ Chapter 8.2.7 "Digital sensors", page 93</p>
11	Leave the "Link" submenu by pressing the "Exit" button. This takes you back to the display of the assignment table.

# 7 Startup

---

Step	Action
6	<p>Check whether the assignment table entry has changed from "Installation" to "linked". If this is not the case after a waiting period of about 10 seconds, linking has failed. In such a case, check the correctness of the configuration and bus cabling (see Chapter 23.1 "Troubleshooting and remedies for digital sensors", page 363). For diagnosis, it is helpful to display more information about the assignment table entry. To display the information, press the "Info" button. This opens a text window in which, among other things, the most recent bus fault is displayed.</p> <p>⇒ Chapter 8.2.7 "Digital sensors", page 93</p>

## 7.2.2 Restarting

### Sensors with digiLine electronics

A digiLine electronics assembly that was disconnected from the bus for maintenance and repair is detected again automatically upon reconnection, linked to its original assignment table entry and resumes operation.

When replacing JUMO digiLine electronics assemblies, each electronics assembly must be replaced individually before the next one is disconnected from the bus. In this way, each new digiLine electronics assembly is linked automatically with the original assignment table entry.

### Digital sensors from the product groups 2026xx

A digital sensor from the product groups 2026xx that was disconnected from the bus for maintenance and repair is detected again automatically upon reconnection, linked to its original assignment table entry and resumes operation.

When replacing digital sensors from the product groups 2026xx, it is necessary to follow the initial startup procedure to put the new digital sensors into operation (see Chapter 7.2.1 "Initial startup", page 66).

## 7.3 Function test


Important hardware information is displayed in the "Device Info" menu.  
The functionality of the device can be checked from here.

### 7.3.1 Checking the optional boards

Open the hardware information for the installed optional boards as follows:  
Device Menu > Device Info > Slots

A tab with hardware and software information for each correctly installed optional board now appears.

Sample screen:  
Hardware  
Information for an optional board  
"Universal input"



If no tab appears for an optional board, the board was not recognized and there is a hardware problem. In such cases, check whether the optional board concerned was installed correctly.

⇒ Chapter 11.1 "Inserting optional boards", page 185

If this is not successful, contact Technical Support at JUMO.

The contact data can be found on the back of these installation instructions.

### 7.3.2 Checking sensors and inputs/outputs

To check correct operation of all inputs/outputs, you can display the current analog and binary values.

Device Menu > Device Info > Inputs/Outputs

Depending on the type of input, up to 2 columns will be visible in the Device Info screens for inputs.

- **Compensated:** Display value that is calculated from the value measured by the sensor through use of an appropriate compensation method and after taking the corresponding calibration values into account.  
This suppresses incorrect measured values that can be caused by outside factors (e.g. temperature) or sensor wear (e.g. a dirty electrode).
- **Uncompensated:** Value measured by sensor (raw value of the measurement input, e.g. pH measuring chain voltage)

## 7 Startup

---

These sensor values are subject to distortion caused by outside factors. Display of uncompensated values is used primarily for diagnostic purposes. The compensated values are used for the actual measurement of analysis variables.

The following example considers analysis inputs in the form of a conductivity measurement input and a pH measurement input. The device calculates the (compensated) values of the process variable from the (uncompensated) raw measurement data.

Sample screen:  
IN 7 measures conductivity  
IN 8 measures pH value  
  
IN 9 to 10 are available only on the JUMO AQUIS touch S.

Device info	
Temperature	Analysis
	Univer ◀ ▶
	Compensated
IN 7:	31,447 mS/cm
IN 8:	7,0091 pH
IN 9:	-----
IN 10:	-----
	Uncomp.
	33,867 mS/cm
	-0,5434 mV
	-----
	-----
13/03/09	21:40:29
Master	100%



## 8.1 Operating concept

This chapter explains how to use the functions at the operating level (e.g. controller and data monitor) and access the menu structure for editing device settings. The JUMO AQUIS touch P is operated by means of the touchscreen, using either a finger or stylus with a soft, rounded plastic tip.



### CAUTION!

The touchscreen must not be operated with sharp or pointed objects, as these could damage the protective film and the touchscreen.



### CAUTION!

Use only a soft cloth to clean the touchscreen. Commercially available cleaners may contain substances that damage the protective film and the display.



### NOTE!

Operation depends on the user's rights. Operating and setting options are restricted, depending on the user who is logged in.

The "Master" and "Service" users have access to all menus and functions (default setting).

⇒ Chapter 8.1.1 "Passwords and user rights", page 73

### 8.1.1 Passwords and user rights

The device has 4 users with factory-configured user names, passwords, and user rights. The passwords in the device can be changed.

⇒ Chapter 8.2.1 "Logon/Logoff", page 87

The JUMO PC setup program is needed to change user names and user rights.

⇒ "User list", page 292

The following table provides an overview of the factory-set user accounts.

#### Factory-set passwords


Users	Every-one	User 2	User 1	Service	Master
Factory-set password	-	20	110	3000	9200

## 8 Operation

### Factory-set user rights

Users	Every- one	User 2	User 1	Service	Master
<b>User rights</b>					
<b>Display of:</b> <ul style="list-style-type: none"> <li>• Current measuring values on overview and detailed screens</li> <li>• Configuration data</li> <li>• parameters</li> <li>• Device information</li> </ul>	X	X	X	X	X
<b>Display of:</b> <ul style="list-style-type: none"> <li>• History of measurement data in the recording function</li> <li>• Event and alarm list</li> <li>• Service data</li> </ul> <b>User actions</b> <ul style="list-style-type: none"> <li>• Acknowledge alarms</li> <li>• Calibrate</li> <li>• Read out history of measurement data in the recording function</li> <li>• Display and change user level parameters</li> <li>• Read out service data</li> <li>• Link digital sensors manually</li> </ul>		X	X	X	X
<b>User actions</b> <ul style="list-style-type: none"> <li>• Operate control functions</li> </ul> <b>Change settings</b> <ul style="list-style-type: none"> <li>• Changing the settings at the perimeter level</li> <li>• Set date and time</li> </ul> <b>Configuration</b> <ul style="list-style-type: none"> <li>• Initialize calibration</li> </ul>			X	X	X
<b>Configuration</b> <ul style="list-style-type: none"> <li>• Configuration of all functions</li> <li>• Activate extra codes</li> </ul>				X	X

## 8.1.2 Display and control elements



- (1) Touchscreen
- (2) Toolbar with buttons for operation
- (3) "Device menu" button with display of:
  - Date and time
  - Logged-in user ("Master" in the example)
  - Remaining memory display in percent for recording function (in the example: 100 %)
- (4) "Alarm/Event List" button
- (5) "Select operator screen" button (direct selection of the desired operation screen)
- (6) "Home" button (back to main screen)
- (7) Placeholder for context-sensitive buttons  
Assignment depends on the particular operator screen.  
Specific buttons are shown in the placeholders on the operation screens for the controller and recording functions.
- (8) "Next operation screen" button (for scrolling through operator screens)

# 8 Operation

---


## 8.1.3 Menu structure

At the **operating level**, 3 different navigation buttons are available to select appropriate screens for display and control of device functions.

The "**Device menu**" and "**Alarm/event list**" menu levels are also displayed by means of corresponding buttons. The device menu contains submenus for setting, servicing, and diagnosing the device and its functions.

The **memory manager** opens automatically as soon as a USB flash drive is inserted into the USB host interface. It exchanges data between the device and the flash drive.

## Overview of the menu structure



## 8 Operation

---




**NOTE!**

The "Recorder Update to USB" and "Recorder Backup to USB" items appear in the "Memory Manager" menu only if the extra "Recording function" is enabled.

⇒ Chapter 4.2 "Order details", page 22

# 8 Operation

## Operation screens in the operation loop



## 8 Operation

Diagram	Operator screen	Description
(1)	General screen 1	Freely configurable overview display of measuring values and digital signal states  The overviews can be configured as a 2-part screen or a 4-part screen. <b>2-part screen:</b> Display of 2 primary and 2 secondary measured values per screen, 1 additional measured value and 3 binary values. <b>4-part screen:</b> Display of 4 primary and 4 secondary measured values per screen, 1 additional measured value and 3 binary values.
(2)	General screen 2	
(3)	Detailed screen 1	Freely configurable large-section screen  Display of 1 main measuring value, 1 second measuring value, 1 additional value and up to 3 binary values, as well as additional visualization of the main measuring value and the alarm limits for an analog input with a bar graph
(4)	Detailed screen 2	
(5)	Detailed screen 3	
(6)	Detailed screen 4	
(7)	Detailed screen 5	
(8)	Detailed screen 6	
(9)	Diagram group 1	Up to 4 analog measuring values and 3 digital functions can be displayed on a configurable recorder screen. Diagrams of disabled groups are not available in the operation loop.
(10)	Diagram group 2	
(11)	Process screen	User-defined visualization screen that is freely configurable by means of an editor in the PC setup program ⇒ Chapter 21.8.11 "Process screens", page 310  With the aid of static and dynamic graphic and display elements for analog and binary values, it is possible to create a screen that displays the process flow concerned in an especially vivid manner. If no process screen is configured, none is available for the operation loop.
(12)	Controller overview	The active controller channels are visualized here in an overview display. The controller overview becomes available as part of the operating loop only if at least 2 controllers are activated. The current setpoint values, actual values and output levels are displayed for all active controllers. In addition, the operating states of the controllers are displayed (manual mode, hold, self-optimization).
(13)	Controller screen Controller 1	The controllers are visualized in detail on the controller screens. The controller screens are available as part of the operation loop only for the respectively configured channels. The information displayed includes the current setpoint value, actual value and output level. The binary values of switching controller outputs are visualized. In addition, controls for setpoint value entry, manual output level control and self-optimization are available. Access to the operating functions depends on the user rights of the logged-in user.
(14)	Controller screen Controller 2	
(15)	Controller screen Controller 3	
(16)	Controller screen Controller 4	




## Display of invalid values

Invalid input signals/measured values or errors in the analog input configuration are detected and shown in the measured value displays as follows:

Type of error	Display
<b>underrange:</b> measuring range underflow	<<<<<
<b>overrange:</b> measuring range overflow	>>>>>
<b>Compensation error:</b> An error occurred when compensating for factors affecting the measurements of the analysis. It is necessary to check the measuring circuits and settings of the compensation signals and the configuration of the analysis measuring input affected.	+++++
<b>Invalid display value</b> Possible errors include: <b>Incorrect input signal:</b> An analog input has an incorrect signal or an analog input was selected for which an optional board is not even present. <b>Error in the formula used by the mathematics module:</b> The result from a formula is invalid (e.g. division by zero)	-----
<b>Display overrun:</b> The value to be displayed is outside the limits of -99999 to +99999.	* * * * *

## Example of display of invalid values:



# 8 Operation


## 8.1.4 Entry of text and numbers

Dialogs for entry of text or numbers appear automatically when the corresponding entry field is tapped.

### Text entry dialog

There are 2 special features in addition to conventional entry of characters:

- **Special characters** appear for selection automatically at those buttons that contain special characters.
- **The text list** simplifies entry of frequently used character strings. A history of character strings entered is stored internally in the device. These are then available for selection in the text list and can be copied simply by tapping the line for the entry.




## Number entry dialog

This dialog opens if an entry field for numerical values is tapped.







Special feature : The **"Exp"** button permits entry of an exponent as a power of ten.

Procedure:

Enter the numerical base value > Tap "Exp" > Enter the exponent > Confirm the entry



## Entry dialog buttons

Explanation	Button
Confirm entry (the value entered is accepted and the dialog closed)	
Cancel entry (the value entered is discarded and the dialog closed)	
Delete 1 character	
Delete entry line completely	
Open text list (select from a history of character strings entered)	
Entry of an exponent as a power of ten	

# 8 Operation

## 8.2 Device menu



**NOTE!**

Operation depends on the user's rights. Operating and setting options are restricted, depending on the user who is logged in.

The "Master" and "Service" users have access to all menus and functions (default setting).


⇒ Chapter 8.1.1 "Passwords and user rights", page 73

The device menu contains submenus for setting and configuring all device functions.

To open one of the submenus in the device menu, tap the corresponding entry. The device menu is opened by tapping the "Device menu" button at the operating level.

⇒ Chapter 8.1.2 "Display and control elements", page 75

⇒ Chapter 8.1.3 "Menu structure", page 76




Device menu items	Description
Logon/Logoff	This is where the user logs on and logs out. In addition, passwords can be changed here. ⇒ Chapter 8.2.1 "Logon/Logoff", page 87
Calibration	Sensor calibration can be configured and performed here. In addition, current calibration values and the calibration log-book are displayed. ⇒ Chapter 12 "Calibration in general", page 193

Device menu items	Description
User level	<p>Permits fast and simple access to a selection of up to 25 frequently needed parameters from the parameter level and the configuration level.</p> <p>No user level is configured at the factory. The user level must be configured and loaded into the device with the aid of the JUMO PC setup program. The "User Level" entry does not appear in the device menu as long as no user level is configured.</p> <p>⇒ Chapter 8.2.2 "User level", page 88</p>
Configuration	<p>Basic operation of the device inputs and outputs and the device functions is set here.</p> <p>⇒ Chapter 10 "Configuration", page 129</p>
Parameterization	<p>Setting the date/time and controller parameter sets, as well as pre-setting controller setpoint values. Fixed numerical values can be defined in the "Manual values" submenu.</p> <p>⇒ Chapter 9 "Parameterization", page 123</p>
Functional level	<p>Manual operation of certain functions for testing and diagnostic purposes (e.g. start wash contact or reset counter)</p> <p>⇒ Chapter 8.2.3 "Functional level", page 89</p>
Device information	<p>Information about the device hardware and software, viewing of current analog and binary values for all device functions, inputs, and outputs</p> <p>⇒ Chapter 8.2.4 "Device information", page 91</p>
Service	<p>Display and readout of service data for diagnostic purposes, saving, and loading of a default configuration and performance of the basic Ci base calibration for startup of Ci analysis inputs (inductive conductivity)</p> <p>⇒ Chapter 8.2.5 "Service", page 92</p>
Calibrate Touchscreen	<p>Calibration of the touchscreen to ensure the reliability and convenience of touch control</p> <p>⇒ Chapter 8.2.6 "Calibrating the touchscreen", page 93</p>
Digital sensors	<p>Open an overview of all configured digital sensors (Assignment table), check the link status of the sensors and manually link sensors that are not linked</p> <p>⇒ Chapter 8.2.7 "Digital sensors", page 93</p>

## 8 Operation

---


To navigate in submenus, menu items are opened by tapping the folder icons identified with a plus sign. Open menu structures are identified with a minus sign and can be closed again by tapping the folder icon. Currently open windows can be left either by tapping "Exit" or the "Close window" button. Data are saved automatically when an open window is closed. Settings that were changed in the submenus take effect.



- (1) Close window
- (2) Closed menu structure (plus sign)
- (3) Open menu structure (minus sign)

### 8.2.1 Logon/Logoff

To access the "Logon/Logoff" menu, tap the "Device menu" button and then select the "Logon/Logoff" menu item. The user can log on/off here and change passwords for the currently configured user accounts.



An overview of the factory-configured users and their rights can be found in the "User Management" chapter.

⇒ Chapter 8.1.1 "Passwords and user rights", page 73

After the re-authentication time has elapsed, a logged-on user is logged off automatically. It is then necessary to log on again.

The re-authentication timeout does not take effect if:

- The logon/logoff dialog is open
- The memory manager is open
- During calibration of analysis sensors
- During calibration of the touchscreen

The re-authentication time is set using the JUMO PC setup program.

⇒ Chapter 21.8.3 "User list", page 292

# 8 Operation

## 8.2.2 User level

The user level consists of a user-defined list of parameters and configuration settings. You need the JUMO PC setup program to configure the user level.

⇒ Chapter 21.8.6 "User level", page 303

The user level can be opened from the device menu only if it has been configured beforehand with the aid of the PC setup program. If this has not been done, there is no user level in the device menu.

Opening the user level provides easy and uncomplicated access to the selected parameters and settings. These can be edited from here. The entry dialog is opened by tapping the display field for a desired data point.

### View of the user level (example)

User level	
	<input type="button" value="OK"/> <input type="button" value="Cancel"/>
Device name	<input type="text" value="Name"/>
Config. IP address	<input type="text" value="Automatic"/>
DNS device name	<input type="text" value="North plant"/>
Time dosing pump	<input type="text" value="00:03:00"/>
Washing time pH-s...	<input type="text" value="10 min"/>
Washing time cond..	<input type="text" value="10 min"/>

To make an entry, tap the display



#### NOTE!

Changing the date/time settings and the configuration data that are relevant for recording of measurement data initiates a restart of measurement data recording by the data monitor or recording function. This is also the case if the change is made from the user level. The restart terminates the current recording of measurement data. In the case of the "Data monitor" function, the content of the screen is deleted.



### 8.2.3 Functional level

The functional level is used primarily for testing and diagnostic purposes. Analog and binary values of the outputs can be controlled manually here. This may be useful, for instance, for checking an individual piece of equipment in a plant. When performing maintenance and repair work, counters for operating hours, switching actions and flow rates can be reset.



#### **WARNING!**

When manually controlling equipment in a system, it is absolutely essential to take appropriate measures to prevent personal injury and property damage. Ensure that only qualified personnel has access to the functional level. The factory settings restrict access to just "Master" and "Service" users.

#### **Functional level menu items:**

- **Flow:** Display the current flow rate, display and reset the total quantity counter
- **Washtimer:** Manually start the wash process, display the time remaining until the wash process and the current binary value
- **Analog outputs:** Read and manually control the current values of analog outputs
- **Digital outputs:** Read current binary values, manually control digital output outputs
- **Counters:** Reset the counters (operating hours and service counters)



#### **NOTE!**

Manual control of analog and digital outputs is possible only if the "Enable menu. mode" option is activated for the specific output in the configuration. In general, actions at the function level can be executed only by the "Master" and "Service" users.

- ⇒ Chapter 10.6 "Analog outputs of base unit and optional boards", page 146
- ⇒ Chapter 10.8 "Digital outputs of base unit and optional boards", page 148
- ⇒ Chapter 8.2.1 "Logon/Logoff", page 87

# 8 Operation

---


## Manual control of analog/digital outputs

Activate the configuration setting "Enable menu mode" for the outputs you wish to control manually. "Manual mode buttons" buttons for manual control for these outputs then appear at the functional level. To adjust output values manually, proceed as follows:

Select Device Menu > Functional Level > Analog or Digital Output tab > Tap "Manual mode" button > Tap Output Display field > Entry dialog opens > Enter value > Confirm

An activated manual mode can be recognized by the green background of the particular output value display at the functional level.

### View of functional level analog outputs (example)



- (1) "Manual mode" button
- (2) Yellow background: Manual mode off
- (3) Green background: Manual mode active

Once "Manual mode" has been switched off, the output immediately returns to the value assigned in its configuration. The output display is once again yellow.

### 8.2.4 Device information

For testing and diagnostic purposes, the "Device info" menu provides access to extensive data about the hardware and software of the device, as well as current analog and binary values.

#### Device Info menu items:

- **General:** Information about the main board, device software and Ethernet configuration
- **Slots:** Equipping overview of expansion slots, display of diagnostic and version information for the installed optional boards
- **Inputs/outputs:** Overview of all analog and binary values of the inputs and outputs of the device
- **Functions:** This menu is particularly helpful when checking functions after configuration changes. It contains detailed information about all internal functions (math/logic, flow, limit value, timer, washtimer, counter, and controller) via their current status.
- **Ethernet info:** Ethernet communication statistics for diagnosis by trained personnel

# 8 Operation

---

## 8.2.5 Service

The "Service" menu is used for in-device troubleshooting and diagnostics. It is intended primarily for trained personnel. When troubleshooting together with Service, the operator can access data that the JUMO service technicians need for diagnosis.




**NOTE!**

The Service menu appears in the Device menu only if a user with corresponding user rights is logged in.

⇒ Chapter 8.2.1 "Logon/Logoff", page 87

### Service Menu items

- **Default-configuration:** The operator can store the current device configuration in the device's memory. This configuration can be reloaded as the active configuration at any time. This is important, for instance, to return to the initial configuration after configuration changes made for testing purposes.



Configurations can also be saved with the PC setup program or on a USB flash drive with the aid of the Memory Manager.

⇒ Chapter 8.4 "Memory Manager (USB flash drive)", page 104

- **Debug Window:** The Debug window can be used to check the behavior of the device software in detail. Data are displayed to assist the JUMO service technicians during troubleshooting.
- **Ci base calibration:** The Ci base calibration is required when starting up an optional board or sensor for inductive conductivity measurements and can be performed here.  
⇒ Chapter 11.2 "Ci base calibration", page 188
- **Digital sensor 1 to 6:** For each digital JUMO sensor from the product group 2026xx that is operating on the device, a menu appears here that allows you to reset the calibration date of the sensor to the default settings.

- **Service data: Status information** that can be evaluated by JUMO service personnel for diagnostic purposes can be read here. In addition, the "**Service count.**" and "**Internal data**" are displayed. The service counters record the number of switching operations executed by the digital outputs. The **voltage of the buffer battery** and the **board temperature** are shown in the "Internal data".



### CAUTION!

A buffer battery is built into the device. Its purpose is to maintain data when the device is switched off or if the voltage supply is interrupted. If the battery approaches the end of its operating life (approximately 7 years) then a battery prealarm will indicate that status. When the battery is empty a battery alarm will indicate that status. The battery must be exchanged before it is empty. The battery must be exchanged by the JUMO Service department! In this case, send in the device!

### 8.2.6 Calibrating the touchscreen

To ensure precise and reliable operation of touchscreen control, you can open the "Calibrate touchscreen" menu.

The device then prompts you tap 4 points on the touchscreen. Simply follow the instructions on the display.



### 8.2.7 Digital sensors

The assignment table (list of all configured inputs for digital sensors) is displayed here. Up to 6 digital sensors can be connected and operated via the selected serial interface. The link status of the configured sensors is displayed in the form of a symbol in the right column.

Setpoint-Table			
	Description	Parameter	
1	Digit. sensor 1	pH	
2	Digit. sensor 2	pH	
3		No sensor	
4		No sensor	
5		No sensor	
6		No sensor	



## 8 Operation

### Link status symbols for the assignment table entries

Status	Explanation	Symbol
linked	Communication between the sensor electronics and the JUMO AQUIS touch P has been successfully established. The sensor is operating.	
Installation	<p>The device searches for the individual assignment table entry of a linkable sensor. A new sensor can be linked manually or automatically if the following prerequisites are met:</p> <ul style="list-style-type: none"> <li>• The sensor type must match the settings of the assignment table entry.</li> <li>• The sensor version must be compatible</li> <li>• Operation of bus communication must be assured through correct interface settings (with JUMO digiLine electronics, the interfaces are configured automatically during the scan)</li> </ul> <p>Known sensors are identified and assigned and linked with the known entry            After successful assignment, the status changes from "Installation" to "linked" following connection of the sensor to the bus. If a sensor cannot be linked, the status remains "Installation". If the status has not changed from "Installation" to "linked" after a waiting period of about 15 seconds, linking of the sensor electronics has failed. A description of the startup procedure for digital sensors can be found in the chapter on startup.            ⇒ Chapter 7.2 "Digital sensors", page 66</p>	

## 8 Operation

In addition to the "Exit" button, this view also has "Info" and "Link" buttons. The following table explains the function of these buttons.




Explanation	Button
The "Info" button opens an overview of important information to more easily identify the individual sensor connected.	
With the "Link" button, you can access the submenu for linking sensors that are not linked. Digital sensors from the JUMO product groups 2026xx must be linked by means of this button during startup. When errors occur during the startup of digital sensors, you usually have the ability here to detect connected digital sensors by means of a bus scan and then to link the detected sensors manually. Help for problems when sensor electronics cannot be detected or linked can be found in the Annex. ⇒ Chapter 23.1 "Troubleshooting and remedies for digital sensors", page 363	

### Submenu for linking

In this menu, the bus can be "scanned" for connected sensors. The sensors detected are displayed in a list. Sensors that are not detected cannot be linked here manually. In addition to the "Exit" button, this view also has "info", "Scan" and "Link" buttons. The following table explains the function of these buttons. In this menu, the bus can be "scanned" for connected sensors. Corresponding user rights are needed to access the "Link" submenu. The default settings authorize the "Master", "User 1", "User 2" and "Service" users for this.


⇒ Chapter 8.1.1 "Passwords and user rights", page 73

The following table explains the function of these buttons.

Explanation	Button
The "Info" button opens an overview of important information to more easily identify the individual sensor connected.	
Pressing the "Scan" button starts the search for sensors connected to the bus. Detected sensors are listed on conclusion of the bus scan.	
Detected sensors can be linked manually with the "Link" button in this menu. It appears in this view when one of the detected sensors in the list has been highlighted by a tapping it in this menu. The procedure is described at the end of this table. Help for problems when digital sensors cannot be detected or linked can be found in the Annex. ⇒ Chapter 23.1 "Troubleshooting and remedies for digital sensors", page 363	

## 8 Operation




### Procedure for manual linking of sensors

Step	Action																			
1	In the "Digital Sensors" menu, highlight the assignment table entry to be linked.																			
2	Open the "Link" submenu by tapping the corresponding button in the "Digital Sensors" menu.																			
3	Open the "bus scan" by pressing the "Scan" button (magnifying glass).																			
4	In the list of detected sensors, highlight the one that you wish to link with the previously highlighted assignment table entry. JUMO sensors with digiLine electronics can be identified by the hardware address on the nameplate of the digiLine electronics. It is also displayed in the list of detected sensors and in the sensor information ("Info" button).																			
5	The "Link" button now appears above the table. Press this button to link the selected assignment table entry with the sensor selected from the list of detected sensors.																			
6	<p>If the link was successful, the previously selected entry now has the status "linked" in the assignment table. If the sensor electronics could not be linked, an error message appears. The error message displays a table with information about the selected assignment table entry and the sensor selected from the list of detected sensors. The error message is displayed in the lower area.</p> <p><b>Example of an error message:</b> No assignment table entry was selected before the "Link" submenu was opened.</p>  <table border="1" data-bbox="906 1099 1422 1480"> <thead> <tr> <th colspan="2">Info</th> </tr> <tr> <th></th> <th></th> </tr> <tr> <th></th> <th>Actual</th> <th>Sensor</th> </tr> </thead> <tbody> <tr> <td>Type</td> <td></td> <td>pH</td> </tr> <tr> <td>VdN</td> <td></td> <td>0</td> </tr> <tr> <td>TAG</td> <td></td> <td></td> </tr> <tr> <td>With temp</td> <td></td> <td>Yes</td> </tr> </tbody> </table> <p>No sensor selected</p>	Info					Actual	Sensor	Type		pH	VdN		0	TAG			With temp		Yes
Info																				
	Actual	Sensor																		
Type		pH																		
VdN		0																		
TAG																				
With temp		Yes																		



### Bus status display

The operating status of the digiLine bus is visualized in the title bar. The symbols used for this and their meaning are explained in the following table.

<p><b>Green</b> There are no bus errors. All sensors are linked and functioning.</p>	
<p><b>Red</b> This symbol appears in the title bar when connecting sensor electronics that have not yet been linked with the device. As soon as the sensor electronics are linked, the bus status changes to "Green". Furthermore, the "Red" status is also displayed during a bus scan (manual or after the device is switched on).</p>	
<p><b>Yellow</b> The "Yellow" status appears in the title bar when digital sensors are not linked, e. g. As the result of defective components in the bus or a faulty configuration (see Chapter 23.1 "Troubleshooting and remedies for digital sensors", page 363).</p>	

## 8 Operation

---

### 8.3 Alarm/Event list


The JUMO AQUIS touch P offers the option of configuring alarm functions and event functions in numerous functions. In addition, the electronics of the JUMO AQUIS touch P are self-monitoring and trigger corresponding preprogrammed alarms and events in case the internal device malfunctions.

Alarms and events appear in the lists in chronological order. The respective list is opened from the "Alarm/Event List" menu.

The alarm/event list is opened by tapping the "Alarm/event list" button at the operating level.

⇒ Chapter 8.1.2 "Display and control elements", page 75


⇒ Chapter 8.1.3 "Menu structure", page 76



## 8.3.1 Alarm list

The alarm list displays the current alarms. Alarms are cleared upon elimination of the alarm condition. Each alarm triggers a "collective alarm". The alarm list view contains buttons for viewing details about alarms and acknowledging collective and dosing alarms.

⇒ "Acknowledging collective/dosing alarms", page 101



Alarms are visualized further by the color of the bell icon on the "Alarm/event list" button, in the "Alarm list" menu item of the "Alarm/event list" menu and in the title bar of the operation screens. The symbols used for visual signaling of alarms are listed in the following table.

Meaning	Symbol
at least 1 alarm present	
Details can be viewed in the "Alarm list" and in the "Event list".	
no alarms	

Visualization of alarms in the title bar can be activated in the configuration. The most recently occurring alarm then flashes red in the title bar of the operation screens.

⇒ Chapter 10.3.1 "Generally", page 131

If the alarm from a measuring input disappears, the color of the respective measuring-value display changes in accordance with the color settings.

⇒ Chapter 10.3.3 "Colors", page 132

## 8 Operation

---

All alarms are available in the binary selector. In this way, digital outputs or other internal functions of the device can be controlled via alarms.

### Acknowledging collective/dosing alarms

The **collective alarm** combines all alarms in the alarm list. It simplifies signaling of one or several active alarms with external indicating devices or to control rooms. The digital signal for the collective alarm is available in the binary selector in 2 versions:

- **Collective alarm:** Is triggered by the occurrence of any alarm and disappears only after all alarms in the alarm list have been cleared.
- **Collective alarm ack.:** Is triggered by the occurrence of any alarm and disappears when the alarm is acknowledged.

Selection of a collective alarm when configuring device functions and digital outputs:

Binary selection > Alarm and Internal Signals >  
Collective Alarm/Collective Alarm Ack.

**Dosing alarms** are triggered by the controllers if the absolute value of the control deviation is larger than the "alarm tolerance". An "alarm delay" can be set for each dosing alarm. Dosing alarms and acknowledgment of them must be activated in the controller configuration. The "alarm tolerance" and "alarm delay" settings are made in the controller parameters.

⇒ Chapter 10.12.1 "Configuration of the controllers", page 164

⇒ Chapter 9.2 "Parameter Sets (Controller parameter)", page 124

Selection of a dosing alarm when configuring internal functions and digital outputs:

Binary Selection > Controller > Dosing Alarm, Controller 1 to 4

Collective and dosing alarms can be acknowledged with the "Confirm" button.


# 8 Operation

## 8.3.2 Event list

A number of situations that are essential for tracking and diagnostic purposes are logged in the event list. The entries are identified with corresponding icons on the basis of the type of event. In addition, events are logged with an icon in the data monitor/recording function.







Detailed information on the data monitor/recording function

⇒ Chapter 8.6 "Operation of the data monitor/recording function", page 113




## 8 Operation

The following table provides an overview of the possible entries in the event list.

Events	Symbol
Power on	
Power off	
Alarm occurred	
Alarm cleared	
<ul style="list-style-type: none"> <li>• Configured event (condition occurred)</li> <li>• Calibration start</li> <li>• Timer start</li> <li>• Wash contact start</li> <li>• Controller manual mode on</li> <li>• Controller self-optimization started</li> </ul>	
<ul style="list-style-type: none"> <li>• Configured event (condition ended)</li> <li>• Calibration stop/cancel</li> <li>• Timer stop</li> <li>• Wash contact stop</li> <li>• Controller manual mode off</li> <li>• Controller self-optimization ended</li> </ul>	
<ul style="list-style-type: none"> <li>• Switch daylight saving time</li> <li>• No connection to an input module</li> <li>• Configuration change</li> <li>• Reset counter</li> <li>• Reset flow measurement</li> <li>• Confirm collective alarm</li> </ul>	No symbol

## 8 Operation

### 8.4 Memory Manager (USB flash drive)



The Memory manager is used to transfer data between the JUMO AQUIS touch P and a USB flash drive. To open the memory manager, close all windows and insert the USB flash drive into the USB host interface. The memory manager will then open automatically. You require the relevant user rights for access to the menu options "USB->Configure devices" and "Software update". The factory settings authorize the "Master" and "Service" users for this.

⇒ Chapter 8.1.1 "Passwords and user rights", page 73

#### Memory Manager menu items:

- **Safely remove hardware:** To prevent hardware damage or loss of data, it is necessary to select this menu item before removing and inserted USB flash drive. Please follow the instructions on the device's display.
- **Recorder Update -> USB:** Use this function for **regular retrieval of recorder data** and **continuous archiving** of measured-data histories. Measurement data that have not yet been retrieved are stored on the flash drive together with their configuration data. The measurement data are stored in DAT files and the configuration data in SET files. These files can be opened and evaluated with the aid of the JUMO PCA3000 evaluation software. Data that has been read out is marked internally as retrieved and the available memory display is reset to 100 %.



#### CAUTION!

Ensure that recorder updates are performed in a timely manner!  
When the ring memory is full (display of remaining memory in device reads 0 %), measurement data in the ring memory is lost (starting with the oldest).

- **Recorder Backup -> USB:** This function is used to **back up** the recorder data to **prevent data loss**. All measurement data in the ring memory (also data already retrieved) are transmitted to the flash memory together with their configuration data. The measurement data are stored in DAT files and the configuration data in SET files. These files can be opened and evaluated with the aid of the JUMO



PCA3000 evaluation software.

In contrast to Recorder Update, there is no internal marking of recorder data and no resetting of the available memory display.



**NOTE!**

The "Recorder Update" and "Recorder Backup" functions are available only if the extra code "Recording" is enabled.



**NOTE!**

A measuring data recording session is closed by changing configuration data that are relevant to the data monitor or registration function (e.g. scaling or description of an analog channel). The measurement data accumulated since the beginning of the current recording session are stored in the device in a file with the extension "DAT" together with an additional file with the extension "SET". A new recording session begins as soon as the new configuration goes into effect. One DAT file and one SET file are created for each recording session when recorder data are retrieved via Update or Backup.

- **Device Config. -> USB:** The complete, current configuration of the device is transmitted to the flash drive and saved in a file with the name "KONF304.SET". If the flash drive already contains a configuration file, a security prompt appears asking whether you are sure you want to overwrite this file. Pressing the "OK" button saves the current configuration to the flash drive and overwrites the previous file.

## 8 Operation

---

- **USB -> Device config.:** A configuration that is saved on the flash drive is loaded into the device and activated as the current configuration. Only the currently active configuration is overwritten. The previous default configuration is retained. If desired, the current configuration can be saved as the default configuration.  
⇒ Chapter "Service Menu items", page 92



### NOTE!

A check of version compatibility is performed when transferring device configurations from the USB flash memory to the device. If the device setup on the USB flash drive is incompatible with the version of the device software of the destination device, the transfer is terminated. The second term of the device version number must be greater than or equal to the second term of the device version number used to create the device setup file.

Examples of combinations of version levels:

Device software version used to create the configuration = 304.**02**.xx, device software version of the destination device = 304.**02**.xx,  
The versions are compatible

Device software version used to create the configuration = 304.**01**.xx, device software version of the destination device = 304.**02**.xx,  
The versions are compatible

Device software version used to create the configuration = 304.**02**.xx, device software version of the destination device = 304.**01**.xx,  
The versions are not compatible

- **Service data -> USB:** A data record with service-relevant information about the device is transmitted to the flash drive and saved in a file with the name "DEBUG304.SET". The information can be used by JUMO Service for diagnostic purposes.
- **Software Update:** The device software can be updated with the aid of a USB flash drive. To do so, an appropriate update file must have been saved on the flash drive in advance; this file can be obtained from JUMO Service.



### CAUTION!

It is strongly recommended that the configuration and recorder data be backed up prior to performing a software update.

### 8.5 Operating the controllers

**NOTE!**

Since the automatic control mode is of prime importance in the case of controllers, correct configuration of the individual controller and its parameterization (adjustment of the control response) are very important for achieving good process value stability.

Before starting up a controller channel, ensure that all settings in the configuration and the parameterization are correct.

⇒ "Operating the controllers", page 107

⇒ Chapter 9.2 "Parameter Sets (Controller parameter)", page 124

**NOTE!**

In most cases, the parameterization are made automatically with the aid of self-optimization. In exceptional cases, however, it may be necessary to determine

the controller parameters experimentally or to calculate them and then enter them into the controller's parameter sets manually.

How to operate the 4 different operating modes (automatic mode, manual mode, hold mode and self-optimization) is described in the following 4 subchapters.

# 8 Operation

---

## 8.5.1 Automatic control mode


The automatic control mode is the normal operating mode used by the controller to maintain the actual value of a process variable at the specified setpoint. The controller evaluates the control deviation and controls the output such that the actual value of the process approaches the setpoint. Changes to the current setpoint can be made in the controller operator screen or in the "parameterization". Two setpoints are stored for each controller in the parameterization. Setpoint 1 is active by default. Setpoint 2 can be activated instead of Setpoint 1 in each controller by means of "Setpoint selection". Setpoints can also be specified by external sources and transmitted to the controllers in the JUMO AQUIS touch P via analog inputs. "Setpoint selection" and the configuration of external setpoints are set in the "Setpoint configuration".

⇒ Chapter 9.3 "Setpoint values", page 127

⇒ Chapter 10.13 "Setpoint value configuration", page 171

## 8 Operation

On the operator screen of each controller, it is possible to change the current controller setpoint value, switch to the "Manual mode" or start "Self-optimization".



- (1) Display of the digital controller output signals as indicator lights
- (2) "Manual entry" button for changing the current setpoint value  
A change to the currently active setpoint value is transferred to the controller parameters. When external setpoint values are used, this button is hidden.
- (3) Bar graph to display the current output level
- (4) Start/cancel "self-optimization" button  
Self-optimization is used to determine the optimal controller parameters automatically.
- (5) "Manual mode" on/off button  
When manual mode is activated, the output level assumes a preconfigured value and can then be changed manually.  
⇒ Chapter 8.5.2 "Controller in the manual mode", page 110
- (6) Numerical display of the current output level
- (7) Display of the current setpoint value
- (8) Display of the current actual value

# 8 Operation

## 8.5.2 Controller in the manual mode


In manual mode, the user can manually control the controller outputs. The controller outputs can be controlled in two ways:

- **Entry of a numerical value:** Using the "Manual entry" button, the user can open a dialog to enter a fixed numerical value for the output.
- **Jogging mode:** Pressing and holding the arrow buttons sets the output to  $\pm 100\%$  or the corresponding digital controller output to "on" depending on the controller configuration. After the button is released, the output level returns to 0% or the corresponding digital controller output level back to "off". This function is used to operate actuators (e.g. solenoid valves, dosing pumps or motorized positioners) manually. To protect the actuators, the output does not change abruptly when the button is pressed, but rather in a continuous manner.

It is also possible to specify a manual output level in the configuration in order to ensure that a "safety output level" is generated when changing to the manual mode.

The manual output level is preset in the controller configuration.

⇒ Chapter 10.12 "Controller", page 164



- (1) Display of the digital controller output signals as indicator lights
- (2) Display of active manual mode
- (3) "Manual entry" button for entering the manual output level
- (4) "Jogging mode" button for manual control of actuators
  - **Down arrow** for output level = -100% or digital controller output off (only for three-point, three-point step controllers and continuous controllers with integral position controller)
  - **Up arrow** for output level = +100% or digital controller output on
- (5) "Manual mode" on/off button
- (6) Bar graph to display the current output level
- (7) Numerical display of the current output level

### 8.5.3 Hold mode

The hold mode of a controller is activated in two ways:

- Calibration of the actual-value input
- Hold signal for the individual controller (specified in the controller configuration)


In the hold mode, automatic control is suspended. The controller generates the preconfigured value as output level unless acceptance of the hold output is disabled in the configuration. In this case, the output level is frozen.

Only the setpoint value can be changed in this operating mode. In the hold mode, however, the setpoint value change has no effect. The changed setpoint value takes effect only when the controller returns to the automatic control mode.

The hold mode has priority over the manual mode. If the hold mode is activated while the controller is in the manual mode, the controller changes from manual mode to hold mode and then returns to manual mode when hold mode is deactivated.

The hold output level is preset and the digital signal for activating hold mode is set in the controller configuration.

⇒ Chapter 10.12 "Controller", page 164



- (1) Display of active hold mode
- (2) "Manual entry" button for changing the current setpoint. The change to the currently active setpoint is transferred to the controller parameters. The output level, however, remains frozen during hold mode. When external setpoint values are used, this button is hidden.

To configure external setpoint values:

⇒ Chapter 10.13 "Setpoint value configuration", page 171

# 8 Operation

## 8.5.4 Optimizing controllers


The control response can be optimized by entering known controller parameters manually or automatically by means of "self-optimization". During self-optimization, the individual controller determines the mathematical parameters for a process. The controller changes the output level (step change) and evaluates the response of the actual value in the process (step response). Following successful self-optimization, the controller parameters determined in this way are adopted in the "Parameterization" function

⇒ Chapter 9.2 "Parameter Sets (Controller parameter)", page 124



### WARNING!

During self-optimization, the controller outputs assume unpredictable values! Before a self-optimization starts, it must be ensured that greater deviations between the actual value and the set setpoint value do not cause property damage or physical injury.



- (1) Display of active self-optimization
- (2) Start/cancel "self-optimization" button
- (3) Button for changing the current setpoint value  
Changing the setpoint values during self-optimization is not possible.
- (4) Bar graph to display the current output level
- (5) Numerical display of the current output level
- (6) Display of the current setpoint value
- (7) Display of the current actual value




## 8.6 Operation of the data monitor/recording function

The standard version of the JUMO AQUIS touch P is equipped with a data monitor. It is used to record and view the analog measuring value and signal states of digital functions. Two groups are available, each of which can record up to 4 analog values and 3 binary values and display them in the form of a line recorder diagram. There is a separate diagram for each group in the operation loop. The recording function represents an Add-On to the data monitor and is available as an extra code.

⇒ Chapter 4.2 "Order details", page 22


The features of the data monitor and recording function are listed in the following table:

Function Features	Data monitor	Recording
<b>Measured-data recording</b> Recording of the measuring values from up to 4 analog channels and display of the measuring values in the form of a line recorder diagram	X	X
<b>Digital data recording</b> Recording of the binary values from up to 3 digital channels and display of the digital data in the form of a binary channel diagram	X	X
<b>Displaying events</b> Event list entries are shown as icons in the line recorder diagram	X	X
<b>History function</b> For scrolling the line recorder diagram to the past to view measurement data and events from farther back in time		X
<b>Zoom function</b> The time range is compressed to view measured-data histories over longer periods in one area of the screen		X
<b>Measurement data retrieval</b> for archiving recorded measurement data and evaluating the data via JUMO PCC/PCA3000		X



### Stylus trace view

The "Next channel" button is used to scroll through the individual stylus trace views. For the particular channel selected, the appropriate scale with stylus trace appears in the stylus trace view. The position of the stylus corresponds to the current measured value of the channel.




- (1) Stylus  
The position on the scale corresponds to the current measuring value of the channel.
- (2) "Next Channel" button for scrolling through the stylus trace views (graphical representations of a scale with a stylus) for the individual channels 1 to 4
- (3) Scale  
The beginning and end of the scale correspond to the "display range" in the configuration of the source of the analog value (e. g. analog input or mathematical formula).

# 8 Operation

## Scrolling through the stylus trace views

The sequence of views that appear with repeated tapping of the "Next Channel" button can be seen in the graphic below.




### 8.6.2 History function

The history function is available only in the recording function. It permits the user to view all recorded data in the ring memory on the device's display. The history is opened by tapping the "History" button on the operator screen for the respective group. The scroll and zoom functions can be used to put the view in the desired form.

- **Scroll:** The diagram can be scrolled forward and backward with the aid of the "Scroll" buttons.
- **Zoom:** The time range in the display can be compressed with the aid of the "Zoom" button. This permits viewing of measurement curves over a longer period of time in a single area of the screen.

The "Exit" button is used to leave the history view; the display then returns to the operator screen for the corresponding group.



- (1) Title bar with indication of the cursor position (time and date), Zoom factor and memory cycle time
- (2) "Exit" button for leaving the history view
- (3) "Zoom" button for compressing the time range in the area of the screen
- (4) "Scroll" buttons for scrolling forward and backward in the history
- (5) Cursor

## 8 Operation

---

### 8.7 Online visualization

Using a web browser, all operation screens of the operation loop, the alarm/event list, the measurement data history of the recording function and the calibration logbooks can be opened and viewed online. This requires the "Standard online visualization" to be set as online visualization in the basic settings.

⇒ Chapter 10.2 "Basic settings", page 130

A PC with Microsoft® Windows® operating system and Microsoft® Silverlight® installed is required to use this function.

Actions involving the device functions (e.g. setpoint value entry or operating a controller manually) are not possible from a web browser and must take place directly on the device. Device settings can be made only on the device itself or via the JUMO PC setup program. In the online visualization, the "Device menu" button opens only the calibration logbook. In the recording function, the measured-data history can be opened.

Detailed information on the above-mentioned views:

⇒ Chapter "Operation screens in the operation loop", page 79

⇒ Chapter 8.3 "Alarm/Event list", page 98

⇒ Chapter 12.3 "Calibration logbook", page 195

The online visualization can be opened by up to 5 clients simultaneously.



#### **NOTE!**

The web server can also be configured and activated as an alternative to online the visualization. When a web server is active, the website of the web server is displayed in the web browser instead of the online visualization.

The website is opened in exactly the same manner as the online visualization, i.e. by entering the IP address or the URL of the device. Up to 5 clients have simultaneous access. The user needs the web server password to open the website.

Operation of the web server visualization depends on the specific layout of the website stored in the device.

⇒ Chapter 21.8.14 "Web server", page 331

The online visualization is open with a web browser.

Enter either the IP address or the URL of the JUMO AQUIS touch P in the address bar of your web browser.

⇒ Chapter 10.17 "Ethernet", page 177

When the website opens, it is possible to select between "Visualization" and "Quad View".

## 8 Operation

**The visualization** displays a view identical in appearance to the device. A request for a password appears next. The web server password specified in the web server configuration must be entered here.


⇒ Chapter 21.8.14 "Web server", page 331

As on the device, an operator screen can now be selected from the operation loop.

⇒ Chapter "Operation screens in the operation loop", page 79

Access to the device menu remains blocked. Only the calibration logbooks are displayed when the "Device menu" button is pressed.

⇒ Chapter 12.3 "Calibration logbook", page 195




## 8 Operation

---



**Quad View** enables the user to open 4 different and independent views of the device. The open Quad View displays 4 plus signs for this purpose. Clicking on any one opens a request to enter the IP address of the JUMO AQUIS touch P. After the IP address has been entered, the selected view opens and can be controlled exactly as in the "Visualization" view.

Clicking on the minus sign at the upper left above one of the four views resets the Quad View.






## Example of a Quad View:



313.01.01-022



313.01.01-022

**Kalibrierlogbuch**

Exit Detail

Datum	rel.ZK %	TK %/K	T1 °C	T2 °C
21.01.2013	50,00			

313.01.01-022

**Alarmliste - Ganzes Gerät**

Zurück Details

Datum	Uhrzeit	Beschreibung

313.01.01-022

# 8 Operation

---

Control variables (parameters) for the device's functions are set here. These include:

- Date and time
- Controller parameters (two parameter sets per controller)
- Controller setpoint values (two setpoint values per controller)
- manual values (for storing fixed numerical values, e.g. altered equipment data or conversion factors)

## 9.1 Date and time

The following table explains the parameters for setting the date and time. "Date and time" parameter list

Parameter	Selection/ Value range	Explanation
Current date/time	Date/time entry dialog	Setting the current date and time
Time zone GMT	-720 to 720 min	Difference between local time and GMT
Switch daylight saving time	inactive, automatic	activate/deactivate daylight saving time automatically
Start DST <ul style="list-style-type: none"> <li>• Switch time Month</li> <li>• Switch time Weekday</li> <li>• Day in month</li> <li>• Switch time</li> </ul>	January to December  Monday to Sunday  First to fourth, last  hh:mm:ss	Month for switch to daylight saving time  Weekday for switch to daylight saving time  Number of the selected weekday for switch to daylight saving time in the respective month  Time to switch to daylight saving time
End DST <ul style="list-style-type: none"> <li>• Switch time Month</li> <li>• Switch time Weekday</li> <li>• Day in month</li> <li>• Switch time</li> </ul>	January to December  Monday to Sunday  First to fourth, last  hh:mm:ss	Month to switch to standard time  Weekday to switch to standard time  Number of the selected weekday for switch to standard time in the month concerned  Time to switch to standard time



### NOTE!

The date and time are set in the online parameters in the JUMO PC setup program.

⇒ See chapter 21.10.1 "Date and time" Page 335

# 9 Parameterization

## 9.2 Parameter Sets (Controller parameter)

The parameters for the controller channels determine the control response of the individual control circuits. For stable control response, these parameters must be matched to the prevailing process conditions. Each controller channel has two parameter sets; the selection is made by means of a binary signal. "Parameter set 1" is active by default. The second set can be activated as an alternative via the binary signal. In this way, it is possible to match each controller channel to the changing process conditions in order to maintain a stable control response.

The best parameter settings can usually be found by the controllers' self-optimization function. This approach, however, works only with linear processes.

⇒ Operating the controllers Page 107

For nonlinear processes (control paths), it is advisable to set the parameters manually.

The following table provides an overview of the parameter sets for the controller channels. Depending on the configuration of the particular controller channel, only valid parameters are active for entry. Those not used appear in light gray, but cannot be edited. Duplicate parameters refer to the first and second controller output.

**Open:** Device Menu → Parameterization → Parameter Sets → Controller 1 to 4 → Parameter Set 1 and 2

Parameter (Formula sym.)	Setting options	Explanation
Proportional-range 1 ( $X_{p1}$ )	0 to 9999.9 (Unit dependent on the actual value input variable) factory setting: 0.0	Range of the actual value in which the controller output is proportional to the control deviation. The smaller the proportional band selected, the larger the change in controller output for the control deviation. If the proportional band is set to a value of 0, the controller functions automatically as a limit monitor without a PID controller structure.
Proportional-range 2 ( $X_{p2}$ )		
Rate time 1 ( $T_{v1}$ )	0 to 9999 s  factory setting: 80.0 s	Affects the derivative component (D-term) of the controller output signal. The purpose of the D-term is to damp the change of the actual value with time, and thereby suppress the hunting tendency. The effect of the D-term increases as the derivation time increases
Derivative time 2 ( $T_{v2}$ )		
Reset time 1 ( $T_{n1}$ )	0 to 9999 s  factory setting: 350.0 s	Affects the integral component (I-term) of the controller channel. The purpose of the I-term is to minimize persistent control deviations. The effect of the I-term decreases as the reset time increases.
Reset time 2 ( $T_{n2}$ )		

## 9 Parameterization

Parameter (Formula sym.)	Setting options	Explanation
Switching period 1 (C <sub>y1</sub> )	0 to 9999 s factory setting: 20.0 s	If an output of a controller channel is configured as a Pulse length output, the period between the switching pulses is fixed. The length of the switching period should be selected such that, on the one hand, the cyclic controller output signal (e.g. for heating, cooling, feeding etc.) does not cause any disturbing fluctuations of the actual value, while, at the same time, the switching outputs and the equipment being controlled are not stressed unduly.
Switching period 2 (C <sub>y2</sub> )		
Contact spacing (X <sub>sh</sub> )	-0 to 999.9 (Unit dependent on the actual value input variable) factory setting: 0.0	Minimum control deviation at which switching controller outputs become active Used to protect switching outputs and the connected equipment when controlled by modulating and continuous controllers with pulse outputs. With very small control deviations, switching of the controller output is suppressed.
Switching hysteresis 1 (X <sub>d1</sub> )	0 to 999.9 (Unit dependent on the actual value input variable)	Switching distance between the output states (on/off) In switching controllers (proportional band = 0) The Switch hyst. (switching hysteresis) should be selected such that the actual value resulting from the switching controller output signal does not vary too much, while, on the other hand, the switching outputs and the equipment being controlled are not stressed unduly.
Switching hysteresis 2 (X <sub>d2</sub> )	factory setting: 1.0	
Actuator time (TT)	5 to 3000 s factory setting: 60 s	Time required by an actuator to cover the entire output level range.
Working point (Y0)	-100 to 100 % factory setting: 0 %	Constant value used to correct the controller working point The set value corresponds to the output when the actual value and the setpoint value are identical (control deviation = 0). Used in controller structures without an I-term as a manual output level offset to eliminate persistent control deviations.
max. output (Y1)	0 to 100 % factory setting: 100 %	maximum output not active, limit monitor response (proportional band = 0)
Min. output level (Y2)	-100 to 100 % factory setting: -100 %	minimum output level not active, limit monitor response (proportional band = 0)

## 9 Parameterization

Parameter (Formula sym.)	Setting options	Explanation
min. relay switch-on time 1 ( $T_{k1}$ )	0 to 60 s factory setting: 0.0 s	Depending on the Min. relay switch-on time, a lower limit is set for the pulse length or an upper limit is set for the pulse frequency. This thereby limits the operating frequency of switching outputs.
Min. relay switch-on time 2 ( $T_{k2}$ )		
max. pulse frequency 1	0 to 240 $\text{min}^{-1}$ factory setting: 60 $\text{min}^{-1}$	<b>for continuous controllers with a pulse frequency output :</b> maximum pulse frequency
max. pulse frequency 2		
Switch-on delay 1	0 to 999.9 s factory setting: 0.0 s	Delay of the energizing edge with limit monitor response (proportional band = 0)
Switch-on delay 2		
Switch-off delay 1	0 to 999.9 s factory setting: 0.0 s	Delay of the switch-off edge with limit monitor response (proportional band = 0)
Switch-off delay 2		
Alarm tolerance	0 to 999.9 (Unit dependent on the actual value input variable) factory setting: 0.0	maximum value of the control deviation without triggering an alarm, if this value is exceeded, the controller monitoring function triggers a "Dosing alarm"
Alarm delay	0 to 9999 s factory setting: 0 s	Delay of the dosing alarm allows violation of the alarm tolerance for a limited time.

### 9.3 Setpoint values

The "Setpoint values" submenu allows two setpoint values for each controller channel to be entered. As with the parameter sets, it is also possible to switch between setpoint values by means of a binary signal. "Setpoint value 1" is active by default. The second setpoint value can be activated as an alternative via the binary signal. The setpoint value that is currently active can be changed from the corresponding "controller screen".

**Open:** Device Menu → Parameterization → Setpoint Values → Setpoint Value Controller 1 to 4

Setpoint changeover via a binary signal is set in the Setpoint value configuration.

⇒ Setpoint value configuration Page 171

⇒ Operating the controllers Page 107

### 9.4 Manual values

Up to 16 constant numerical values that are available for device functions can be stored here. The "Manual values" menu provides simple and clearly organized access to stored numerical values in order to change them as necessary.

**Open:** Device menu → Parameterization → Manual values

For "Manual values", settings such as decimal place, unit etc. must be made in the configuration.

⇒ See chapter 10.21 "Manual values (configuration)" Page 180

Examples of practical use of "Manual values":

- "Formula" are used to control a process. These contain process-relevant equipment information (e.g. tank capacities). If the equipment configuration is modified, these data can be changed in the "Manual values" menu and even edited from the user level.

⇒ See chapter 8.2.2 "User level" Page 88

- Another application example is the storage of constant process values (e. g. the duration of a chemical reaction), the value of which is also known without a measurement. If the process conditions change (e.g. through use of a catalyst), the stored process values can be modified accordingly.

# 9 Parameterization

---



## 10.1 Important information

**WARNING!**

After every configuration change, the device restarts functions affected by the changes. Analog and digital outputs can assume undesired states during start-up.

Therefore, configuration changes must never be made while equipment is operating!

**CAUTION!**

Besides incorrect installation, incorrectly set values on the device can impair performance of the connected process or cause damage. Therefore, always provide safety devices independent of the device and allow only qualified personnel to make settings.

**CAUTION!**

When changing configuration data that are relevant for the data monitoring and recording function, data recording is terminated and a new recording session begun.

**NOTE!**

Changes to the configuration settings described in this chapter can be made directly on the device or via the JUMO PC setup program.

**NOTE!**

Settings in the "Configuration" menu can be changed only if a user with corresponding user rights is logged in.

⇒ Chapter 8.1.1 "Passwords and user rights", page 73

**NOTE!**

Changes to the configuration go into effect only after you leave the configuration menu ("Exit" menu item or "Close window" button).

# 10 Configuration

## 10.2 Basic settings

Open: Device Menu > Configuration > Basic Settings

Configuration point	Selection/ setting option	Explanation
Device name	up to 20 text characters	Device ID, e.g. for identification of exported measurement data in the JUMO PCA 3000 evaluation software
National language	German English	Setting the operating language  Additional languages can be installed on the device using the setup program. ⇒ Chapter 21.8.4 "Country settings", page 295
Language select after power on	Yes No	Specifies whether a prompt for selecting the operating language should appear when the device is switched on
Supply frequency	50 Hz 60 Hz	Supply frequency of the electric power grid serving the mounting site  The supply frequency must be specified to suppress EMC interference caused by the mains voltage. Setting the correct supply frequency is thus also necessary when supplying the device with direct voltage.
Device temp.	Degrees Celsius Degrees Fahrenheit	Setting the default on the temperature unit for all temperature values in the device
Interface temperature	Degrees Celsius Degrees Fahrenheit	Setting the default on the temperature unit for all temperature values communicated via interfaces
Memory alarm limit	0 to 100 %	If the available memory display reaches this value, the memory alarm is triggered.
<b>The following settings can be edited only with the aid of the JUMO PC setup program</b>		
Setup quick info	up to 20 text characters	Brief information text about setup
Setup info	up to 501 text characters	Detailed information text about setup
Version online-visualization	No online-vis. Standard online-vis.	Selection of a saved online-visualization  Online-visualization permits remote control of the operation screens via a web browser ⇒ Chapter 8.7 "Online visualization", page 118  When the webserver is active on the device, the website of the webserver is displayed in the web browser instead of the online-visualization. ⇒ Chapter 21.8.14 "Web server", page 331

## 10.3 Display

### 10.3.1 Generally

Open: Device Menu > Configuration > Display > General

Configuration point	Selection/ setting option	Explanation
Lock touchscreen	Selection from binary selector	Digital signal that blocks operation of the touchscreen (e.g. key switch for locking operation)
Simulation of inputs	Yes No	When this function is activated, alternating on/off signals are simulated automatically at the digital inputs and continuous value changes at the analog inputs This function is used for troubleshooting. Deactivate it during normal operation.
Main screen	Selection of an operation screen from the operation loop	Selection of the operation screen as main screen  The main screen appears after the device has been switched on or the "Home" button has been pressed.
Display 1 and 2 general screen	Yes No	Individual operation screens can be shown or hidden in the operation loop here.
Show detailed screen 1 to 6		
Show diagram 1 and 2		
Show process screen		
Show controller overview		
Show controller 1 to 4		
Show alarms	Yes No	Activation or deactivation of alarm visualization in the title bar of the operation screens

# 10 Configuration

## 10.3.2 Screen

Open: Device Menu > Configuration > Display > Screen

Configuration item	Selection/ setting option	Explanation
Activation of screen-saver	inactive time to switch off control signal	Type of screensaver activation
Wait time for screen-saver	10 to 32767 s	<b>only with activation of the screensaver after wait time:</b> Time to wait before displaying the screensaver when there is no activity on the device
Signal screensaver	Selection from binary selector	<b>only with control signal screensaver activation:</b> Signal for activating the screensaver
Brightness	1 to 10	Display brightness (10 levels)

## 10.3.3 Colors

Open: Device Menu > Configuration > Display > Colors

Configuration point	Selection/ setting option	Explanation
Alarm 1 to 2	Selection from color palette	Color setting for signaling alarms 1 to 2 of the measuring inputs  Upon reaching the set alarm values, the measured value displays and bar graphs appear in the set colors.
Recording: Analog channel 1 to 4 Binary channel 1 to 3 Background, analogue Background, binary Color t-stamp diagr Color diag. traces	Selection from color palette	Color setting for the visualization elements of the individual recorder screens
Controller Background Setpoint value Actual value Output level Heating contact Cooling contact	Selection from color palette	Color setting for the visualization elements of the individual controller screens

## 10.4 Operating loop

### 10.4.1 General screens

**Open:** Device Menu > Configuration > Operation Loop > General Screen > General Screen 1 to 2

Configuration point	Selection/ setting option	Explanation
Gener. screen type	2-part screen 4-part screen	Selection of the type of overview screen; <b>2-part screen:</b> Display of 2 main values, 2 second values, 1 additional value and 3 binary values; <b>4-part screen:</b> Display of 4 main values, 4 second values, 1 additional value and 3 binary values
Screen title	up to 31 text characters	Title of the overview screen
Value title 1 to 2(4)	up to 15 text characters	Titles of the individual main value display fields
Signal main value 1 to 2(4)	Selection from analog selection	Signal source of the analog value for each main value displayed
Color main value 1 to 2(4)	Selection from color palette	Color of the measured value display for each main value
Signal sec. value 1 to 2(4)	Selection from analog selection	Signal source of the analog value for each second value displayed
Color sec. value 1 to 2(4)	Selection from color palette	Color of the measured value display for each second value
Title additional value	up to 15 text characters	Title of the additional value display field
Signal add value	Selection from analog selection	Signal source of the analog value displayed as additional value
Color addit. value	Selection from color palette	Color of the measured value display for the additional value
Title binary value	up to 15 text characters	Title of the binary value display field
Signal binary val. 1 to 3	Selection from binary selector	Signal sources of the binary values visualized in the binary value display field

# 10 Configuration

---

## 10.4.2 Detailed screens

**Open:** Device menu > Configuration > Operation Loop > Individual screen > Individual screen 1 to 6

<b>Configuration point</b>	<b>Selection/ setting option</b>	<b>Explanation</b>
Screen title	up to 31 text characters	Title of the individual screen
Input signal main value	Selection from analog selection	Signal source of the analog value displayed as the main value and visualized as a bar graph
Color main value	Selection from color palette	Color of the measured value display and the bar graph for the main value
Second value input signal	Selection from analog selection	Signal source of the analog value displayed as the second value
Color sec. value	Selection from color palette	Color of the measured value display for the second value
Title additional value	up to 15 text characters	Title of the additional value display field
Additional value	Selection from analog selection	Signal source of the analog value displayed as additional value
Color addit. value	Selection from color palette	Color of the measured value display for the additional value
Title binary value	up to 15 text characters	Title of the binary value display field
Signal binary val. 1 to 3	Selection from binary selector	Signal sources of the binary values visualized in the binary value display field

## 10.5 Analog inputs

### 10.5.1 Base unit temperature inputs

Base unit temperature inputs: IN 4/5

**Open:** Device Menu > Configuration > Analog Inputs > Temperature Inputs 1 to 2

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation for the input
Signal type	<b>IN 4/5:</b> Pt100 Pt1000 400 Ω 4000 Ω  <b>IN 5 :</b> 100 kΩ NTC 8k55 NTC 22k Resistance potentiometer <sup>a</sup>	Type of sensor connected  For <b>Pt100, Pt1000 and NTC</b> , corresponding linearizations are provided.  For <b>400 Ω, 4000 Ω and 100 kΩ</b> , a customer-specific linearization must be configured. For <b>resistance transmitters<sup>a</sup></b> a customer-specific linearization can be configured if necessary. ⇨ "Customer-specific linearization", in this table
Connection type	2-wire, 3-wire	<b>only for signal types Pt100, Pt1000, 400 Ω, 4000 Ω, 100 kΩ and NTC:</b> Connection variants for the connected resistance thermometer
Customer-specific linearization	Selection of a linearization table	<b>only for signal types 400 Ω , 4000 Ω , 100 kΩ or resistance transmitters<sup>a</sup>:</b> Linearization tables contain up to 40 value pairs in any measurement characteristic line. Each value pair assigns a display value (Y-column) to a measuring value (X-column). Up to 8 linearization tables can be stored. To create a linearization table, you need the JUMO PC setup program.
Start of display range	-99999 to +99999 <sup>b</sup>	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
Display range end	-99999 to +99999 <sup>b</sup>	
Decimal place	Auto, Fixed comma format	Decimal points in the display
Offset	-999 to +999 <sup>b</sup>	Correction value added to measuring value  This value can be used, for instance, to compensate for measurement errors resulting from the resistance of wires.
Filter time constant	0.0 to 25.0 s	Optimization of measuring value updating  The higher the value of the filter time const., the slower the measured value is updated.

## 10 Configuration

---

Configuration point	Selection/ setting option	Explanation
Ra	0 to 99999 $\Omega$	<b>only for IN 5:</b> Resistance value between the slider (S) and start point (A) in a resistance transmitter/potentiometer <sup>a</sup> when the slider is at the start point.
Rs	6 to 99999 $\Omega$	<b>only for IN 5:</b> Span of the variable resistance value between the slider (S) and start point (A)
Re	0 to 99999 $\Omega$	<b>only for IN 5:</b> Resistance value between the slider (S) and end point (E) in a resistance transmitter/potentiometer <sup>a</sup> when the slider is at the end point.
Alarms 1/2	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ Chapter 10.10.2 "Alarms for analog signals and digital sensors", page 159	

<sup>a</sup> Resistance transmitter

<sup>b</sup> The temperature unit specified in the basic settings appears in the entry field.  
⇒ Chapter 10.2 "Basic settings", page 130



## 10.5.2 Universal inputs of base unit and optional boards

Base unit universal input: IN 6  
 Optional board universal inputs: IN 11/12

**Open:** Device Menu > Configuration > Analog Inputs >  
 Universal Input 1 to 3 > Configuration

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation for the input
Operating mode	linear scaling, temp. measurement, pH-value measurement, conductivity measure- ment, free chlorine pH/T-compensated	<p>Type of measuring</p> <p><b>linear scaling:</b> Standard signals (for IN 11/12 and resistance transmitter<sup>a</sup>) with linear measurement characteristic line or customer-specific linearization</p> <p>For standard signals the scale start point, scale end point and unit must be specified.</p> <p><b>Temp. measurement:</b> Measurement made with a resistance thermometer</p> <p>The type of sensor is selected in the "Signal type" configuration item. The unit for the temperature is specified in the "Basic Settings" menu.          ⇒ Chapter 10.2 "Basic settings", page 130</p> <p><b>pH value, conductivity, and free chlorine:</b> The values measured by the individual analysis sensors are received in the form of a standard signal. Outside factors affecting the individual analysis process variables are compensated. It is thus necessary to make appropriate compensation settings in the configuration of the universal input.</p>
Signal type	<p><b>IN 6/11/12:</b>            0 to 20 mA            4 to 20 mA            20 to 0 mA            20 to 4 mA</p> <p><b>only IN 11/12:</b>            0 to 10 V            10 to 0 V            Pt100            Pt1000            400 Ω            4000 Ω            Resistance potentiometer</p>	<p>Type of sensor connected</p> <p>Correct scale settings are required for the <b>standard signals</b>.          ⇒ "Scale start/end" in this table.</p> <p>Appropriate linearizations are available for <b>Pt100, Pt1000 and resistance transmitters<sup>a</sup></b>.</p> <p>For <b>400 Ω and 4000 Ω</b>, a customer-specific linearization must be configured.          ⇒ "Customer-specific linearization" in this table</p>

## 10 Configuration

Configuration point	Selection/ setting option	Explanation
Connection type	2-wire, 3-wire	<b>only for signal types Pt100, Pt1000, 400 Ω and 4000 Ω:</b> Connection variants for the connected resistance thermometer
Customer-specific linearization	Selection of a linearization table	Linearization tables contain up to 40 value pairs in any measurement characteristic line. Each value pair assigns a display value (Y-column) to a measuring value (X-column). Up to 8 linearization tables can be stored. To create a linearization table, you need the JUMO PC setup program.
Unit	up to 5 text characters	Process variable unit not adjustable for pH measurement  The temperature unit is specified in the basic settings. ⇒ Chapter 10.2 "Basic settings", page 130
Scale start	-99999 to +99999 <sup>b</sup>	<b>only for standard signals:</b> Measured value from sensor (uncomp.) that corresponds to the lower limit of the standard signal range [0 V or 0(4) mA]; Refer to the technical data for the sensor.
Scale end	-99999 to +99999 <sup>b</sup>	<b>only for standard signals:</b> only for standard signals: Measured value from sensor (uncomp.) that corresponds to the upper limit of the standard signal range [10 V or 20 mA]  Refer to the technical data for the sensor.
Start of display range	-99999 to +99999 <sup>b</sup>	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
Display range end	-99999 to +99999 <sup>b</sup>	
Decimal place	Auto Fixed comma format	Decimal points in the display
Offset	-999 to +999 <sup>b</sup>	<b>only for temperature and conductivity measurement:</b> Correction value added to measured value
Filter time constant	0.0 to 25.0 s	Optimization of measured value updating  The higher the value of the filter time const., the slower the measured value is updated.
Ra	0 to 4000 Ω	<b>only for IN 11/12:</b> Resistance value between the slider (S) and start point (A) in a resistance potentiometer when the slider is at the start point

## 10 Configuration

Configuration point	Selection/ setting option	Explanation
Rs	6 to 4000 $\Omega$	<b>only for IN 11/12:</b> Span of the variable resistance value between the slider (S) and start point (A)
Re	0 to 4000 $\Omega$	<b>only for IN 11/12:</b> Resistance value between the slider (S) and end point (E) in a resistance potentiometer when the slider is at the end point.
Compensation temperature	Selection from analog selection	Analog input of the compensation thermometer for temperature-compensated measurement of pH value, free chlorine or conductivity
Compensation	TC linear, TC-curve, natural water, natural water with expanded temperature range, ASTM neutral, ASTM acid, ASTM alkaline, NaOH 0 to 12 %, NaOH 25 to 50 %, HNO <sub>3</sub> 0 to 25 %, HNO <sub>3</sub> 36 to 82 %, H <sub>2</sub> SO <sub>4</sub> 0 to 28 %, H <sub>2</sub> SO <sub>4</sub> 36 to 85 %, H <sub>2</sub> SO <sub>4</sub> 92 to 99 %, HCL 0 to 18 %, HCL 22 to 44 %	Type of temperature compensation for conductivity measurement
Reference temp.	15 to 30 °C	<b>required only for conductivity measurement with "TC linear" or "TC curve" temperature compensation:</b> Temperature at which the (temperature-compensated) conductivity value displayed was set
Compensation pH value	Selection from analog selection	Analog input of the pH-value sensor for pH-compensated measurement of free chlorine
Alarms 1/2	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ Chapter 10.10.2 "Alarms for analog signals and digital sensors", page 159	
Calibration timer	Calibration timers prompt the user to calibrate sensors on a regular basis. The settings for all analysis inputs and the universal inputs are explained together. ⇒ Chapter 10.11 "Calibration timer", page 163	

<sup>a</sup> Resistance transmitter

<sup>b</sup> The unit for the particular sensor value appears in the entry field.

# 10 Configuration

## 10.5.3 pH/Redox/NH<sub>3</sub> analysis inputs

**Open:** Device Menu > Configuration > Analog Inputs > Analysis Input 1 to 4 > Configuration

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation for the input
Electrode type	pH standard pH antimony pH ISFET redox ammonia	Type of electrode connected
Redox unit	mV percent	<b>mV:</b> unit for the redox potential  <b>percent:</b> concentration percentage that can be derived from the redox measurement This requires a two-point calibration. ⇒ Chapter 14.2.1 "Calibration methods for Redox sensors", page 207
Filter time constant	0.0 to 25.0 s	Optimization of measured value updating  The higher the value of the filter time const., the slower the measured value is updated.
Start of display range	-99999 to +99999 <sup>a</sup>	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
Display range end	-99999 to +99999 <sup>a</sup>	
Compensation temperature	Selection from analog selection	Analog input of the temperature sensor for compensation of the effect of temperature on the pH-value measurement
Glass electrode monitoring	off minimum impedance maximum impedance min./max. impedance	configurable monitoring of pH glass electrodes <b>without impedance converter</b>  <b>minimum impedance:</b> monitoring for soft short/sensor failure  <b>maximum impedance:</b> monitoring for aging/pollution/wire break
Reference electrode monitoring	On Off	Activation of reference electrode impedance monitoring  A high-impedance symmetrical connection is required.
max. reference impedance	0 to 100 kΩ	upper impedance limit for monitoring a reference electrode
Alarm/Event list	off event alarm	Assignment of sensor failure notification to alarm list or event list
Sensor alarm delay	0 to 999 s	The sensor alarm is suppressed for the set duration of the alarm delay.

## 10 Configuration

Configuration point	Selection/ setting option	Explanation
Text sensor alarm	up to 21 text characters	Text for the alarm/event list in case of sensor error
Alarms 1/2	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ Chapter 10.10.2 "Alarms for analog signals and digital sensors", page 159	
Calibration timer	Calibration timers prompt the user to calibrate sensors on a regular basis. The settings for all analysis inputs and the universal inputs are explained together. ⇒ Chapter 10.11 "Calibration timer", page 163	

<sup>a</sup> The entry field units depend on the configuration items "Electrode type" and "Redox unit".



### NOTE!

The following points must be observed for correct operation of glass electrode monitoring via impedance measurement (see preceding table):

- Impedance measurements are possible only with glass-based sensors.
- Sensors must be connected directly to an analysis input for pH/Redox/NH<sub>3</sub> on the device.
- Impedance converters must not be installed in the measuring circuit.
- The maximum admissible cable length between sensor and device is 10 m.
- Fluid resistances have a direct impact on the measurement result. It is therefore advisable to activate the impedance measurement in liquids at a minimum conductivity of approx. 100 µS/cm.

# 10 Configuration

## 10.5.4 CR/Ci analysis inputs (conductive/inductive conductivity)

**Open:** Device Menu > Configuration > Analog Inputs > Analysis Input 1 to 4 > Configuration

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation for the input
Compensation temperature	Selection from analog selection	Analog input of the compensation thermometer for temperature-compensated conductivity measurement
Reference temp.	15 to 30 °C	<b>required only for conductivity measurement with "TDS", "TC linear" or "TC curve" temperature compensation:</b> The temperature at which the conductivity value displayed was set
Filter time constant	0.0 to 25.0 s	Optimization of measured value updating  The higher the value of the filter time const., the slower the measured value is updated.
nominal cell constant	<b>for CR:</b> 0.01 to 10 cm <sup>-1</sup> <b>for Ci:</b> 4.00 to 8.00 cm <sup>-1</sup>	nominal cell constant of the conductivity sensor (can be read from the sensor nameplate)
Cell type	2 electrodes 4 electrodes	For conductivity sensors with 4 electrodes, pollution detection is made available.
Pollution detection	OFF ON	<b>possible only for conductive conductivity measurement in a 4-wire circuit:</b> When this function is activated, a sensor alarm is triggered in case of soiling.
Wire break detection	OFF ON	<b>possible only for conductive conductivity measurement:</b> When this function is activated, a sensor alarm is triggered in case of a sensor wire break.
Alarm/Event list	off event alarm	<b>possible only for conductive conductivity measurement:</b> Assignment of the sensor failure notification to alarm list or event list
Sensor alarm delay	0 to 999 s	<b>possible only for conductive conductivity measurement:</b> The sensor alarm is suppressed for the set duration of the alarm delay.
Text sensor alarm	up to 21 text characters	<b>possible only for conductive conductivity measurement:</b> Text for the alarm/event list in case of sensor error
Measuring range selection 1	Selection from binary selector	Measuring range switching permits selection of the measuring ranges 1 to 4 by controlling the binary signals. ⇒ Chapter "CR/Ci measuring range switching", page 143
Measuring range switching 2	Selection from binary selector	

# 10 Configuration

Configuration point	Selection/ setting option	Explanation
Measuring ranges 1 to 4	-	Four ranges each can be configured for conductive/inductive (CR/Ci) conductivity measurements. The settings for all CR-/Ci analysis inputs are explained together. ⇒ "CR/Ci measuring range configuration", page 144
Alarms 1/2 per measuring range 1 to 4		Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ Chapter 10.10.2 "Alarms for analog signals and digital sensors", page 159
Calibration timer		Calibration timers prompt the user to calibrate sensors on a regular basis. The settings for all analysis inputs and the universal inputs are explained together. ⇒ Chapter 10.11 "Calibration timer", page 163

## 10.5.5 CR/Ci measuring ranges

Four configurable measuring ranges are available for each CR/Ci analysis input for measuring electrolytic conductivity. The measuring range is switched by means of 2 selectable digital signals. These signals are specified in the configuration of the individual conductivity measurement inputs.

⇒ Chapter 10.5.4 "CR/Ci analysis inputs (conductive/inductive conductivity)", page 142

### CR/Ci measuring range switching

The following table shows which binary value combinations activate the individual measuring ranges:

Active measuring range	Binary signal Measuring range selection 1	Digital signal Measuring range switching 2
Measuring range 1	0	0
Measuring range 2	1	0
Measuring range 3	0	1
Measuring range 4	1	1

# 10 Configuration

## CR/Ci measuring range configuration

**Open:** Device Menu > Configuration > Analog Inputs > Analysis Input 1 to 4 > Measuring Range 1 to 4

Configuration point	Selection/ setting option	Explanation
TDS factor	0.01 to 2.00	<b>only for conductive conductivity with TDS compensation:</b> Conversion factor from measured conductivity to display unit (see configuration item "Unit" in this table)
Compensation	<b>for CR/Ci:</b> Off, TC linear, natural water, natural water with expanded temperature range	Type of temperature compensation for conductivity measurement
	<b>only for CR:</b> TDS, ASTM neutral, ASTM acid, ASTM alkaline	
	<b>only for Ci:</b> TC curve, NaOH 0 to 12 %, NaOH 25 to 50 %, HNO3 0 to 25 %, HNO3 36 to 82 %, H2SO4 0 to 28 %, H2SO4 36 to 85 %, H2SO4 92 to 99 %, HCL 0 to 18 %, HCL 22 to 44 %	
Unit for calculation	<b>for CR/Ci:</b> $\mu\text{S/cm}$ $\text{mS/cm}$	Unit in which the conductivity is displayed
	<b>only for CR:</b> $\text{k}\Omega/\text{cm}$ $\text{M}\Omega/\text{cm}$	
Unit	up to 5 text characters	<b>only for conductive conductivity measurement with TDS compensation:</b> Unit for the process variable to be displayed for TDS measurements or when using customer-specific linearization (e.g. ppm or mg/l)



## 10 Configuration

Configuration point	Selection/ setting option	Explanation
Customer-specific linearization	Selection of a linearization table	Linearization tables contain up to 40 value pairs in any measurement characteristic line. Each value pair assigns a display value (Y-column) to a measuring value (X-column). Up to 8 linearization tables can be stored. To create a linearization table, you need the JUMO PC setup program.
Start of display range	-99999 to +99999 <sup>a</sup>	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
Display range end	-99999 to +99999 <sup>a</sup>	
Decimal place	Auto Fixed comma format	Decimal points in the display
Offset	-99999 to +99999 <sup>a</sup>	Correction value added to measured value
Alarms 1/2 per measuring range 1 to 4	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ Chapter 10.10.2 "Alarms for analog signals and digital sensors", page 159	

<sup>a</sup> The unit set for the conductivity measurement input appears in the entry field.

# 10 Configuration

## 10.6 Analog outputs of base unit and optional boards

Open: Device Menu > Configuration > Analog Outputs >  
Analog Output 1 to 9

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation for the output
Signal output value	Selection from analog selection	Analog signal source of the output
Analog signal	0 to 10 V 0 to 20 mA 4 to 20 mA 10 to 0 V 20 to 0 mA 20 to 4 mA	Type of standard signal to be generated
Enable manu. mode	Yes No	The manual mode for the specific output is enabled/locked here. The manual mode permits fixed analog values to be set for the output for testing purposes. ⇒ Chapter 8.2.3 "Functional level", page 89
Safety value 1 to 4	0 to 10.7 V or 0 to 22 mA	Specification of an analog value that the output assumes at hold, at calibration or at error  If an analysis input for conductivity measurement is set as "Signal output value", the safety values 1 to 4 are assigned to conductivity measuring ranges 1 to 4. Pairs with the same number belong together. Otherwise, the safety value 1 applies.
Scale start 1 to 4	-99999 to +99999 <sup>a</sup>	Analog value of the analog signal source (see configuration item "Signal output value") that corresponds to the lower limit of the standard signal range generated [0 V or 0(4) mA]
Scale end 1 to 4	-99999 to +99999 <sup>a</sup>	Analog value of the analog signal source (see configuration item "Signal output value") that corresponds to the upper limit of the standard signal range generated (10 V or 20 mA)
Digital signal for hold	Selection from binary selector	Digital signal for activating the hold function  When the hold function is activated, the analog output assumes the state defined in the "Response at hold" setting.

# 10 Configuration

Configuration point	Selection/ setting option	Explanation
Response at hold	low high NAMUR low NAMUR high hold safety value	Specification of the analog output value when the hold function is activated, during calibration of one of the sensors for the particular output or at error (overrange/underrange)  <b>low:</b> lower limit of the standard signal value range [0 V or 0(4) mA]
Response at calibration	Moving Frozen Safe value	<b>high:</b> upper limit of the standard signal value range (10 V or 20 mA)
Response at error	low high NAMUR low NAMUR high hold safety value	<b>NAMUR low:</b> lower NAMUR limit of the standard signal [0 V or 0(3.4) mA]  <b>NAMUR high:</b> upper NAMUR limit of the standard signal (10.7 V or 22 mA)  <b>hold:</b> unchanging analog value  <b>Safety value:</b> see configuration item "Safety value" in this table

<sup>a</sup> The unit for the value set for the "Signal output value" appears in the entry field.

## 10.7 Digital inputs of base unit and optional boards

**Open:** Device Menu > Configuration > Digital Inputs > Digital Input 1 to 9

Configuration point	Selection/ setting option	Explanation
Description	up to 21 text characters	Designation for the input
Inversion	Yes No	Invert/do not invert state
Contact	<b>Base unit:</b> potential-free contact, external voltage source  <b>Optional boards:</b> potential-free contact	Type of digital signal connected
Alarm	Digital inputs alarms are used to monitor input-side switching signals. The alarm settings for all digital device functions are explained together. ⇒ Chapter 10.10.3 "Digital signal alarms", page 162	

# 10 Configuration

---

## 10.8 Digital outputs of base unit and optional boards

Open: Device Menu > Configuration > Digital Outputs >  
Digital Output 1 to 17

Configuration point	Selection/ setting option	Explanation
Description	up to 21 text characters	Designation for the output
Signal output value	Selection from binary selector	Digital signal source for the output
Inversion	Yes No	Invert/do not invert state
Enable manu. mode	Yes No	The manual mode for the specific output is enabled/locked here. Manual mode permits fixed binary values (switching states) to be set for the output for testing purposes. ⇒ Chapter 8.2.3 "Functional level", page 89

## 10.9 Digital sensors



**NOTE!**

For operation of digital sensors, you need the extra code "JUMO digiLine protocol activated" (see Chapter 4.2 "Order details", page 22)



**NOTE!**

Only one serial interface of the device can be configured for operation of digital sensors. If your device has 2 serial interfaces (base unit and possibly an optional board), select 1 interface for connection of digital sensors and configure it appropriately.



**NOTE!**

Correct functioning of digital sensors depends on correctly setting the interface to which the digital sensors are connected and are to be operated. Make sure the selected serial interface is configured correctly.

### 10.9.1 Generally

**Open General Settings Digital Sensors:**

Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > General

Configuration point	Selection/ setting option	Explanation
Parameters	No sensor pH ORP Temperature O-DO Turbidity	Setting of type information for the digiLine electronics or digital sensors
with temperature input	Yes No	Digital sensors and JUMO digi-Line electronics can only be linked if of these settings match the type information of the sensor to be linked. If this setting is changed during operation of a linked sensor, the sensor involved loses its link and must be put into operation anew.
VdN number	0 to 999	

# 10 Configuration

## 10.9.2 Configuration

### Open Configuration Digital Sensors:

Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Configuration

#### Gen. settings for all types of digital sensors

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Plain text designation for the digital sensor input  This designation is displayed in menus, e. g. analog or binary selection.
Alarms 1/2	Analog input alarms are used to monitor measured values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ Chapter 10.10.2 "Alarms for analog signals and digital sensors", page 159	

#### Only for JUMO sensors with digiLine electronics pH/ORP/T

Configuration point	Selection/ setting option	Explanation
TAG checking	inactive active	If desired, this function can be activated to assign digiLine electronics to measuring points. When it is activated, the "TAG number" of the sensor is compared with the entry in the "Sensor Tag" field of the digital sensor inputs on connection of a sensor to a master device. If these differ, the digiLine electronics are not linked.
Sensor TAG	up to 20 text characters	The "TAG number" of the digiLine electronics can be entered and edited in the digiLine electronics only with the JUMO DSM software.
Filter time constant <sup>a</sup>	0 to 25 s	Optimization of measured value updating in the digiLine electronics  The higher the value of the filter time const., the slower the measured value is updated.
Start of display range	-99999 to +99999 <sup>b</sup>	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
Display range end	-99999 to +99999 <sup>b</sup>	

# 10 Configuration

Configuration point	Selection/ setting option	Explanation
Compensation <sup>a</sup>	Fixed compensation temperature Sensor temperature Interface	<p><b>For pH sensors only:</b> Selection of the signal source for temperature compensation in the digiLine electronics</p> <p><b>Fixed compensation temperature:</b> Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature".</p> <p><b>Sensor temperature:</b> The integrated temperature probe of the pH sensor supplies the compensation temperature.</p> <p><b>Interface:</b> The AQUIS touch P transmits the compensation temperature to the digiLine electronics via the serial interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".</p>
fixed compensation temperature <sup>a</sup>	-25 to+150 °C	<p><b>only if "Compensation" is set to "Fixed compensation temperature":</b> constant temperature value, for temperature compensation of the pH value measurement in the digiLine electronics</p>
Compensation temperature	Selection from Analog selection	<p><b>only if "Compensation" is set to "Interface":</b> Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for temperature compensation of the pH value measurement in the digiLine electronics</p>
Temperature input filter time <sup>a</sup>	0 to 25 s	<p>Optimization of measured temperature value updating in the digiLine electronics</p> <p>The higher the value of the filter time const., the slower the measured value is updated.</p>
Temperature offset <sup>a</sup>	-10 to+10 °C	Correction value that is added to the measured temperature value

<sup>a</sup> This setting is saved in the configuration of the digiLine electronics.

<sup>b</sup> The unit for the item set in "Parameter" appears in the entry field.

# 10 Configuration

For JUMO ecoLine O-DO sensors only

Configuration point	Selection/ setting option	Explanation
Oxygen unit	% Sat mg/l ppm	Selection of the unit in which the oxygen concentration is displayed.
Salt content	0 to 10000 g/kg	Indication of the salt content (salinity) of the measurement solution for compensation of the effect of the salinity on the measured value of the oxygen concentration in the measurement solution
Air pressure	500 to 1500 hPa	Indication of the ambient air pressure for compensation of the effect of the air pressure on the measured value of the oxygen concentration in the measurement solution
Compensation <sup>a</sup>	Fixed compensation temperature Sensor temperature Interface	<p><b>Fixed compensation temperature:</b> Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature".</p> <p><b>Sensor temperature:</b> The integrated temperature probe of the O-DO sensor supplies the compensation temperature.</p> <p><b>Interface:</b> The AQUIS touch P transmits the compensation temperature to the sensor electronics via the interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".</p>
fixed compensation temperature <sup>a</sup>	-25 to +150 °C	<p><b>only if "Compensation" is set to "Fixed compensation temperature":</b></p> <p>constant temperature value, for temperature compensation of the pH value measurement in the digiLine electronics</p>
Compensation temperature	Selection from Analog selection	<p><b>only if "Compensation" is set to "Interface":</b></p> <p>Selection of the signal source from the Analog selection of the JUMO AQUIS touch P for temperature compensation of the pH value measurement in the digiLine electronics</p>



## 10 Configuration

Configuration point	Selection/ setting option	Explanation
Start of display range	-99999 to +99999 <sup>a</sup>	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
Display range end	-99999 to +99999 <sup>a</sup>	
Sampling rate	1 to 999 s	Indication of the length of the interval between 2 measurements  A slower "sampling rate" contributes to a longer operating life of the sensor. With faster "sampling rates, the measured value is updated frequently.
Filter time constant	0 to 25 s	Optimization of measured value updating in the digiLine electronics  The higher the value of the filter time const., the slower the measured value is updated.

<sup>a</sup> The unit set as the unit in "Oxygen unit" appears in the entry field.

## 10 Configuration

---

For JUMO NTU sensors only

Configuration point	Selection/ setting option	Explanation
Turbidity measuring range	automatic 0 to 50 NTU 0 to 200 NTU 0 to 1000 NTU 0 to 4000 NTU	Selection of the measuring range for the turbidity measurement  The user can choose a fixed measuring range or automatic measuring range selection.
Turbidity unit	NTU FNU	Selection of the unit in which the measured turbidity value is displayed.
Decimal place	Fixed comma format	Decimal points in the display
Filter time constant	0 to 25 s	Optimization of measured value updating in the digiLine electronics  The higher the value of the filter time const., the slower the measured value is updated.
Start of display range	-99999 to +99999 <sup>a</sup>	Upper/lower limit for labeling the scale when displaying measured values, e.g. in recorder diagrams and bar graphs
Display range end	-99999 to +99999 <sup>a</sup>	

<sup>a</sup> The unit set as the unit in "Turbidity unit" appears in the entry field.

## 10.9.3 Sensor alarms

Digital sensors cyclically transmit a number of alarm and status bits. In the settings for the sensor alarms, it is possible to set which of these signals should be indicated on the JUMO AQUIS touch P. The settings for the alarm conditions themselves are made in the configuration of the individual sensor electronics or stipulated by the specifications for the particular sensor. More detailed information on configuration can be found in the operating manual for the particular sensor type.

### Open Sensor Alarms Digital Sensors:

Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Sensor Alarms

Every alarm transmitted by the digital sensors has the following configuration parameters:

Configuration point	Selection/ setting option	Explanation
Alarm/Event list	off event alarm	Assignment of alarm notification to alarm list or event list
Sensor alarm delay	0 to 999 s	time delay from receipt of the alarm signal from the sensor and triggering of the alarm on the device
Alarm text	–	Text for the alarm/event list  Displayed only and cannot be changed.

The range of alarm types that can be transmitted by a digital sensor depends on the sensor type. The individual alarm lists for the various sensor types are provided in the following.

# 10 Configuration

---

## JUMO digiLine pH

<b>Alarm</b>	<b>Explanation</b>
pH sensor alarm	Alarm for pH value out of range
Temperature sensor alarm	Alarm for temperature out of range
pH min. warning	Lower pH limit value pre-alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
pH min. alarm	Lower pH limit value alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
pH max. warning	Upper pH limit value pre-alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
pH max. alarm	Upper pH limit value alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Min. temperature warning	Lower temperature limit value pre-alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Min. temperature alarm	Lower temperature limit value alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Max. temperature warning	Upper temperature limit value pre-alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Max. temperature alarm	Upper temperature limit value alarm from sensor (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Calibration timer alarm	Alarm for sensor calibration due (see "Calibration data" in the JUMO digiLine pH operating manual)
CIP/SIP/Autoclaving warning	Pre-alarm for maximum number of CIP/SIP/autoclaving cycles (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
CIP/SIP/Autoclaving alarm	Alarm for maximum number of CIP/SIP/autoclaving cycles (see "Sensor monitoring" in the JUMO digiLine pH operating manual )
Sensor stress warning	Sensor stress pre-alarm (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Sensor stress alarm	Sensor stress alarm (see "Sensor monitoring" in the JUMO digiLine pH operating manual)
Digital input state	Signal state of the digital input of the sensor electronics

## 10 Configuration

---

### JUMO digiLine ORP

<b>Alarm</b>	<b>Explanation</b>
ORP sensor alarm	Alarm for redox value out of range
Calibration timer alarm	Alarm for sensor calibration due (see "Calibration data" in the JUMO digiLine ORP operating manual)
Digital input state	Signal state of the digital input of the sensor electronics

### JUMO digiLine T

<b>Alarm</b>	<b>Explanation</b>
Temperature sensor alarm	Alarm for temperature value out of range
Digital input state	Signal state of the digital input of the sensor electronics

# 10 Configuration

## 10.9.4 CIP/SIP definition (JUMO digiLine pH only)

### Open CIP/SIP Definition Digital Sensors:

Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > CIP/SIP Definition

Configuration point	Selection/ setting option	Explanation
CIP min. temperature <sup>a</sup>	-20 to+150 °C	Temperature thresholds for identifying CIP/SIP cycles  If the CIP/SIP cycle takes place above one of these values during the set duration of a CIP/SIP cycle, the values identify a successfully completed CIP/SIP cycle and the CIP or SIP counter is incremented. The respective counter is reset only after the value has dropped below the CIP/SIP temperature.
SIP min. temperature <sup>a</sup>		
CIP cycle duration <sup>a</sup>	0 to 9999 s	Duration of a CIP/SIP cycle
SIP cycle duration <sup>a</sup>		
CIP/SIP alarming	inactive active	Setting for alarming on the JUMO AQUIS touch P, if the CIP, SIP or autoclaving counters in the digiLine electronics have reached the maximum number of permissible cycles.

<sup>a</sup> This setting is saved in the configuration of the digiLine electronics.

## 10.9.5 Calibration timer

### Open Calibration Timer Settings Digital Sensors:

Device Menu > Configuration > Digital Sensors > Digital Sensors 1 to 6 > Calibration Timer

Configuration point	Selection/ setting option	Explanation
Calibration interval <sup>a</sup>	0 to 9999 days	Time from one calibration to the next. When a calibration is due is indicated by the calibration alarm on the JUMO AQUIS touch P. Furthermore, the calibration alarm can be queried via the Modbus.

<sup>a</sup> This setting is saved in the configuration of the digiLine electronics.

## 10.10 Limit monitoring and alarms

### 10.10.1 Limit value monitoring

**Open Limit Monitoring:**

Device Menu > Configuration > Limit Monitoring >  
Limit Monitoring 1 to 8

Configuration point	Selection/ setting option	Explanation
Description	up to 21 text characters	Designation for the limit monitoring
Input signal	Selection from Analog selection	Signal source of the analog value that is monitored by limit monitoring
Alarms 1/2	Limit monitoring alarms are used to monitor output signals with respect to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ "Alarms for analog signals and digital sensors", page 159	

### 10.10.2 Alarms for analog signals and digital sensors

**Open Limit Monitoring Alarm Configuration:**

Device Menu > Configuration > Limit Monitoring > Limit Monitoring 1 to 8

**Open Temperature Inputs Alarm Configuration:**

Device Menu > Configuration > Analog Inputs >  
Temperature Inputs 1 to 2

**Open Universal Inputs Alarm Configuration:**

Device Menu > Configuration > Analog Inputs >  
Universal Input 1 to 3 > Configuration

**Open pH/Redox/NH<sub>3</sub> Analysis Inputs Alarm Configuration:**

Device Menu > Configuration > Analog Inputs >  
Analysis Input 1 to 4 > Configuration

**Open CR / Ci Analysis Inputs Alarm Configuration:**

Device Menu > Configuration > Analog Inputs >  
Analysis Input 1 to 4 > Configuration > Measuring Range 1 to 4

**Open Alarm Configuration Inputs for Digital Sensors:**

Device Menu > Configuration > Digital Sensors >  
Digital Sensors 1 to 6 > Configuration


Configuration point	Selection/ setting option	Explanation
Digital signal for hold	Selection from the binary selector	Digital signal for activating the hold function  When the hold function is activated, the alarm assumes the state defined in the "Response at hold" setting.

## 10 Configuration


Configuration point	Selection/ setting option	Explanation
Response at hold	inactive active hold	Specification of the alarm state when the hold function is activated, at calibration of the particular input or at error (out of range)  <b>inactive:</b> alarm suppressed  <b>active:</b> alarm forced  <b>hold:</b> alarm state is maintained regardless of alarm condition changes  <b>normal:</b> alarm in acc. with alarm condition
Response at calibration	inactive active hold normal	
Response at error	inactive active hold	
Alarm type	inactive minimum alarm maximum alarm alarm window invert alarm window	Four alarm types (comparator functions) can be selected to monitor measured values for violation of limit values. ⇒ Characteristic lines after the table
	<b>only for CR analysis inputs:</b> USP Pre-alarm USP cleaned water cleaned water pre-alarm	Limit value alarms to USP <645> or European Pharmacopoeia (Ph. Eur.) for cleaned water
Alarm/Event list	off event alarm	Assignment of alarm notification to alarm list or event list
Alarm text	up to 21 text characters	Text for the alarm/event list
Limit value	-99999 to +99999	Limit value for the particular alarm type
Hysteresis	0 to 99999	Spacing between switch-on and switch-off points for the alarm types ⇒ Characteristic lines after the table
Window range	0 to 99999	Range of the alarm window ⇒ Characteristic lines after the table
Pulse function	Yes No	Time limit for alarm with the wiper time as maximum alarm duration
Pulse time	0 to 999 s	Duration of alarm with pulse function activated
Alarm delay On	0 to 999 s	Time delay between occurrence of the alarm condition and triggering of the alarm
Alarm delay Off	0 to 999 s	Time delay between ending of the alarm condition and clearing of the alarm




## Minimum alarm (On-signal when value drops below lower limit)




## Maximum alarm (On-signal when value exceeds upper limit)



## Alarm window (On-signal within a configurable value range)



## Invert alarm window (On-signal outside a configurable value range)



# 10 Configuration

---

## 10.10.3 Digital signal alarms

**Open:** Device Menu > Configuration > Digital Inputs >  
Digital Input 1 to 9

Configuration point	Selection/ setting option	Explanation
Digital signal for hold	Selection from the binary selector	Digital signal for activating the hold function  When the hold function is activated, the alarm assumes the state defined in the "Response at hold" setting.
Response at hold	inactive active hold normal	Specification of the alarm state when the hold function is activated  <b>inactive:</b> alarm suppressed  <b>active:</b> alarm forced  <b>hold:</b> alarm state is maintained regardless of alarm condition changes  <b>normal:</b> alarm in acc. with alarm condition
Alarm type	active inactive	Arming or disarming an alarm
Alarm/Event list	off event alarm	Assignment of alarm notification to alarm list or event list
Alarm text	up to 21 text characters	Text for the alarm/event list
Alarm active at	high low	Digital input alarm condition
Alarm delay	0 to 999 s	Time delay between occurrence of the alarm condition and triggering of the alarm

## 10.11 Calibration timer

Every analysis input and universal input has its own calibration timer. Calibration timers signal when sensor calibration is due. Once a particular input has been calibrated successfully, its calibration timer is reset. The signal can be generated, for instance, by digital outputs, external indicator lights or the alarm/event list.

### 10.11.1 Configuration of the calibration timers

#### **Open Calibration Timer Configuration Universal Inputs:**

Device Menu > Configuration > Analog Inputs >  
Universal Input 1 to 3 > Calibration Timer

#### **Open Calibration Timer Configuration Analysis Inputs:**

Device Menu > Configuration > Analog Inputs >  
Analysis Input 1 to 4 > Calibration Timer

Configuration point	Selection/ setting option	Explanation
Function	inactive active	Activation/deactivation of the calibration timer for an analog input
Alarm/Event list	off event alarm	Assignment of calibration timer timeout notification to alarm list or event list
Alarm text	21 text characters	Text for the alarm/event list upon timeout of calibration timers
Calibration interval	0 to 99999 days	Time period after resetting the calibration timer through successful calibration until timeout of the calibration timer

# 10 Configuration

## 10.12 Controller

### 10.12.1 Configuration of the controllers

**Open:** Device Menu > Configuration > Controller > Controller 1 to 4 > Configuration

Configuration point	Selection/ setting option	Explanation
Controller type	Two-point controller Three-state controller, Coarse-/fine controller, Modulating controller, Proportional controller with integrated actuator driver, Continuous controller	Selection of controller type
Control direction	Inverse Direct	<b>Inverse:</b> Output increases with negative control deviation (actual value < setpoint value), output decreases with positive control deviation <b>direct:</b> Output level increase with positive control the deviation (actual value >setpoint value), Output value decrease with negative control deviation
Output type 1	Pulse length output	Signal type of controller output signal
Output type 2	Pulse frequency output Continuous output	
Output contact type 1 to 2	Normally-closed contact Normally open contact	Contact type (control direction) of the digital controller outputs (K1,K2)  Working contact corresponds to a normally-open contact Resting contact corresponds to a normally-closed contact
Manual mode	Enabled Disabled	Enabling of manual mode
Acceptance of manual output 1	Yes No	Acceptance of the preconfigured manual output (for the 1st controller output on coarse-/fine controllers) upon activation of the manual mode
Man. output level 1	-100 to +100 %	Preconfigured Man. output level (for the 1st controller output on coarse/fine controllers)  Accepted automatically on activation of the "manual mode" if acceptance of the manual output level is set to "Yes". Otherwise, the controller accepts the last output level from the automatic control mode.
Acceptance of manual output 2	Yes No	<b>only for coarse/fine controllers:</b> Acceptance of the preconfigured manual output for the 2nd controller output upon activation of the manual mode

## 10 Configuration


Configuration point	Selection/ setting option	Explanation
Man. output level 2	0 to 100 %	<b>only for coarse/fine controllers:</b> Preconfigured Man. output level for the 2nd controller output Accepted automatically upon activation of the manual mode if acceptance of the manual output level is set to "Yes"; otherwise the controller assumes the last output level from the automatic control mode.
Acceptance of hold output level 1	Yes No	Acceptance of the preconfigured hold output (for the 1st controller output on coarse/fine controllers) upon activation of the hold mode
Hold output level 1	-100 to +100 %	Preconfigured hold output level (for the 1st controller output on coarse-/fine controllers)  Accepted automatically on activation of the "manual mode" if acceptance of the manual output level is set to "Yes". Otherwise, the controller accepts the last output level from the automatic control mode.
Acceptance of hold output level 2	Yes No	<b>only for coarse/fine controllers:</b> Acceptance of the preconfigured hold output for the 2nd controller output upon activation of the hold mode
Hold output level 2	0 to 100 %	<b>only for coarse/fine controllers:</b> Preconfigured hold output level for the 2nd controller output  Accepted automatically upon activation of the hold mode if acceptance of the hold output level is set to "Yes"; otherwise, the controller assumes the last output level from the automatic control mode.
Self-optimization	Enabled Disabled	Enabling of self-optimization
Alarm monitoring	Inactive Active	Activation/deactivation of alarm monitoring  Alarm monitoring provides a continuous plausibility check of the control deviation. A dosing alarm is triggered when the control deviation is greater than the value of the alarm tolerance set in the controller parameters. If "Alarm ack." is activated (see next configuration item), the controller switches to hold mode on a holding alarm.

# 10 Configuration

Configuration point	Selection/ setting option	Explanation
Alarm ack.	Inactive Active	<p>Activation/deactivation of the acknowledgment function</p> <p>Dosing alarms of the respective controller must be acknowledged in the "Alarm list" when "Alarm acknowledgement" is activated. Dosing alarms are not cleared automatically when the control deviation drops to a value that is less than or equal to the alarm tolerance. The alarm tolerance is set in the controller parameters.            ⇒ Chapter 9.2 "Parameter Sets (Controller parameter)", page 124.</p>


## Pulse length output

With a pulse width output, the output level generated by the controller has the form of the pulse/pause ratio of a square-wave signal with a fixed frequency (pulse width modulation). Output of this type of signal from the device uses a digital output.



## Pulse frequency output

With a pulse frequency output, the output level generated by the controller has the form of the frequency of a square-wave signal with a fixed pulse/pause ratio. Output of this type of signal from the device uses a digital output.



## Continuous output

With a continuous output, the output level generated by the controller is transmitted directly to connected functions. Output of this type of signal from the device uses an analog output. The proportionality between the min/max span of the controller output level and the signal strength is specified by the scaling of the analog output.

For more detailed information on the subject of control technology, you can download the technical article "Control technology - Basic principles and tips for the practitioner" (FAS 525) as a PDF document for free from the JUMO website.

# 10 Configuration

## 10.12.2 Controller inputs

**Open:** Device Menu > Configuration > Controller > Controller 1 to 4 > Input


Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation of the controller input
Actual value	Selection from Analog selection	Selection of the analog signal source for the actual value
Output level feedback	Selection from Analog selection	<p><b>only for modulating controller and continuous controller with integrated position controller</b></p> <p>Selection of the analog signal source for the current output level (e.g. universal input with resistance transmitter or analog input with standard signal)</p> <p>On continuous controllers with an integrated position controller, output level feedback is necessary.</p>
Parameter selection	Selection from binary selector	<p>Selection of the digital signal source for switching from parameter set 1 to parameter set 2</p> <p>Two parameter sets are stored for each controller and can be switched via this digital signal. ⇒ Chapter 9.2 "Parameter Sets (Controller parameter)", page 124</p>
Digital signal for manual	Selection from binary selector	<p>Selection of the digital signal source to switch the controller to manual mode</p> <p>In addition to the button on the respective controller screen, it is also possible to activate manual mode with a digital signal (e.g. key switch for a digital input) binary signal.</p>
Digital signal for hold	Selection from binary selector	Selection of the digital signal source to switch the controller to hold mode
Manual text	up to 15 text characters	Text for the alarm/event list upon activation of manual mode
Alarm text	up to 15 text characters	Text for the alarm/event list upon occurrence of a dosing alarm



# 10 Configuration

## 10.12.3 Disturbance feedforward control

**Open:** Device Menu > Configuration > Controller > Controller 1 to 4 > Ena. variable disturbance

Configuration point	Selection/ setting option	Explanation
additive var. disturb.	Selection from Analog selection	<p>Analog input for the additive variable disturbance The additive output level component <math>Y_{add}</math> added. This is calculated as follows:</p> $Y_{add} = X \times [(Y_2 - Y_1) \div (X_2 - X_1)] + Y_1$  <p><math>Y_{add}</math>: Additive output level component  <math>X</math>: Variable disturbance value  <math>X_1</math>: Additive var. disturb. X start value  <math>X_2</math>: Additive var. disturb. X end value  <math>Y_1</math>: Additive var. disturb. Y start value  <math>Y_2</math>: Additive var. disturb. Y end value</p>
Additive var. disturb. X Start value	-99999 to +99999	Smallest value of the variable disturbance
Additive var. disturb. X End value	-99999 to +99999	Largest value of the variable disturbance
Additive var. disturb. Y Start value	-100 to +100 %	Additive output level component with largest variable disturbance value
Additive var. disturb. Y End value	-100 to +100 %	Additive output level component with largest variable disturbance value

# 10 Configuration

Configuration point	Selection/ setting option	Explanation
Multiplicative Disturbance	Selection from Analog selection	<p>Analog input for the multiplicative variable disturbance</p> <p>The ratio of the variable disturbance value at the working point of the variable disturbance is multiplied by the proportional gain of the controller. Changes in the variable disturbance affect the total gain of the controller.</p> $K_{Tot} = K_p \times (X \div A)$ <p> <math>K_{Tot}</math>: Total gain of the controller  <math>K_p</math>: Proportional gain  <math>X</math>: Variable disturbance value  <math>A</math>: Working point </p>
Working point	0 to 99999	<p>Stationary variable disturbance value (variable disturbance value under steady-state, normal operating conditions of the system)</p> <p>If the variable disturbance equals the value of the working point (<math>X = A</math>), the following holds:</p> $K_{Tot} = K_p \times 1$

## 10.12.4 Self-optimization

**Open:** Device Menu > Configuration > Controller > Controller 1 to 4 > Self-optimization

Configuration point	Selection/ setting option	Explanation
Standby output	-100 to +100 %	Output level at start of self-optimization
Output level for step	10 to 100 %	<p>Sudden output value increase issued by the controller as a test signal</p> <p>For automatic parameterization of the controller, the response (step response) of the process (section) is evaluated.</p>
Transfer CY	Yes No	Acceptance of the switching cycle ( $C_y$ ) for pulse width outputs from self-optimization into the controller parameters

## 10.13 Setpoint value configuration

**Open:** Device Menu > Configuration > Setpoint Value Configuration > Setpoint Value Configuration Controller 1 to 4

Configuration point	Selection/ setting option	Explanation
external Setpoint 1 to 2	Selection from Analog selection	<p>Selection of the analog value as setpoint value source</p> <p>If external setpoint values 1 to 2 are selected, they replace setpoint values 1 to 2 of the controller parameters in the respective controllers. ⇒ Chapter 9.2 "Parameter Sets (Controller parameter)", page 124</p> <p>With external setpoint values, the "Manual entry" button on the controller screen is hidden. ⇒ Chapter 8.5.1 "Automatic control mode", page 108</p>
Signal Setpoint changeover	Selection from binary selector	<p>Digital signal for switching from setpoint value 1 to Setpoint value 2</p> <p>Binary value = 0 activates (external) setpoint value 1 Binary value = 1 activates (external) setpoint value 2</p>
Start Setpoint value limit	-99999 to +99999	lower limit for setpoint values
End Setpoint value limit	-99999 to +99999	upper limit for setpoint values


# 10 Configuration

## 10.14 Timers

Open timer: Device Menu > Configuration > Timer > Timer 1 to 10 > Timer

Configuration point	Selection/ setting option	Explanation
Timer function	Inactive Timers Control timer	Operating principle of the timer  <b>Control timer:</b> Functions as weekly time switch Settings for a time program during the week ⇒ Chapter 10.14.1 "Control timer", page 174  <b>Timer:</b> Functions as timing element; the chronological progression of the output signal can be flexibly matched to the application via the settings. A detailed timing diagram follows this table.
Description	up to 15 text characters	Timer designation
Response after Power off	Program stop Continue running Restart	Response of the timer upon interruption of the Voltage supply
Timer time	hh:mm:ss	Elapsed time from timer start until the timer generates the set binary value
Lead time Timer start	0 to 9999 s	Delay time before the timer time starts
After-run time timer end	-1 to +9999 s	Time interval after timeout of the timer time  Special feature: If the "After-run time after timer end" is set to the value -1, the time interval is infinitely long.
Signal Timer quit signal	Selection from binary selector	<b>only for "after-run time, timer end" &gt; 0:</b> Binary signal for resetting the timer during the after-run time after timer end.
Timer start signal	Selection from binary selector	Digital signal to start the timer  Retriggering with "Timer start" is possible only if the "Lead time" and the "Timer time" have timed out.
Output signal	high low	Polarity inversion of the timer output signal  <b>high:</b> the output signal is not polarity inverted. <b>low:</b> the output signal is polarity inverted.
Timer stop signal	Selection from binary selector	Digital signal to reset the timer
Timer hold signal	Selection from binary selector	Interrupts timer operation
Timer restart signal	Selection from binary selector	Digital signal to reset and restart the timer during the "Lead time" or "Timer time"


# 10 Configuration

Configuration point	Selection/ setting option	Explanation
Signal Tolerance band x	Selection from Analog selection	<p>Selection of an analog signal the deviation of which from the "Tolerance band w signal" is to be monitored</p> <p>The timer starts and continues running only if the amount of deviation is not greater than the set window range. If the deviation is greater than the window range, running timers are interrupted and timer start for timers that have not yet started is prevented.</p> 
Signal Tolerance band w	Selection from Analog selection	Selection of the analog signal from which the "Tolerance band x signal" may not deviate by more than the "Window range" in order for the timer to run
Window range	0 to 99999 <sup>a</sup>	maximum amount of deviation $ x - w $
Enable wash event	Yes No	Activation/deactivation of event list entries with On-signal from "Timer start signal"
Event list text	up to 21 text characters	Text for the event list with On-signal from "Timer start signal"

<sup>a</sup> The unit for the window range is obtained from the "Tolerance band x signal" parameter in this table.

# 10 Configuration

## Timing diagram



### 10.14.1 Control timer

Timer settings for a timed program during the week

Prerequisite: The "Timer function" must be configured as a "Control timer".

⇒ Chapter 10.14 "Timers", page 172

Up to 4 Switch-on and Switch-off times can be specified separately for each weekday.

**Open Switching Time Settings:** Device Menu > Configuration > Timers > Timer 1 to 2 > Control Timer > Monday to Sunday

Configuration point	Selection/ setting option	Explanation
Switch-on times 1 to 4	hh:mm:ss	When the time passes the On-time, the control timer sets the binary value = 1 (switched on).
Switch-off times 1 to 4	hh:mm:ss	When the time passes the Switch-off time, the control timer sets the binary value = 0 (switched off).

## 10.15 Washtimer

Open: Device Menu > Configuration > Washtimer > Washtimer 1 to 2

Configuration point	Selection/ setting option	Explanation
Washtimer active	Yes No	Activation/deactivation of the washtimer  Washtimers are used to clean analysis sensors regularly and can actuate external equipment for cleaning sensors via digital outputs.
Description	up to 15 text characters	Timer designation
Time interval	0 to 999 h	Cycle for automatically repeated sensor cleaning
Washing time	0 to 999 min	Duration of sensor cleaning
Hold time after washing	0 to 999 s	After-run time of the washtimer hold signal upon timeout of the washing time  The washtimer hold signal provides an On-signal for the duration of the washing time plus the hold time. The hold signal is intended primarily to activate the hold mode for controllers and analog outputs. These functions are held in a safe mode until the washed analysis sensor provides stable measured values once again.
Signal for interval restart	Yes No	Activation/deactivation of event list entries during sensor cleaning
Event list text	up to 21 text characters	Text for the event list during sensor cleaning

# 10 Configuration

## 10.16 Counters

Open: Device Menu > Configuration > Counter > Counter 1 to 4

Configuration point	Selection/ setting option	Explanation
Function	Inactive Service count. Operating hours counter	Counter operation mode  <b>Service count.:</b> The positive edges (switch-on operations) of a digital signal are counted (E.g. for checking the wear status of relays)  <b>Operation hours counter:</b> The On-time of a digital signal is measured and the number of completed operating hours displayed.
Description	up to 15 text characters	Counter designation
Input signal	Selection from the binary selector	Digital signal, the switch-on operations or operating hours of which are to be counted
Alarm type	If a counter has reached its limit value, appropriate notifications can be configured for the alarm/event list.  The alarm settings for all digital device functions are explained together. ⇒ Chapter 10.10.3 "Digital signal alarms", page 162	
Alarm/event list		
Alarm text		
Service count. limit value	0 to 99999	Alarm threshold for number of positive edges (activations)
Operating hours counter limit value	0 to 99999 h	Alarm threshold for the number of operating hours



## 10.17 Ethernet

The Ethernet settings must be requested from the administrator of the network in which the device is installed.

**Open:** Device Menu > Configuration > Ethernet

Configuration point	Selection/ setting option	Explanation
Assign IP address	Manual Automatic	<p><b>manual:</b> If no DHCP server is installed or a dedicated IP configuration is desired and the IP address configuration is known (e.g. from the network administrator), the data can be entered manually.</p> <p><b>automatic:</b> A DHCP server is installed in the network. During power-up and booting, the JUMO AQUIS touch P receives the IP configuration from the DHCP server; the IP configuration takes place automatically.</p>
Manual IP address	Valid IP address <sup>a</sup>	IP configuration of the Ethernet optional board  Manual entry of known configuration data or automatic configuration by the DHCP server (see configuration item "IP address assignment")
Subnet mask	Valid subnet mask <sup>a</sup>	
Standard gateway	Valid IP address <sup>a</sup>	
DNS server	Valid IP address <sup>a</sup>	
Transfer rate	Automatic 10 Mbit/s half duplex 10 Mbit/s full duplex 100 Mbit/s half duplex 100 Mbit/s full duplex	<p>Transmission speed (bit rate) and duplex mode of the Ethernet optional board</p> <p>This setting must match the setting of the switch or router port to which the JUMO AQUIS touch P is connected.</p>

<sup>a</sup> To enter an IP configuration manually for the JUMO AQUIS touch P, a valid available IP address in the network must be known. Please contact your network administrator in this regard.



### NOTE!

The Ethernet settings are entered in the online parameters in the JUMO PC setup program.

The IP configuration of the device can also be changed from the PC if the PC and device are connected via Ethernet. In this case, changing the IP address or subnet mask can interrupt the PC-device connection.

⇒ See chapter 21.10.3 "Ethernet", page 336

# 10 Configuration

## 10.18 Serial interfaces

The serial interface settings of all participating devices on a bus must match.

**Open:** Device Menu > Configuration > Serial Interfaces > Serial Interfaces 1 to 2

Configuration point	Selection/ setting option	Explanation
Protocol	Modbus slave Modbus digital sensors	<p>Communication protocol of the bus system</p> <p><b>Modbus Slave:</b> For operation of the device as a slave in a Modbus system</p> <p><b>Modbus digital sensors:</b> For operation of digiLine sensors on the serial interface (see order details for extra code "JUMO digiLine protocol activated")</p> <p>In the JUMO AQUIS touch P, either the interface on the base unit or the optional serial interface (if present) can be configured for digital sensors (digiLine operation). Simultaneous use of both interfaces for digiLine operation is not possible.</p>
Baud rate	9600 19200 38400	<p>Transmission speed (symbol rate) of the serial interface<sup>a</sup></p> <p>When connecting digital sensors from the product groups 2026xx, the baud rate must be set to 9600 baud prior to startup. Otherwise, the sensors will not begin operation.</p>
Data format	8 - 1 - no parity 8 - 1 - odd parity 8 - 1 - even parity	<p>Format of the data word<sup>a</sup></p> <p>Format: Useful bit – stop bit – parity bit</p>
Minimum response time	0 to 500 ms	<p>Minimum time from receiving a query to sending a response</p> <p>This parameter is used to adjust the response speed of the device to slower bus users.</p>
Device address	1 to 254	<p><b>For "Modbus Slave" protocol only:</b> Unambiguous specification of a bus participant</p>

<sup>a</sup> For all users to communicate with one another, this setting be the same on all users.

## 10.19 Formula

Mathematical formula are created with the JUMO PC setup program and loaded to the device. Following this, the configuration of a mathematical formula can also be edited directly on the device.

**Open:** Device Menu > Configuration > Mathematical Formula > Formula 1 to 8

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Formula designation
Temperature	None Relative Absolute	For automatic conversion of temperature units, it is necessary to know whether the calculated result is an <b>absolute temperature</b> (temperature value on the Celsius scale) or a <b>relative temperature</b> (temperature difference in °C). If the result of the calculation not a temperature, " <b>none</b> " must be set here.
Unit	up to 5 text characters	<b>Entry of the unit for temperatures inactive:</b> Unit for the output value of the mathematical formula (calculation result)
Start Display range	-99999 to +99999 <sup>a</sup>	Upper/lower limit for labeling the scale For representation of measured values as recorder diagrams and bar graphs
End Display range	-99999 to +99999 <sup>a</sup>	
Response at error	No output Replacement value	Control of value output for error (E.g. division by zero). The value in the configuration item "Value for error" serves as substitute value.
Value for error	-99999 to +99999 <sup>a</sup>	Safety value for the output of a mathematical formula for error

<sup>a</sup> The unit set for the particular mathematical formula appears in the entry field.

# 10 Configuration

## 10.20 Logic formula

Logic formula are created with the JUMO PC setup program and loaded to the device. Following this, the configuration of a logic formula can also be edited directly on the device.

**Open:** Device Menu > Configuration > Logic Formula > Formula 1 to 30

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Logic formula designation
Alarm type	Corresponding notifications for the alarm/event list can be configured for logic formulas  The alarm settings for all digital device functions are explained together. ⇒ Chapter 10.10.3 "Digital signal alarms", page 162	
Alarm/Event list		
Alarm text		
Alarm delay		
Digital signal for hold		
Response at hold		

## 10.21 Manual values (configuration)

**Open:** Device menu > Configuration > Manual Values (config.) > Manual Value (config.) 1 to 16

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation of the manual value
Temperature	None Relative Absolute	For automatic conversion of temperature units, it is necessary to know whether the manual value is an <b>absolute temperature</b> (temperature value on the Celsius scale) or a <b>relative temperature</b> (temperature difference in °C). If the manual value not a temperature, <b>"none"</b> must be set here.
Unit	up to 5 text characters	<b>Entry of the unit for temperatures inactive:</b> Unit for the manual value
Decimal place	Auto Fixed comma format	Decimal points in the display
Start Display range	-99999 to +99999 <sup>a</sup>	Upper/lower limit for labeling the scale when displaying measuring values, e.g. in recorder diagrams and bar graphs
End Display range	-99999 to +99999 <sup>a</sup>	

<sup>a</sup> The unit set for the particular manual value appears in the entry field.

## 10.22 External analog inputs

Open: Device Menu > Configuration > External Analog Inputs > External Analog Inputs 1 to 8

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation of the external analog input
Temperature	None Relative Absolute	For automatic conversion of temperature units, it is necessary to know whether the analog value received via the external analog input is an <b>absolute temperature</b> (temperature value on the Celsius or Fahrenheit scale) or a <b>relative temperature</b> (temperature difference). If this analog value is not a temperature, <b>"none"</b> must be entered here.
Unit	up to 5 text characters	Unit for the analog value received via the external analog input
Decimal place	Auto Fixed comma format	Decimal points in the display
Start Display range	-99999 to +99999 <sup>a</sup>	Upper/lower limit for labeling the scale when displaying measuring values, e.g. in recorder diagrams and bar graphs
End Display range	-99999 to +99999 <sup>a</sup>	
Hold value	No Yes	Nonvolatile storage of the last analog value received when the device restarts
Alarms 1/2	Alarms for external analog inputs are used to monitor analog values received via the individual external analog inputs in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ Chapter 10.10.2 "Alarms for analog signals and digital sensors", page 159	

<sup>a</sup> The unit set for the particular manual value appears in the entry field.

# 10 Configuration

## 10.23 External digital inputs

Open: Device Menu > Configuration > External Digital Inputs > External Digital Inputs 1 to 8

Configuration point	Selection/ setting option	Explanation
Description	up to 15 text characters	Designation of the external digital input
Hold value	No Yes	Nonvolatile storage of the last analog value received when the device restarts
Alarm	Alarms for external digital inputs are used to monitor input-side digital signals. The alarm settings for all digital device functions are explained together. ⇒ Chapter 10.10.3 "Digital signal alarms", page 162	

## 10.24 Flow Rate

Open: Device Menu > Configuration > Flow Rate > Flow Rate 1 to 2

Configuration point	Selection/ setting option	Explanation
Input type	Inactive Digital input 2 Digital input 3 Analog input	Selection of the signal source for the flow rate measurement  <b>Digital input 1/2:</b> Pulse frequency signals via Digital inputs <b>Analog input:</b> An analog signal is specified in the configuration item "Analog signal".
Description	up to 15 text characters	Designation of the flow rate function
Analog signal	Selection from Analog selection	<b>only for "Analog input" as "Input type":</b> Selection of the analog signal source as the flow rate signal
Measuring principle	Period measurement 3 to 300 Hz  Pulse counting 300 Hz to 10 kHz	<b>only for "Digital input 2/3" as "Input type":</b> Measurement method for determining the flow rate  Pulse frequency signals are provided by paddle wheel sensors, for instance.
Time base	0 to 9999 s	<b>only for "Pulse counting" as "Measuring principle":</b> Duration of a counting segment  The pulses counted within a counting segment divided by the time base yields the pulse frequency value. With a setting of 0 s, the time base is 250 ms.

## 10 Configuration

Configuration point	Selection/ setting option	Explanation
K-factor	0 to. 99999 l <sup>-1</sup>	<p>Ratio of the pulse count to flow rate (pulses per liter)</p> <p>The K-factor can be obtained from the documentation for the fitting in which the flow rate sensor (e.g. paddle wheel sensor) is installed.</p> <p>If the flow rate signal is transmitted as a standard signal or via an interface (external analog inputs), be aware that the K-factor affects analog values as well. For reliable handling of the flow rate as an analog signal, it is recommended that the flow value be generated as a standard signal and the K-factor set to a value of 1.</p>
Unit	l / s l / min l / h m <sup>3</sup> / s m <sup>3</sup> / min m <sup>3</sup> / h gal / s gal / min gal / h customer-specific	<p>Unit for the flow rate value</p> <p><b>Customer-specific unit:</b>            In the individual measured display, the flow value in liters per second is multiplied by the factor from the "Conversion factor" setting and the unit displayed on the basis of the " Unit description" setting.</p>
Conversion factor (flow)	-99999 to +99999	only for "customer-specific" as "Unit": Conversion factor from the unit "l / s" for the flow to the customer-specific unit
Unit description (flow)	up to 5 text characters	<b>only for "customer-specific" as "Unit":</b> Entry of an arbitrary customer-specific unit for the flow
Decimal place (flow)	Auto, Fixed comma format	Decimal points in the display
Start Display range (flow)	-99999 to +99999 <sup>a</sup>	Upper/lower limit for labeling the scale when displaying measuring values, e.g. in recorder diagrams and bar graphs
End Display range (flow)	-99999 to +99999 <sup>a</sup>	

# 10 Configuration

Configuration point	Selection/ setting option	Explanation
Total quantity	Off hourly daily weekly monthly annually unlimited	<b>only available with flow measurement activated:</b> Activation of the flow rate quantity counter  The setting establishes the automatic reset cycle. In addition, the flow rate quantity counters can be reset manually at the functional level or via a digital signal (reset input).  The last counter state is saved during resetting and is available in the analog selection as " Total quantity - Periods 1/2".
Reset input	Selection from binary selector	<b>only for "unlimited" as "Total quantity":</b> Digital signal for resetting the current counter state
Conversion factor (flow rate quantity)	-99999 to +99999	<b>only for "customer-specific" as "Unit":</b> Conversion factor from the unit "l" for the flow rate quantity to the customer-specific unit
Unit designation (flow rate quantity)	up to 5 text characters	<b>only for "customer-specific" as "Unit":</b> Entry of an arbitrary customer-specific unit for the flow rate quantity
Decimal place (flow rate quantity)	Auto, Fixed comma format	Decimal points in the display
Start Display range (flow rate quantity)	-99999 to +99999 <sup>b</sup>	Upper/lower limit for labeling the scale when displaying measuring values, e.g. in recorder diagrams and bar graphs
End Display range (flow rate quantity)	-99999 to +99999 <sup>b</sup>	
Alarms 1/2	Flow rate function alarms are used to monitor flow values in relation to adjustable limit values. The alarm settings for all analog device functions are explained together. ⇒ Chapter 10.10.2 "Alarms for analog signals and digital sensors", page 159	

<sup>a</sup> The unit set for the particular flow rate function appears in the entry field.

<sup>b</sup> The unit set as the flow rate quantity for the particular flow function appears in the entry field.



# 11 Retrofitting optional boards


## 11.1 Inserting optional boards






### DANGER!

Insertion and removal of optional boards must be performed only by qualified personnel. To ensure electrical safety, country-specific regulations must be observed.


The following step-by-step table explains in detail the procedure for retrofitting optional boards:

Step	Action
1	Disconnect all phases of the voltage supply to the device (power grid, outside power supply sources for relays/solid-state relays etc.).
2	<p>Identify the optional board from the part number on the sticker attached to the packaging as well as from the connection socket and the accessories table.</p> <p>⇒ Chapter "Accessories", Page 25</p>  <p>Using the block diagram, select a suitable slot for the optional board.</p> <p>⇒ Chapter 3.2 "Block diagram", Page 19</p>

# 11 Retrofitting optional boards

Step	Action
3	<p data-bbox="576 259 1431 360">Disconnect all screw terminals and interface cables connected at the rear of the device. To prevent connections being interchanged, note down the assignment of the connectors to the sockets.</p> 
4	<p data-bbox="576 792 1431 860">Undo (do not remove) the two countersunk screws on the bottom of the case and remove the pan head screw on the side of the case.</p> 
5	<p data-bbox="576 1274 1246 1308">Now open the rear panel of the case and remove it.</p> 

# 11 Retrofitting optional boards

Step	Action
6	<p>Insert the optional board in the selected slot. Ensure that the board is seated correctly.</p> 
7	<p>Fill all empty slots with plastic board frames.</p>
8	<p>Re-insert the rear panel of the case and fasten with 3 screws. Make sure that all the toothed lock washers for securing the screws are re-inserted (see Step 4). The screws represent the protection conductor connection to the rear panel of the case.</p>
9	<p>Reinsert all the plug-in screw terminals and interface cables that were removed in Step 3 into the correct sockets.</p> <p>For "Ci analysis input" optional boards (inductive conductivity), continue at Step 10; otherwise, at Step 12</p>
10	<p>Connect the inductive conductivity sensor using the M12 socket adapter from the scope of delivery of the Ci optional board to the Ci optional board of the device.</p>
11	<p>Connect the 2-wire temperature sensor cable of the M12 socket adapter to an appropriate analog input (e. g. temperature measuring input). Observe the specifications for the temperature sensor integrated into the conductivity sensor.</p>
12	<p>Now, reconnect the power supply and check whether the new hardware has been recognized.</p> <p>⇒ Chapter 7.3.1 "Checking the optional boards", Page 71</p>
13	<p>Only for Ci optional boards (inductive conductivity): Perform a Ci base calibration.</p> <p>⇒ Chapter "Performing the Ci base calibration", Page 189</p>
14	<p>Only for optional boards for analysis inputs: Calibrate the analysis inputs.</p> <p>⇒ Chapter 12 "Calibration in general", Page 193</p>

# 11 Retrofitting optional boards

---

## 11.2 Ci base calibration

Analysis inputs for inductive conductivity sensors must undergo a Ci base calibration in the course of commissioning. A basic Ci calibration must be performed when:

- A new sensor or a new Ci optional board is being installed for the first time
- The sensor or a Ci optional board was replaced
- A Ci optional board was repositioned to a different optional board slot
- Data loss occurred as the result of failure of the backup battery while the power was switched off
- Device software was updated

After the basic calibration has been performed, the measuring input can be calibrated. Following successful calibration, the measuring input is ready for use.



### **NOTE!**

For the Ci base calibration, you need the JUMO Type 202711/21 calibration adapter for inductive conductivity sensors (TN 00543395).




### **CAUTION!**




A buffer battery is built into the device. Its purpose is to maintain data when the device is switched off or if the voltage supply is interrupted. If the battery approaches the end of its operating life (approximately 7 years) then a battery prealarm will indicate that status. When the battery is empty a battery alarm will indicate that status. The battery must be exchanged before it is empty. The battery must be exchanged by the JUMO Service department! In this case, send in the device!

# 11 Retrofitting optional boards



## Performing the Ci base calibration

Step	Action
1	<p>Ensure that you have user rights for calibration settings. The default settings authorize the "Master" and "Service" users for this.</p> <p>⇒ Chapter 8.1.1 "Passwords and user rights", Page 73</p>
2	<p>Ensure that the electronics of the JUMO AQUIS touch P have reached operating temperature. You can view the board temperature at:</p> <p>Device Menu → Service → Service Data → "Internal Data" tab</p> <p>Ensure that the ambient temperature specified for the device corresponds to the conditions for the normal operating mode. Wait until the board temperature has reached an approximately constant value.</p>
3	<p>Place the sensor such that the sensor body is suspended freely in air. Observe the following rules during the entire calibration:</p> <ul style="list-style-type: none"><li>• Keep all objects away from the sensor body</li><li>• Do not touch the sensor body</li><li>• Do not allow the sensor body to lie flat on a surface</li></ul>  <p>Sensor body of a Ci sensor</p>



# 11 Retrofitting optional boards

Step	Action
4	<p>Place the wire of the calibration sensor with 2 windings through the opening in the Ci sensor without connecting the ends of the wires.</p> 
5	<p>Start the Ci base calibration</p> <p>Device Menu → Service → Ci Base Calibration IN 7 to 8</p>
6	<p>Enter the cell constant for the sensor and confirm by pressing "OK".</p> <p>Tap button to enter</p> 
7	<p>The device now performs a measuring with the open cable loop of the calibration adapter open. Wait until the measured value displayed stabilizes and then confirm by pressing "OK".</p> 

# 11 Retrofitting optional boards

Step	Action
8	<p>Connect the ends of the wires forming the conductor loop of the calibration adapter.</p> 
9	<p>Set the calibration adapter to the resistance value shown in the instruction text in the display (in the example: 20kΩ). Once the measurement displayed has stabilized, confirm by pressing "OK".</p> <p>Follow the instructions →</p> 
10	<p>Now follow the instructions on the display. You will be requested to set certain resistance values on the calibration adapter one at a time and then to confirm each measuring by pressing "OK".</p> <p>All resistance value set on the calibration adapter are measured for the end of one measuring range and the beginning of the following measuring range. Each resistance value will thus be confirmed 2 times. Only the last measuring will be confirmed 1 time.</p>

# 11 Retrofitting optional boards

Step	Action																								
11	<p data-bbox="576 259 1441 327">Once all measurements have been confirmed, a summary of the calibration data acquired appears. Confirm by pressing "OK".</p> <p data-bbox="576 360 1441 427">If the Ci base calibration fails, the procedure is canceled without acceptance of the calibration data.</p> <div data-bbox="576 640 839 741"> <p>Protocol after successful Ci base calibration</p> </div>  <table border="1" data-bbox="903 584 1417 797"> <thead> <tr> <th>Zero point</th> <th>Slope</th> </tr> </thead> <tbody> <tr> <td>-0,02mS/cm</td> <td>+100,30%</td> </tr> <tr> <td>-0,01 mS/cm</td> <td>+100,04%</td> </tr> <tr> <td>-0,01 mS/cm</td> <td>+100,05%</td> </tr> <tr> <td>-10,10mS/cm</td> <td>+100,88%</td> </tr> <tr> <td>+2,85mS/cm</td> <td>+99,56%</td> </tr> </tbody> </table> <p data-bbox="911 808 1142 831">Calibration completed</p> <div data-bbox="576 1043 847 1122"> <p>Protocol after failed Ci base calibration</p> </div>  <table border="1" data-bbox="903 987 1417 1200"> <thead> <tr> <th>Zero point</th> <th>Slope</th> </tr> </thead> <tbody> <tr> <td>-0,02mS/cm</td> <td>+100,48%</td> </tr> <tr> <td>-0,50mS/cm</td> <td>+148,32%</td> </tr> <tr> <td>+0,02mS/cm</td> <td>+100,10%</td> </tr> <tr> <td>-10,66mS/cm</td> <td>+101,31%</td> </tr> <tr> <td>+3,33mS/cm</td> <td>+99,56%</td> </tr> </tbody> </table> <p data-bbox="911 1211 1158 1234">Limit values exceeded!</p>	Zero point	Slope	-0,02mS/cm	+100,30%	-0,01 mS/cm	+100,04%	-0,01 mS/cm	+100,05%	-10,10mS/cm	+100,88%	+2,85mS/cm	+99,56%	Zero point	Slope	-0,02mS/cm	+100,48%	-0,50mS/cm	+148,32%	+0,02mS/cm	+100,10%	-10,66mS/cm	+101,31%	+3,33mS/cm	+99,56%
Zero point	Slope																								
-0,02mS/cm	+100,30%																								
-0,01 mS/cm	+100,04%																								
-0,01 mS/cm	+100,05%																								
-10,10mS/cm	+100,88%																								
+2,85mS/cm	+99,56%																								
Zero point	Slope																								
-0,02mS/cm	+100,48%																								
-0,50mS/cm	+148,32%																								
+0,02mS/cm	+100,10%																								
-10,66mS/cm	+101,31%																								
+3,33mS/cm	+99,56%																								
12	<p data-bbox="576 1301 1441 1364">Accept the calibration data acquired by pressing "Yes"; discard the data by pressing "No".</p>																								



## 12.1 Notes

**WARNING!**

During the calibration, the relays and analog output signals assume the configured states!

## 12.2 General information

The actual electrical characteristics of analysis sensors always deviate somewhat from the nominal specifications. The reasons for this include:

- Like every measuring instrument, analysis sensors always have a certain measurement uncertainty that results from manufacturing tolerances.
- During use, analysis sensors are exposed to chemical processes. Deposits and wear phenomena caused by these processes result in changes of the electrical characteristics of sensors.

To optimize the accuracy of measurements, analysis sensors must be calibrated. Calibrations are required:

- during installation or when changing a sensor
- regularly at time intervals that must be specified by the user
- if implausible measuring values are displayed
- if process conditions change, e. g. as the result of equipment modification

Calibration timers can be configured to provide a regular reminder of when calibrations are due.

⇒ Chapter 10.11 "Calibration timer", Page 163

Each successfully completed calibration is recorded in the calibration logbook.

⇒ Chapter 12.3 "Calibration logbook", Page 195

### 12.2.1 General procedure for calibration

#### True calibration (calibrating with routines)

After opening one of the calibration routines in the device, the user is guided through a process with measurements and entries. In the course of this process, the calibration values are determined and saved automatically.

Suitable calibration routines are available for every type of analysis sensor. The individual calibration routines for the various sensor types are described in separate chapters.

⇒ Chapter 13 "Calibrating a pH measuring chain", Page 199 to Chapter 17 "Calibrating Ci conductivity sensors", Page 223

Execution of calibration routines requires that the following prerequisites be met:

## 12 Calibration in general

---

- You must be logged in as a user with the right to perform calibrations. Factory-preset users have all of these rights.  
⇒ „Passwords and user rights“, Page 73
- You must ensure that the calibration default settings for the individual analysis inputs and, possibly, the universal inputs are set correctly. The explanations of the calibration default settings can be found in the chapters on calibration of the various analysis sensors.
- In the case of Ci analysis inputs, it should be noted that the optional boards must undergo a basic calibration during the initial commissioning. If this has not yet been performed, it is necessary to do so prior to any other calibration.

⇒ Chapter 11.2 "Ci base calibration", Page 188

### Manual entry of calibration values



**NOTE!**

Incorrectly entered calibration values result in incorrect measuring values. Correct measurements are essential for control systems and limit monitoring.

If calibration values are known, they can also be entered manually. This may be the case with temperature-compensated conductivity measurements, for instance, when the temperature coefficient of a liquid is known. Known calibration values are entered manually under:

Device Menu → Calibration → Select Analog Input → Calibration Values

## 12.3 Calibration logbook

A separate logbook is maintained for each analysis and universal input.

The last 10 **successful** calibrations of the input concerned are saved in the calibration logbook. Canceled or failed calibrations (calibrations outside the permissible limits) are not saved in the logbook, but rather noted in the event list. Manual changes of calibration values on the device are also documented. The following data are recorded in the logbook:

- Heading with description of the measuring input and calibration method
- Date and time
- Measurand
- Calibration assessment (assessment of the calibration values determined during the true calibration)
- Calibration values determined or entered
- Reference values used
- Calibration mode (true calibration/manual entry of calibration values)

Since this information does not yet fit in a screen line, the logbook entries are listed in abbreviated form with the date and calibration results for the time being. More exact information can be accessed for every entry via the detail view.

### Example of a calibration logbook

	Date	Zero-Point	Slope 1	Slope 2
✓	12/01/12	+54.65		
⚠	12/01/12	+7.00	-62.11	-62.11
✓	12/01/12	+6.71	-59.91	-59.91

### Calibration assessment symbols

✓	Calibration values are valid: Sensor is OK
⚠	The calibration values determined are critical. It is recommended that the sensor be cleaned.
✎	Manual value input

For Ci analysis inputs (inductive conductivity) and universal inputs that have been configured as a conductivity measuring input, a "TC curve" button is also displayed. Tapping this button opens a list with the temperature coefficients determined from the last "TC curve calibration".

## 12 Calibration in general

---

	Datum	Rel.Zk %	Tk %/K	T1 °C	T2 °C
	01/01/13		1,50		
	01/01/13		3,00		

### Example of a detail view of a logbook entry

The calibration logbook provides an overview of the calibrations performed. Tapping the "Details" button opens the selected logbook entry in the detail view. The detail view displays a table with all calibration values from a calibration procedure. The "Service" button is used for diagnostic purposes by trained personnel or JUMO Service.




Analysis input 4	
Two-point pH calibration	
Time	12/01/14 07:45:11
Calibration mode	With reference solution
pH zero point	+7.00 pH
Slope	-62.11 mV/pH +105.0 %
pH buffer 1	+5.00 pH +25.00 °C
pH buffer 2	+7.00 pH +25.00 °C

## 12 Calibration in general


### Assessment criteria

#### pH calibrations




(glass electrodes and ISFET connected to analysis measuring inputs as well as standard signals connected to universal inputs)

Calibration value [unit]	—				—
Zero point [pH]	... < 5 ≤ ... <	6 to 8	< ... ≤ 9 < ...		
Slope [%]	... < 75 ≤ ... <	89.6 to 103.1	< ... ≤ 110 < ...		

#### pH calibrations (antimony electrodes connected to analysis measuring inputs)

Calibration value [unit]	—		—
Zero point [pH]	... <	-2 to +2	< ...
Slope [%]	... <	10 to 110	< ...

#### Redox zero-point calibration




Calibration value [unit]	—				—
Zero point [mV]	... < -200 ≤ ... <	-120 to +120	< ... ≤ +200 < ...		



#### NOTE!

There is no assessment of the calibration values in the case of a Redox 2-point calibration.

#### Ammonia calibration




Calibration value [unit]	—				—
Zero point [mV]	... < -612 ≤ ... <	-312 to +588	< ... ≤ +888 < ...		


## 12 Calibration in general

---

### Calibration of conductivity sensors

(analysis measuring inputs and standard signals connected to universal inputs)

Calibration value [unit]	—					—							
Rel. cell constant (CR) [%]	...	<	50	≤	...	<	75 to 125	<	...	≤	150	<	...
Rel. cell constant (Ci) [%]	...	<	80	≤	...	<	90 to 110	<	...	≤	120	<	...

Calibration value [unit]	—				—		
Temperature coefficient (CR) [%/K]	...			<	0 to 8	<	...
Temperature coefficient (Ci) [%/K]	...			<	0 to 5.5	<	...



**NOTE!**

No assessment of the calibration values is performed for universal inputs in the "linear scaling" operation mode.

# 13 Calibrating a pH measuring chain

---

## 13.1 Important information



### **WARNING!**

During the calibration, the relays and the analog output signals assume the states configured under the respective "Response at calibration" configuration points for the analog and digital outputs!

## 13.2 General information

The calibration of pH electrodes is based on measurements in buffer solutions with a defined pH-value. The pH values of the buffer solutions used are specified either via entry of fixed values into the calibration default settings, entered during the calibration or recognized automatically by "automatic buffer recognition" during the calibration process. For "automatic buffer recognition", a buffer set table must be selected in the calibration default settings. In this case, the buffer solutions used must be listed in the provided buffer set table. Since pH value measurement of liquids is temperature-dependent, the temperature of the buffer solution must be sensed in order to compensate for its effect on the result of the measurement. This requires either manual entry or measurement with the aid of a Temperature sensor.

### 13.2.1 Calibration methods for pH sensors

#### **Zero-point calibration**

This calibration method is used to determine the pH zero point on the measurement characteristic curve. The slope is retained.

A buffer solution with a defined pH value is needed as a reference.

#### **Two-point Calibration**

By measuring 2 different buffer solutions with defined pH values, the pH zero point and pH slope of the measuring chain are established.

The pH values of the buffer solutions must be at least 2 pH apart. This calibration method is recommended for most applications.

#### **Three-point calibration**

With a three-point calibration, the pH zero point as well as the pH slope in the acidic region and the pH slope in the alkaline region are established. The three-point calibration can be performed only for pH sensors on analysis inputs. It is not available for JUMO digiLine pH sensors.

This method requires 3 buffer solutions with defined pH-values as references. One of these must be acidic, one neutral and one alkaline. The pH values of the buffer solution must be at least 2 pH apart from one another. This calibration method is recommended for applications with more demanding accuracy requirements when performing measurements in both the alkaline and acidic regions.

# 13 Calibrating a pH measuring chain

## 13.2.2 Calibration default settings for pH sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the pH Calibration are described in the following.

Open the calibration default settings:

Device Menu > Calibration > Select Analysis Input for pH/redox/NH<sub>3</sub> > Calibration Presets




**NOTE!**

The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.

⇒ Chapter 8.2.1 "Logon/Logoff", page 87

Sample screen:  
pH calibration default settings





## 13 Calibrating a pH measuring chain

### pH calibration default settings

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.

Calibration routines that are not enabled are not visible in the calibration menu. Additional calibration default settings are explained in the following table.

Parameters	Possible settings	Explanation
Buffer set selection	Buffer set 1 to 3  factory-preset: <ul style="list-style-type: none"> <li>• <b>Buffer set 1:</b> Reference buffer solutions for calibrating pH measuring instruments acc. to DIN 19266</li> <li>• <b>Buffer set 2:</b> Technical buffer solutions, preferably for calibrating and adjusting technical pH measuring instruments acc. to DIN 19267</li> </ul>	Buffer set tables contain pH values for selected buffer solutions as a function of temperature. These tables can be prepared/edited using commercially available standard solutions (DIN 19266, NIST; otherwise, technical buffer solutions etc.) or on the basis of customer-specific information. With their aid, buffer solutions can be recognized automatically when calibrating. The pH value data for the buffer solutions used must be contained in the buffer set table selected.  When a Buffer set is selected, this activates automatic buffer recognition and the entry fields for the settings "pH buffer 1 to 3" are hidden. You need the JUMO PC setup program to edit buffer set tables.
Buffer 1 pH-value	-2 to +16 pH	manual entry of the pH-values of the buffer solutions being used for the calibration  Depending on the selected Calibration routine, the corresponding entry fields for "pH buffer 1 to 3" are displayed. The pH-values of the buffer solutions used must be at least 2 pH apart.
Buffer 2 pH-value	-2 to +16 pH	
Buffer 3 pH-value	-2 to +16 pH	
Compensation	Fixed compensation temperature Temperature input Interface	<b>Fixed compensation temperature:</b> Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature".  <b>Temperature input:</b> The integrated temperature probe of the pH sensor supplies the compensation temperature.  <b>Interface:</b> The AQUIS touch P transmits the compensation temperature to the sensor electronics via the interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".

## 13 Calibrating a pH measuring chain

---

Parameters	Possible settings	Explanation
Temperature compensation	Selection from Analog selection	Temperature input for automatic sensing of the test/sample solution temperature during the calibration

# 13 Calibrating a pH measuring chain


## 13.3 pH Calibration routines



**NOTE!**

You must be logged in with corresponding user rights to perform calibrations.  
 ⇒ Chapter 8.2.1 "Logon/Logoff", page 87

### 13.3.1 Zero-point calibration


Step	Action
1	<p>Start the Zero-point calibration.</p> <p><b>for pH sensors on analysis inputs:</b>                      Device Menu &gt; Calibration &gt; Select Analysis Input for pH/redox/                      NH<sub>3</sub> &gt; Open Zero-Point Calibration</p> <p><b>for pH sensors with JUMO digiLine electronics:</b>                      Device Menu &gt; Calibration &gt; Digital Sensor 1 to 6 &gt; Open Zero-Point Calibration</p>
2	<p>If temperature compensation was not specified in the calibration default settings, enter the temperature of the buffer solution here manually.</p> <p>If temperature compensation was specified, the temperature of the buffer solution is determined automatically.</p> <div style="display: flex; align-items: center; margin-top: 20px;"> <div style="margin-right: 20px;">tap button to enter temperature</div>  </div>
3	Clean the pH electrode and immerse it in the buffer solution.

# 13 Calibrating a pH measuring chain


Step	Action								
4	<p><b>Entry of the pH-value of the buffer solution</b></p> <ul style="list-style-type: none"> <li> <b>without buffer recognition:</b>            Check whether the "pH buffer 1" matches the pH-value of the buffer solution used. If a buffer set table was not specified, the "buffer 1 pH" value is taken from the calibration default settings. It is still possible to change this manually here.         </li> </ul> <div data-bbox="906 512 1423 898" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center; background-color: #0056b3; color: white; padding: 2px;">Zero point-pH-calibration</p> <div style="display: flex; justify-content: space-around; border-bottom: 1px solid gray;"> <span style="background-color: #d3d3d3; padding: 2px 10px;">✔ OK</span> <span style="background-color: #d3d3d3; padding: 2px 10px;">✘ Cancel</span> </div> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="background-color: #ffff00; text-align: center;">Measuring value</td> <td style="background-color: #ffff00; text-align: center;">Temperature</td> </tr> <tr> <td style="text-align: center; font-size: 2em; color: red;">+7,08</td> <td style="text-align: center;">+22,00 °C</td> </tr> <tr> <td></td> <td style="background-color: #ffff00; text-align: center;">pH buffer 1</td> </tr> <tr> <td></td> <td style="text-align: center;">+5,00 pH</td> </tr> </table> <p style="font-size: 0.8em; margin-top: 5px;">           1: Clean electrode            2: Immerse electrode in buffer 1.            3: Wait for stable value            4: Press OK-key         </p> </div> <p style="margin-left: 20px;">tap button to enter pH-value of the buffer field</p> <ul style="list-style-type: none"> <li> <b>with buffer recognition:</b>            A prerequisite here is that a buffer set table has been selected in the buffer set table and the pH-value of the buffer solution used is contained in this buffer set table. If these prerequisites are satisfied, the pH value of the buffer solution is determined automatically during the calibration.         </li> </ul>	Measuring value	Temperature	+7,08	+22,00 °C		pH buffer 1		+5,00 pH
Measuring value	Temperature								
+7,08	+22,00 °C								
	pH buffer 1								
	+5,00 pH								
5	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"								
6	A Protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.								
7	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.								

# 13 Calibrating a pH measuring chain

## 13.3.2 Two-point and three-point calibration

Step	Action
1	<p>Start the desired Calibration routine.</p> <p><b>for pH sensors on analysis inputs:</b> Device Menu &gt; Calibration &gt; Analysis Input Select Analysis Input for pH/redox/NH<sub>3</sub> &gt; Open Two-Point or Three-Point Calibration</p> <p><b>for pH sensors with JUMO digiLine electronics:</b> Device Menu &gt; Calibration &gt; Digital Sensor 1 to 6 &gt; Open Two-Point Calibration</p>
2	<p>If temperature compensation was not specified in the calibration default settings, enter the temperatures of the buffer solution here manually. If temperature compensation was specified, the temperature of the buffer solution is determined automatically.</p> <p>To enter the temperature, tap the button</p> 
3	<p>Clean the pH electrode and immerse it in one of the buffer solutions. For a Two-point calibration, you need 2 buffer solutions. For a three-point calibration, you need 3 buffer solutions (acidic, neutral, and alkaline).</p>

# 13 Calibrating a pH measuring chain

Step	Action
4	<p><b>Entry of the pH-value of the buffer solution</b></p> <ul style="list-style-type: none"> <li> <b>without buffer recognition:</b>            Check whether the "pH buffer 1" matches the pH-value of the buffer solution used. If a buffer set table was not specified, the "buffer 1 pH" value is taken from the calibration default settings. It is still possible to change this manually here.         </li> </ul> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;">           tap button to enter pH-value of the buffer field         </div>  </div> <ul style="list-style-type: none"> <li> <b>with buffer recognition:</b>            A prerequisite here is that a buffer set table has been selected in the buffer set table and the pH-value of the buffer solution used is contained in this buffer set table. If these prerequisites are satisfied, the pH value of the buffer solution is determined automatically during the calibration.         </li> </ul>
5	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK".
6	For each additional calibration point, repeat steps 3 to 5 with the required buffer solutions.
7	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
8	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

# 14 Calibrating redox sensors

---

## 14.1 Important information



### **WARNING!**

During the calibration, the relays and analog output signals assume the configured states!

## 14.2 General information

The calibration of Redox sensors is based on measurements in test solutions with a defined Redox potential.

### 14.2.1 Calibration methods for Redox sensors

#### Zero-point calibration

This calibration method is used to determine the redox zero point. A test solution with a defined redox potential is needed as a reference. "mV" must be set as the redox unit in the configuration of the redox measuring input (analysis input or input for digital sensors).  
⇒ Chapter 10.5.3 "pH/Redox/NH3 analysis inputs", page 140

#### Two-point Calibration

This calibration is used to establish an application-specific measurement characteristic curve where Redox potentials are represented as a percentage of concentration values. The redox potentials of 2 solutions are measured. Concentration values in percent are then assigned to the measured values by the user.

Two process-typical sample solutions are needed as calibration solutions as a reference. "Percent" must be set as the redox unit in the configuration of the redox measuring input (analysis input or input for digital sensors).  
⇒ Chapter 10.5.3 "pH/Redox/NH3 analysis inputs", page 140

**Example:** In a detoxification plant, the toxicity of a liquid is to be measured on the basis of the Redox potential. The calibration requires 2 solutions:

- the concentration of the highly toxic solution is given as 80 % by the user, for instance
- the concentration of the detoxified solution is given as 10 % by the user, for instance

Using the redox potential, the toxicity can now be measured and displayed in percent.

# 14 Calibrating redox sensors

## 14.2.2 Calibration default settings for Redox sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the Redox calibration are described in the following.

Open the calibration default settings:

Device Menu > Calibration > Select Analysis Input for pH/redox/NH<sub>3</sub> > Calibration Presets




**NOTE!**

The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.

⇒ Chapter 8.2.1 "Logon/Logoff", page 87

Sample screen:  
Redox calibration default settings  
(zero-point calibration)



### Redox calibration default settings

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.

Calibration routines that are not enabled are not visible in the calibration menu. Additional calibration default settings are explained in the following table.

Parameters	Possible settings	Explanation
Redox test solution	-1500 to +1500 mV	Manual entry of the Redox potential of the test solution being used for calibration



**NOTE!**

Remember that the configuration of the redox measuring input must be set to the redox unit "mV" for the zero-point calibration and to "Percent" for the two-point calibration.

⇒ Chapter 10.5.3 "pH/Redox/NH<sub>3</sub> analysis inputs", page 140



# 14 Calibrating redox sensors

## 14.3 Redox calibration routines



**NOTE!**

You must be logged in with corresponding user rights to perform calibrations.  
 ⇒ Chapter 8.2.1 "Logon/Logoff", page 87

### 14.3.1 Zero-point calibration

Step	Action
1	Ensure that <ul style="list-style-type: none"> <li>the calibration default settings are correct,</li> <li>"mV" is set as the Redox unit in the configuration of the Redox measuring input.</li> </ul> ⇒ Chapter 14.2.2 "Calibration default settings for Redox sensors", page 208. ⇒ Chapter 10.5.3 "pH/Redox/NH3 analysis inputs", page 140
2	Start the Zero-point calibration.  <b>for redox sensors on analysis inputs:</b> Device Menu > Calibration > Select Analysis Input for pH/redox/ NH <sub>3</sub> > Zero-Point Calibration  <b>for redox sensors with JUMO digiLine electronics:</b> Device Menu > Calibration > Digital Sensor 1 to 6 > Zero-Point Calibration
3	Check that the "Redox test solution" value displayed matches the Redox value of the test solution. The "Redox test solution" value is taken from the calibration default settings. It is still possible to change this manually here.  Tap button to change the Redox value of the test solution manually <div style="text-align: right; margin-top: 10px;"> </div>
4	Clean the Redox electrode and immerse it in the test solution. Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK".
5	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.



## 14 Calibrating redox sensors

---

Step	Action
6	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

# 14 Calibrating redox sensors

## 14.3.2 Two-point Calibration

Step	Action
1	<p>Ensure that</p> <ul style="list-style-type: none"> <li>the calibration default settings are correct</li> <li>"Percent" is set as the Redox unit in the configuration of the Redox measuring input.</li> </ul> <p>⇒ Chapter 14.2.2 "Calibration default settings for Redox sensors", page 208.            ⇒ Chapter 10.5.3 "pH/Redox/NH<sub>3</sub> analysis inputs", page 140</p>
2	<p>Start the two-point calibration.</p> <p><b>for redox sensors on analysis inputs:</b>            Device Menu &gt; Calibration &gt; Select Analysis Input for pH/redox/ NH<sub>3</sub> &gt; Two-Point Calibration</p> <p><b>for redox sensors with JUMO digiLine electronics:</b>            Device Menu &gt; Calibration &gt; Digital Sensor 1 to 6 &gt; Two-Point Calibration</p>
3	<p>Enter the concentration value of the first reference solution in percent. Confirm by pressing "OK".</p> <div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>Tap button to enter field</p>  </div>  </div>
4	<p>Clean the Redox electrode and immerse it in the first test solution. Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK".</p>
5	<p>As in step 3, enter the concentration value of the second solution in percent. Confirm by pressing "OK".</p>
6	<p>Clean the Redox electrode and immerse it in the second test solution. Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK".</p>
7	<p>A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK".            Failed calibrations are canceled at this point and discarded.</p>
8	<p>Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook.            Press "No" to discard the results.</p>

## 14 Calibrating redox sensors

---

# 15 Calibrating ammonia sensors

## 15.1 Notes



### WARNING!

During the calibration, the relays and analog output signals assume the configured states!

## 15.2 General information

The calibration of ammonia sensors is based on measurements in ammonia-free test solutions.

### 15.2.1 Calibration methods for ammonia sensors

#### Zero-point calibration

This calibration method is used to determine the ammonia zero point. An ammonia-free test solution (e. g. water) is needed as a reference.


### 15.2.2 Calibration default settings for ammonia sensors

In the ammonia sensor calibration default settings, the zero-point calibration is enabled and preconfigured as the only available calibration routine.

Open the calibration default settings:

Device menu → Calibration → Select Analysis Input for pH/Redox/  
NH<sub>3</sub> → Calibration Default Settings

Sample screen:  
Ammonia calibration  
default settings



# 15 Calibrating ammonia sensors

---

## 15.3 Ammonia calibration routines



**NOTE!**

You must be logged in with corresponding user rights to perform calibrations.  
⇒ Chapter 8.2.1 "Logon/Logoff", Page 87

### 15.3.1 Zero-point calibration

Step	Action
1	Start the Zero-point calibration.  Device menu → Calibration → Select Analysis Input for pH/Redox/ NH <sub>3</sub> → Zero-Point Calibration
2	Clean the ammonia electrode and immerse it in the ammonia-free test solution. Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK".
3	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
4	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

# 16 Calibrating CR conductivity sensors

## 16.1 Notes



### **WARNING!**

During the calibration, the relays and analog output signals assume the configured states!

## 16.2 General information

The calibration of CR sensors is based on measurements in test solutions with a defined electrolytic conductivity. Since the electrolytic conductivity of liquids is temperature dependent, the temperature of the test solution must be sensed. This requires either manual entry or measurement with the aid of a temperature sensor.

### 16.2.1 Calibration methods for CR conductivity sensors (conductive)

#### **Rel. cell constant**

The deviation from the nominal cell constant of a CR sensor is described by the relative cell constant. The rel. cell constant is determined by making a measurement in a test solution with a defined conductivity.

#### **Temperature coefficient**

The temperature coefficient is a measure of the temperature dependence of the electrolytic conductivity of a liquid. Is used to compensate for the effect of temperature when measuring the electrolytic conductivity. When making a temperature-compensated conductivity measurement, the measuring value of the conductivity is always given on the basis of the fixed, preset reference temperature. With the aid of the temperature coefficient, the value of the electrical conductivity at the reference temp. is calculated from the current values of conductivity and temperature measured for the liquid and then displayed. Reference temp. is set in the configuration of the individual CR analysis input. ⇒ Chapter 10.5.4 "CR/Ci analysis inputs (conductive/inductive conductivity)", Page 142

The temperature coefficient is determined from 2 measurements in a test solution at different temperatures (reference and operation temp.).



### **NOTE!**

If the temperature coefficient of a sample solution is known, it can be entered directly.

⇒ Chapter 12.2.1 "General procedure for calibration", Page 193

# 16 Calibrating CR conductivity sensors

## 16.2.2 Calibration default settings for CR conductivity sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the CR calibration are described in the following.


Open the calibration default settings:  
Device menu → Calibration → Select CR Analysis Input → Calibration Default Settings



**NOTE!**

The "Calibration Default Settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.  
⇒ Chapter 8.2.1 "Logon/Logoff", Page 87

Sample screen:  
CR calibration default settings



The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.  
Calibration routines that are not enabled are not visible in the calibration menu.  
Additional calibration default settings are explained in the following table.



## 16 Calibrating CR conductivity sensors

---

### Calibration default settings for calibrating the relative cell constant

Parameter	Setting options	Explanation
Reference conductivity	0 to 9999 mS/cm	Conductivity of the reference solution

### Calibration default settings for calibrating the temperature coefficient

Parameter	Setting options	Explanation
Temperature compensation	Selection from analog selection	Temperature input for automatic sensing of the test/sample solution temperature during the calibration
Reference temperature	-50 to +150° C	The conductivities of a sample solution at the reference temperature and operation temperature are sensed during the calibration procedure. This yields 2 value pairs (temperature/conductivity). These value pairs provide the basis for calculating the temperature coefficient. The operation temp. must differ from the reference temperature by at least 5 °C.
Operation temperature	-50 to +150° C	

# 16 Calibrating CR conductivity sensors

## 16.3 CR calibration routines



**NOTE!**


Conductivity measuring inputs can be configured with measuring range change-over. Accordingly, calibrations must be performed for all "accessible measuring ranges".



**NOTE!**

You must be logged in with corresponding user rights to perform calibrations.  
 ⇒ Chapter 8.2.1 "Logon/Logoff", Page 87

### 16.3.1 Calibrating the relative cell constant


Step	Action
1	<p>Start calibration of the relative cell constant.</p> <p>Device menu → Calibration → Select CR Analysis Input → Rel. cell constant Calibration</p> <p>For CR optional boards, continue with step 2; for universal inputs set to the "conductivity measurement" operation mode, continue with step 3</p>
2	<p>Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK"</p> <p>The calibration values determined apply only to the selected measuring range.</p> <p>Tap button to enter measuring range</p> 

## 16 Calibrating CR conductivity sensors



Step	Action
3	<p>Ensure that</p> <ul style="list-style-type: none"> <li>the sensor has been cleaned and is immersed in the test solution,</li> <li>the set reference conductivity matches the conductivity value of the test solution.</li> </ul> <p>Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK".</p> <p>The preset reference conductivity can be changed here manually if necessary.</p> <div data-bbox="900 624 1414 1008" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center; background-color: #000080; color: white; margin: 0;">Relative cell constant calib.</p> <div style="display: flex; justify-content: space-around; margin: 5px 0;"> <span style="color: green;">✔ OK</span> <span style="color: red;">✘ Cancel</span> </div> <div style="border: 1px solid gray; padding: 5px; margin: 5px 0;"> <p style="text-align: center; background-color: yellow; margin: 0;">Measuring value</p> <p style="text-align: center; font-size: 2em; color: red; margin: 0;">11,9</p> <p style="text-align: right; margin: 0;">mS/cm</p> </div> <div style="border: 1px solid gray; padding: 5px; margin: 5px 0;"> <p style="text-align: center; background-color: yellow; margin: 0;">Reference condit</p> <p style="text-align: center; color: purple; margin: 0;">+12.88</p> <p style="text-align: right; margin: 0;">mS/cm</p> </div> <div style="font-size: 2em; color: black; margin: 5px 0;">→</div> <div style="font-size: 0.8em; margin: 5px 0;"> <p>1: Clean measuring cell</p> <p>2: Dip meas. cell in ref. solution</p> <p>3: Wait for stable value</p> <p>4: Press OK-key</p> </div> </div> <p>tap button to change reference field</p>
4	<p>A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.</p>
5	<p>Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.</p>

# 16 Calibrating CR conductivity sensors

## 16.3.2 Calibrating the temperature coefficient

Step	Action
1	<p>Start calibration of the temperature coefficient.</p> <p>Device menu → Calibration → Select CR Analysis Input → TC Calibration</p>
2	<p>Clean the sensor and immerse it in the sample solution. Ensure that the rel. cell constant is calibrated correctly (if necessary, make a trial measurement with a test solution).</p> <p>For CR optional boards, continue with step 3; for universal inputs set to the "conductivity measurement" operation mode, continue with step 4</p>
3	<p>Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK"</p> <p>The calibration values determined apply only to the selected measuring range.</p> <p>tap button to enter measuring field</p> 

## 16 Calibrating CR conductivity sensors

Step	Action
4	<ul style="list-style-type: none"> <li><b>with temperature sensing</b></li> </ul> <p>A prerequisite is that temperature compensation was specified in the calibration default settings. Bring the temperature of the sample solution to the requested values of the reference and operation temperatures in succession. The order does not matter. Acquisition of the individual values takes place automatically.</p> <p>current actual value of temperature</p>  <p>requested Temperature values</p> <p>Display after acquisition of first value</p>  <p>remaining requested temperature value</p> <ul style="list-style-type: none"> <li><b>without temperature sensing</b></li> </ul> <p>If temperature compensation was not specified in the calibration default settings, you must control acquisition of the value manually. Bring the temperature of the sample solution first to the value of the reference temperature and confirm by pressing "OK". Then proceed in the same manner for the operation temperature.</p>
5	<p>A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.</p>
6	<p>Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.</p>

## 16 Calibrating CR conductivity sensors

---

# 17 Calibrating Ci conductivity sensors

## 17.1 Important information



### **WARNING!**

During the calibration, the relays and analog output signals assume the configured states!

## 17.2 General information

The calibration of Ci sensors is based on measurements in test solutions with a defined electrolytic conductivity. Since the electrolytic conductivity of liquids is temperature dependent, the temperature of the test solution must be sensed. This requires either manual entry or measurement with the aid of a temperature sensor.

### 17.2.1 Calibration methods for Ci conductivity sensors (inductive)

#### **Rel. cell constant**

The deviation from the nominal cell constant of a Ci sensor is described by the relative cell constant. The rel. cell constant is determined by making a measurement in a test solution with a defined conductivity.

#### **Temperature coefficient**

The temperature coefficient is a measure of the temperature dependence of the electrolytic conductivity of a liquid. Is used to compensate for the effect of temperature when measuring the electrolytic conductivity. When making a temperature-compensated conductivity measurement, the measuring value of the conductivity is always given on the basis of the fixed, preset reference temperature. With the aid of the temperature coefficient, the value of the electrical conductivity at the reference temp. is calculated from the current values of conductivity and temperature measured for the liquid and then displayed. Reference temperature is set in the configuration of the individual Ci analysis input.

⇒ Chapter 10.5.4 "CR/Ci analysis inputs (conductive/inductive conductivity)", Page 142

The temperature coefficient is determined from 2 measurements in a test solution at different temperatures (reference and operation temp.).



### **NOTE!**


If the temperature coefficient of a sample solution is known, it can be entered directly.

⇒ Chapter 12.2.1 "General procedure for calibration", Page 193

# 17 Calibrating Ci conductivity sensors

## TC curve (for nonlinear temperature coefficients)

If the conductivity of a liquid whose temperature coefficient changes with temperature has to be measured, this method can determine 5 temperature coefficients for 5 temperature intervals. In this way, it is possible to determine a good approximation of the temperature coefficient curve. While the operator brings the sample solution to the temperature values requested by the device, the device determines the temperature coefficient for each interval. This requires installation of a temperature sensor that the device can use to sense the temperature of the sample solution.



### 17.2.2 Calibration default settings for Ci conductivity sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the Ci calibration are described in the following.

Open the calibration default settings:

Device Settings Menu → Calibration → Select Ci Analysis Input or Universal Input → Calibration Default Settings




#### NOTE!

The "Calibration Default Settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.  
⇒ Chapter 8.2.1 "Logon/Logoff", Page 87



## 17 Calibrating Ci conductivity sensors

Sample screen:  
Ci calibration default  
settings



The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.  
Calibration routines that are not enabled are not visible in the calibration menu.  
Additional calibration default settings are explained in the following table.

### Calibration default settings for calibrating the relative cell constant

Parameter	Setting options	Explanation
Reference conductivity	0 to 9999 mS/cm	Conductivity of the reference solution

### Calibration default settings for calibrating the temperature coefficient

Parameter	Setting options	Explanation
Temperature compensation	Selection from analog selection	Temperature input for automatic sensing of the test/sample solution temperature during the calibration
Reference temperature	-50 to 150 °C	The conductivities of a sample solution at the reference temperature and operation temperature are sensed during the calibration procedure. This yields 2 value pairs (temperature/conductivity). These value pairs provide the basis for calculating the temperature coefficient. The operation temp. must differ from the reference temperature by at least 5 °C.
Operating temperature	-50 to 150 °C	

## 17 Calibrating Ci conductivity sensors

---

### Calibration default settings for calibrating the TC curve

Parameter	Setting options	Explanation
Temperature compensation	Selection from analog selection	Temperature input for automatic sensing of the test/sample solution temperature during the calibration
Starting temperature	-50 to 250 °C	The starting and final temperatures of the range for which a temperature coefficient curve is to be determined. The starting temperature must be at least 20 °C lower than the final temperature. The reference temperature for the measuring input must lie between the starting and final temperatures, and differ from the starting and final temperatures by at least 2 °C.
Final temperature	-50 to 250 °C	

**NOTE!**

Calibration of the TC curve is possible only with automatic temperature sensing.

# 17 Calibrating Ci conductivity sensors

## 17.3 Ci calibration routines



**NOTE!**

Conductivity measuring inputs can be configured with measuring range change-over. Accordingly, calibrations must be performed for all "accessible measuring ranges".



**NOTE!**


You must be logged in with corresponding user rights to perform calibrations.  
⇒ Chapter 8.2.1 "Logon/Logoff", Page 87



**NOTE!**

Analysis inputs for inductive conductivity measurements (Ci) must undergo a basic Ci calibration in the course of commissioning. Subsequent calibration is not possible without this initial basic Ci calibration.  
⇒ Chapter 11.2 "Ci base calibration", Page 188

### 17.3.1 Calibrating the relative cell constant


Step	Action
1	<p>Start calibration of the relative cell constant.</p> <p>Device Settings Menu → Calibration → Select Ci Analysis Input or Universal Input → Relative Cell Constant Calibration</p> <p>for Ci optional boards, continue with step 2; for universal inputs set to the "conductivity measurement" operating mode, continue with step 3;</p>
2	<p>Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK"</p> <p>The calibration values determined apply only to the selected measuring range.</p> <p>tap button to enter measuring range</p> 

# 17 Calibrating Ci conductivity sensors



Step	Action
3	<p>Ensure that</p> <ul style="list-style-type: none"> <li>the sensor has been cleaned and is immersed in the test solution,</li> <li>the set reference conductivity matches the conductivity value of the test solution.</li> </ul> <p>Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK".</p> <p>The preset reference conductivity can be changed here manually if necessary.</p> <div data-bbox="900 624 1415 1008" style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p style="text-align: center; background-color: #000080; color: white; margin: 0;">Relative cell constant calib.</p> <div style="display: flex; justify-content: space-around; margin: 5px 0;"> <span style="color: green;">✔ OK</span> <span style="color: red;">✘ Cancel</span> </div> <div style="display: flex; justify-content: space-between; margin: 5px 0;"> <div style="text-align: center;"> <p style="background-color: yellow; margin: 0;">Measuring value</p> <p style="font-size: 2em; color: red; margin: 0;">11,9</p> <p style="margin: 0;">mS/cm</p> </div> <div style="text-align: center;"> <p style="background-color: yellow; margin: 0;">Reference condit</p> <p style="color: purple; margin: 0;">+12.88</p> <p style="margin: 0;">mS/cm</p> </div> </div> <div style="font-size: 0.8em; margin-top: 5px;"> <p>1: Clean measuring cell</p> <p>2: Dip meas. cell in ref. solution</p> <p>3: Wait for stable value</p> <p>4: Press OK-key</p> </div> </div> <p>tap button to change reference range</p>
4	<p>A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.</p>
5	<p>Press "Yes" to accept the calibration values determined and enter the calibration in the calibration logbook. Press "No" to discard the results.</p>

# 17 Calibrating Ci conductivity sensors

## 17.3.2 Calibrating the temperature coefficient



Step	Action
1	Start calibration of the temperature coefficient.  Device Settings Menu → Calibration → Select Ci Analysis Input or Universal Input → TC Calibration
2	Clean the sensor and immerse it in the sample solution. Ensure that the rel. cell constant is calibrated correctly (if necessary, make a trial measurement with a test solution).  for Ci optional boards, continue with step 3; for universal inputs set to the "conductivity measurement" operating mode, continue with step 4
3	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK" The calibration values determined apply only to the selected measuring range.  <p>tap button to enter measuring range</p> 

# 17 Calibrating Ci conductivity sensors

Step	Action
4	<p>• <b>with temperature sensing</b></p> <p>A prerequisite is that temperature compensation was specified in the calibration the default settings.            Bring the temperature of the sample solution to the requested values of the reference and operation temperatures in succession.            The order does not matter. Acquisition of the individual values takes place automatically.</p> <div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; justify-content: space-between; width: 100%;"> <div style="width: 45%;">current actual value of temperature</div>  </div> <div style="width: 45%; margin-top: 10px;">requested temperature values</div> <div style="width: 100%; margin-top: 20px;">Display after acquisition of first value</div> <div style="display: flex; justify-content: space-between; width: 100%;"> <div style="width: 45%;">remaining requested temperature value</div>  </div> </div> <p>• <b>without temperature sensing</b></p> <p>If temperature compensation was not specified in the calibration default settings, you must control acquisition of the value manually.            Bring the temperature of the sample solution first to the value of the reference temperature and confirm by pressing "OK".            Then proceed in the same manner for the operation temperature.</p>
5	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
6	Press "Yes" to accept the calibration values determined and enter the calibration in the calibration logbook. Press "No" to discard the results.

# 17 Calibrating Ci conductivity sensors

## 17.3.3 Calibrating the TC-Curve

Step	Action
1	<p>Start the desired calibration of the TC-Curve.</p> <p>Device Menu → Calibration → Analysis Input 1 to 4 (Ci) and/or Universal Input 1 to 3 → TC-Curve</p>
2	<p>Clean the sensor and immerse it in the sample solution. Ensure that the rel. cell constant is calibrated correctly (if necessary, make a trial measurement with a test solution).</p> <p>for Ci optional boards, continue with step 3; for universal inputs set to the "conductivity measurement" operating mode, continue with step 4</p>
3	<p>Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK"</p> <p>The calibration values determined apply only to the selected measuring range.</p>  <p>tap button to enter measuring range</p>
4	<p>Bring the temperature of the sample solution to the requested set-points in succession. Six temperatures are requested.</p>  <p>current actual value of temperature</p> <p>requested temperature val-</p>
5	<p>A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.</p>
6	<p>Press "Yes" to accept the calibration values determined and enter the calibration in the calibration logbook. Press "No" to discard the results.</p>

## 17 Calibrating Ci conductivity sensors

---



# 18 Calibrating universal inputs

## 18.1 Important information



### WARNING!

During the calibration, the relays and analog output signals assume the configured states!

## 18.2 General information

### 18.2.1 Calibration methods for universal inputs

Universal inputs can be configured with various operation modes for a number of different process variables (see table below).

Detailed information on the possible configurations:

⇒ Chapter 10.5.2 "Universal inputs of base unit and optional boards", Page 137

Appropriate calibration routines for each operation mode of a universal input can be enabled in the calibration default settings.

The following table lists the availability of calibration routines for the individual operation modes.

Universal input Operation modes  Calibration routine	linear scaling	Temp. mea- surement	pH value measure- ment	Conductivity measure- ment	free chlorine, pH/T-com- pensated
Zero-point calibration	X		X		
Slope calibration	X				X
Two-point calibration	X		X		
Rel. cell constant				X	
Temperature coefficient				X	
TC-curve				X	

#### Zero-point calibration

This calibration method is used to determine the pH zero point on a measurement characteristic curve. The slope is retained.

A test solution with a defined value of the respective process variable is needed as a reference.

#### Slope calibration

This calibration method is used to determine the slope of a measurement characteristic curve. The zero point is retained.

A test solution with a defined value of the respective process variable is needed as a reference.

# 18 Calibrating universal inputs

---

## Two-point calibration

The zero point and slope of the measuring characteristic curve are determined with the aid of 2 measurings of 2 different reference solutions.

Two test solutions with defined values of the respective process variable are needed as a references.

## Calibrating rel. cell constants, temperature coefficients, and TC-curves

The calibration routines for conductivity measuring with the universal input correspond to those for the Ci calibration.

⇒ Chapter 17 "Calibrating Ci conductivity sensors", Page 223

# 18 Calibrating universal inputs

## 18.2.2 Universal inputs calibration default settings

The calibration default setting available for selection depends on the configuration settings of the universal input.

Open the calibration default settings:

Device Menu → Calibration → Select Universal Input → Calibration Default Settings


### Calibration default settings for the individual operation modes

- **linear scaling**

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.

Calibration routines that are not enabled are not visible in the calibration menu. The "linear scaling" operation mode permits adjustment of the zero point, slope, and two-point calibration.

Sample screen:  
Universal input calibration default settings in the "linear scaling" operation mode



- **pH value measurement**

The calibration default settings correspond to those for the zero-point and two-point calibration for pH/Redox/NH<sub>3</sub> analysis inputs.

⇒ „pH calibration default settings“, Page 201

- **Conductivity measurement**

The calibration default settings correspond to those for the Ci calibration.


⇒ Chapter 17.2.2 "Calibration default settings for Ci conductivity sensors", Page 224

# 18 Calibrating universal inputs

- **free chlorine, pH/Temp.-compensated**

In the universal inputs calibration default settings for the "free chlorine, pH/T-compensated" operation mode, the slope calibration is enabled and pre-configured as the only available calibration routine.

Sample screen:  
 Universal input calibration default settings in the "free chlorine, pH/T-compensated" operation mode



Additional calibration default settings for calibration of chlorine sensors are explained in the following table.

Parameter	Possible settings	Explanation
Temperature compensation	Selection from Analog selection	Temperature input for automatic sensing of the test/sample solution temperature during the calibration
pH compensation source	Selection from Analog selection	pH measuring input for automatic sensing of the test/sample solution pH value during the calibration



**NOTE!**

The "Calibration Default Settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.  
 ⇒ Chapter 8.2.1 "Logon/Logoff", Page 87

# 18 Calibrating universal inputs

---

## 18.3 Universal input calibration routines

This chapter explains the universal inputs calibration routines for the "linear scaling" and "free chlorine, pH/T-compensated" operation modes.

The explanations in the corresponding calibration chapters for the "pH value measurement" and "Conductivity measurement" operation modes apply, except that three-point calibration for pH sensors is not available for universal inputs (see Chapter 18.2.1 "Calibration methods for universal inputs", Page 233).

⇒ Chapter 13.3 "pH Calibration routines", Page 203

⇒ Chapter 17.3 "Ci calibration routines", Page 227





**NOTE!**

You must be logged in with corresponding user rights to perform calibrations.

⇒ Chapter 8.2.1 "Logon/Logoff", Page 87



# 18 Calibrating universal inputs

## 18.3.1 Zero point/slope calibration (linear scaling)

Step	Action
1	<p>Start the desired Calibration routine.</p> <p>Device Menu → Calibration → Select Universal Input → Zero-point calibration</p>
2	<p>Clean the sensor and immerse it in the test solution. Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK".</p> <p>The measuring value is based on previous calibration values</p> 
3	<p>Enter the reference value of the test solution. Confirm by pressing "OK"</p> <p>Tap button to enter reference value of test solution</p> 
4	<p>A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.</p>
5	<p>Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.</p>

# 18 Calibrating universal inputs

## 18.3.2 Two-point calibration (linear scaling)

Step	Action
1	<p>Start the desired Calibration routine.</p> <p>Device Menu → Calibration → Select Universal Input → Two-point calibration</p>
2	<p>Clean the sensor and immerse it in the first test solution. Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK".</p> <p>Measuring value based on previous calibration values</p> 
3	<p>Enter the reference value of the first test solution.</p> <p>Tap button to enter reference value of test solution</p> 
4	<p>Clean the sensor and immerse it in the second reference solution. Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK".</p>
5	<p>As in step 3, enter the reference value of the second test solution. Confirm by pressing "OK".</p>
6	<p>A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.</p>
7	<p>Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.</p>



## 18 Calibrating universal inputs

---



# 18 Calibrating universal inputs

## 18.3.3 Slope calibration (free chlorine, pH/Temp.-compensated)

Step	Action
1	<p>Start the slope calibration.</p> <p>Device Menu → Calibration → Select Universal Input → Slope Calibration</p>
2	<p>Clean the sensor and immerse it in the test solution.</p>
3	<p>Check the displayed values for the pH value and temperature. Automatic sensing can be configured in the calibration default settings for both process variables independently of one another. With automatic sensing, the particular influencing variable is only displayed and can no longer be changed here. Without automatic sensing, the particular influencing variable must be entered manually here.</p> <p>Wait until the measuring value displayed stabilizes and then check the pH value displayed. Then confirm by pressing "OK".</p> <p>Example with temperature sensing and without pH-value sensing</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>Measuring value based on previous calibration values</p> <p>Tap button to enter pH value of test solution</p> </div>  </div>
4	<p>Enter the concentration value of the test solution. Confirm by pressing "OK"</p> <div style="display: flex; align-items: flex-start;"> <div style="margin-right: 20px;"> <p>Tap button to enter chlorine concentration</p> </div>  </div>
5	<p>A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.</p>

## 18 Calibrating universal inputs

---

Step	Action
6	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

# 19 Calibrating O-DO sensors

## 19.1 Important information



### WARNING!

During the calibration, the relays and analog output signals assume the configured states!

## 19.2 General information


Depending on the calibration method, O-DO sensors are calibrated on the basis of measurements in water and water sulfite solutions (sulfite concentration < 2 %).



### NOTE!

As the manufacturing of air-saturated water requires a high level of effort and is difficult to reproduce, the easier process of calibration in water vapor-saturated air is recommended for the operational calibration.

### Positioning the sensor in the water vapor-saturated air



To achieve successful calibration, the following points must be taken into account:

- The sensor must be kept dry during the calibration process. Drops of water adhering to the sensor membrane could distort the measurement result.
- The air pressure and temperature must remain constant during the calibration.

# 19 Calibrating O-DO sensors

## 19.2.1 Calibration methods for O-DO sensors

### End value calibration

With end value calibration, the slope of the sensor is calibrated beyond the defined state of 100 % oxygen saturation. This state can in principle be achieved in two ways:

- By positioning the sensor in water vapor-saturated air (for example, directly over a water surface).
- By positioning the sensor in air-saturated water (air is directed through water until the water is saturated with it).

### Two-point Calibration

With two-point calibration, the zero point and slope of the sensor are calibrated. This calibration method offers the greatest possible level of accuracy and is particularly recommended for measurements of small oxygen concentrations.

## 19.2.2 Calibration default settings for O-DO sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the O-DO calibration are described in the following.


Open the calibration default settings:  
Device Menu > Calibration > Digital Sensor 1 to 6 >  
Calibration Default Settings



### NOTE!

The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.  
⇒ Chapter 8.2.1 "Logon/Logoff", page 87

Sample screen:  
O-DO calibration default  
settings



## 19 Calibrating O-DO sensors

---

### O-DO calibration default settings

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.

Calibration routines that are not enabled are not visible in the calibration menu. Additional calibration default settings are explained in the following table.

Parameters	Possible settings	Explanation
Compensation	Fixed compensation temperature Temperature input Interface	<b>Fixed compensation temperature:</b> Compensation with a fixed temperature value that is entered in the configuration item "Compensation temperature".  <b>Temperature input:</b> The integrated temperature probe of the O-DO sensor supplies the compensation temperature.  <b>Interface:</b> The AQUIS touch p transmits the compensation temperature to the sensor electronics via the interface. The source of the compensation temperature is set in the configuration point "Compensation temperature".
Temperature compensation	Selection from Analog selection	Temperature input for automatic sensing of the test/sample solution temperature during the calibration

# 19 Calibrating O-DO sensors


## 19.3 O-DO calibration routine




**NOTE!**

You must be logged in with corresponding user rights to perform calibrations.  
 ⇒ Chapter 8.2.1 "Logon/Logoff", page 87

### 19.3.1 End value calibration



Step	Action
1	<p>Start the end value calibration.</p> <p>Device Menu &gt; Calibration &gt; Digital Sensor 1 to 6 &gt; End Value Calibration</p>
2	<p>If temperature compensation was not specified in the calibration default settings, enter the temperature of the air-saturated water or the water vapor-saturated air here manually.                      If temperature compensation was specified, the temperature is determined automatically.</p> <p>tap button to enter temperature</p> 
3	<p>Immerse the sensor in air-saturated water or position it in water vapor-saturated air (see Chapter 19.2.1 "Calibration methods for O-DO sensors", page 244). If you use water vapor-saturated air, ensure constant air pressure, constant temperature and that no water drops adhere to the membrane during the calibration procedure. Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK".</p>

## 19 Calibrating O-DO sensors

Step	Action
4	<p>The device displays the current measured value of oxygen saturation and the test material temperature. The setpoint value for oxygen saturation (100 %Sat) is set automatically by the device. The user does not need to make any entries here.</p> 
5	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"
6	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
7	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.


# 19 Calibrating O-DO sensors

## 19.3.2 Two-point Calibration

Step	Action
1	Start the two-point calibration.  Device Menu > Calibration > Digital Sensor 1 to 6 > Two-Point Calibration
2	To determine the zero point, prepare a water sulfite solution (sulfite concentration < 2 %).
3	<p>If temperature compensation was not specified in the calibration default settings, enter the temperature of the test materials used here manually. If temperature compensation was specified, the temperature is determined automatically.</p> <p>tap button to enter temperature</p> 
4	Immerse the sensor in the water sulfite solution. Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK".
5	<p>The device displays the current measured value of oxygen saturation and the test material temperature. The setpoint value for oxygen saturation (0 %Sat) is set automatically by the device. The user does not need to make any entries here.</p> 
6	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"



## 19 Calibrating O-DO sensors

Step	Action
7	Immerse the sensor in air-saturated water or position it in water vapor-saturated air (see Chapter 19.2.1 "Calibration methods for O-DO sensors", page 244). If you use water vapor-saturated air, ensure constant air pressure, constant temperature and that no water drops adhere to the membrane during the calibration procedure. Wait until the measuring value displayed stabilizes and then confirm the result of the measurement by pressing "OK".
8	<p>The device displays the current measured value of oxygen saturation and the test material temperature. The setpoint value for oxygen saturation (100 %Sat) is set automatically by the device. The user does not need to make any entries here.</p> <div style="text-align: center;">  </div>
9	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"
10	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
11	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

## 19 Calibrating O-DO sensors

---

## 20 Calibrating turbidity sensors

---

### 20.1 Important information



**WARNING!**

During the calibration, the relays and analog output signals assume the configured states!

### 20.2 General information

Turbidity sensors are calibrated by means of two-point calibration in distilled water and formazine reference solution. The sensor is calibrated ex works, meaning that no calibration is required before initial startup. If the measured values are seen to drift during operation, the sensor should be calibrated.

#### Preparatory cleaning

Rinse off the sensor with clear water. Organic deposits left on the sensor optics, such as a biofilm or silt, may cause measurement errors. These deposits should be removed carefully with warm soapy water and a soft sponge. Never use abrasive agents (e.g. scouring sponge)!

Calcium deposits can be removed by submersing the sensors in a diluted hydrochloric acid solution (**concentration max. 5 %**) for several minutes.

#### 20.2.1 Calibration methods for turbidity sensors

##### Two-point calibration

With two-point calibration, the zero point and slope of the sensor are calibrated. Distilled water is used as the test material for determining the zero point. Formazine is used as the test material for determining the second reference point. The zero point and calculated percent deviation from the ideal slope are saved as reference values.

## 20 Calibrating turbidity sensors

---

### 20.2.2 Calibration presets for turbidity sensors

Before you can perform a calibration, you must first enter the necessary calibration default settings. The possible settings for the calibration of turbidity sensors are described in the following.

Open the calibration default settings:  
Device Menu > Calibration > Digital Sensor 1 to 6 >  
Calibration Default Settings



**NOTE!**

The "Calibration default settings" menu appears in the Device menu only if a user with corresponding user rights is logged in.

⇒ Chapter 8.2.1 "Logon/Logoff", page 87

The calibration default settings enable the calibration routines to be accessed in the particular calibration menu.

Calibration routines that are not enabled are not visible in the calibration menu. You can enable the two-point calibration for turbidity sensors.

## 20 Calibrating turbidity sensors

### 20.3 Calibration routines for turbidity sensors


**NOTE!**

Turbidity sensors can be configured with automatic selection of the measuring range. Accordingly, calibrations must be performed for all "accessible measuring ranges".

**NOTE!**

You must be logged in with corresponding user rights to perform calibrations.  
⇒ Chapter 8.2.1 "Logon/Logoff", page 87

#### 20.3.1 Two-point calibration

Step	Action
1	Start the two-point calibration.  Device Menu > Calibration > Digital Sensor 1 to 6 > Two-Point Calibration
2	Enter one of the measuring ranges 1 to 4. Confirm the entry by pressing "OK"  
3	Clean the sensor and immerse it in the distilled water.
4	The device displays the current measured value of the distilled water. The user does not need to make any entries here.
5	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"
6	Immerse the sensor in a formazine reference solution. Its turbidity value should be approximately at the middle of the selected measuring range.
7	The device displays the current measured value of the formazine reference solution. Enter the actual turbidity value of the reference solution.
8	Wait until the measured value displayed stabilizes and then confirm the result of the measurement by pressing "OK"

## 20 Calibrating turbidity sensors

---

Step	Action
9	A protocol summarizing the calibration values determined then appears. Acknowledge the protocol by pressing "OK". Failed calibrations are canceled at this point and discarded.
10	Press "Yes" to accept the Calibration values determined and enter the Calibration in the Calibration logbook. Press "No" to discard the results.

**NOTE!**

Data transmission from and to the device requires that the following requirements be satisfied:

- The device must be powered on
- The device must be connected to the PC either via USB or Ethernet (see Chapter 21.7 "Connection to device", page 277)
- All windows on the user interface of the device must be closed; the device must be at the operating level

Configuration or parameter changes may not be made simultaneously on the device and with the JUMO PC setup program.

### 21.1 Generally

All configuration data and parameterization can be edited offline with the JUMO PC setup program. Entire device configurations can be loaded into the device, exported from the device and saved on a PC/laptop.

In addition, the software is needed for the following tasks:

- Editing of User names and user rights on the device  
⇒ Chapter 21.8.3 "User list", page 292
- Saving and deleting languages from the device  
⇒ Chapter 21.8.4 "Country settings", page 295
- Creating/editing device settings lists for the User level  
⇒ Chapter 21.8.6 "User level", page 303
- Creating/editing formula and logic formula  
⇒ Chapter 21.8.7 "Formula", page 304  
⇒ Chapter 21.8.8 "Logic formula", page 305
- Creating/editing value tables for customer-specific linearization  
⇒ Chapter 21.8.9 "Customer-specific linearization", page 306
- Editing of Buffer set tables for automatic buffer detection when calibrating pH sensors  
⇒ Chapter 21.8.10 "Buffer set tables", page 309
- Creating/editing Process screens  
⇒ Chapter 21.8.11 "Process screens", page 310
- Configuring the e-mail function  
⇒ Chapter 21.8.12 "E-mail", page 324
- Configuring the Webserver  
⇒ Chapter 21.8.14 "Web server", page 331
- Viewing calibration logbooks  
⇒ Chapter 21.9.1 "Calibration logbooks", page 333

# 21 PC Setup Program

---

## 21.2 Installing the JUMO PC setup program

### Hardware and software requirements

A PC satisfying the following requirements is necessary for installation and operation of the JUMO PC setup program:

- Operating system: Microsoft®<sup>1</sup> Windows 7®<sup>1</sup> (32-bit- and 64-bit version)
- Memory: 1 GB
- Available hard disk space: 1 GB
- DVD drive
- USB host interface
- LAN interface (Ethernet)



**NOTE!**

Close all applications on your PC before starting installation of the JUMO PC setup program.



### 21.2.1 Procedure

Step	Action
1	With the PC running, insert the CD supplied with the device into the drive and close it.
2	After the CD has been inserted, the installation program starts automatically; if this does not happen, proceed as follows: Start the "Launch.exe" file in the main directory of the CD.
3	The installation program guides you through the rest of installation accompanied by on-screen messages.

1. Microsoft and Windows 7 are registered trademarks of Microsoft Corporation.



## 21 PC Setup Program

Step	Action
4	<p>Read and confirm the license agreement. Acceptance of the agreement is a basic requirement for installation of the software.</p> 
5	<ul style="list-style-type: none"> <li>• <b>30-days test version or demo version</b> Activate the check box for the 30-days test version. The entry fields for the license number are filled in automatically.</li> <li>• <b>Full version</b> Insert the license key that you received from JUMO<sup>a</sup>.</li> </ul> 
6	<p>Select the program folder to which the links for starting the software art be copied. The directory for the program files is specified automatically.</p>
7	<p>Click the "Install" button and wait until the installation has completed.</p>

## 21 PC Setup Program

---

<sup>a</sup> To install the full version, you must acquire an appropriate license from JUMO. The contact data can be found on the back of this document.



### **NOTE!**

If the "30-days test version" option is selected during installation, the JUMO PC setup program is fully functional for 30 days. At the end of 30 days, the program switches automatically to a "demo version" where some functions such as data transmission, data storage and printing no longer work. The software can be licensed at a later date.

### **Program start**

Once installation is complete, you can start the PC setup program from the Windows®<sup>1</sup> Start menu.

## 21.3 Logging onto the setup program

The user name and password are not requested following initial installation of the setup program. In the "Extras" menu, the "Renew login / Change password" function can be used to activate this request when the program starts.

⇒ Chapter 21.6.3 "Extras", page 273

Activation of the login function can be used to distinguish between the users "Specialist" and "Service". The two users have different rights regarding access to functions of the PC setup program.

⇒ Chapter 21.3.1 "Rights in the setup program", page 259

If the prompt is active, the user must log on:

---

<sup>1</sup>.Microsoft and Windows 7 are registered trademarks of Microsoft Corporation.

## 21 PC Setup Program

### 21.3.1 Rights in the setup program

Depending on the version and login, individual users have different rights in the PC setup program.

The differences are summarized in the following table.

<b>Users</b> <b>User rights</b>	<b>Demo Version</b>	<b>Service</b>	<b>Specialist</b>
New	X	X	X
Open	X	X	X
Save, Save As, Delete		X	X
Delete undocumented parameters			X
Export data to external mass storage (USB flash drive)		X	X
Import data from external mass storage (USB flash drive)		X	X
Print		X	X
Activate program options	X		X
Activate extra codes			X
Edit interface settings		X	X
Edit device settings	X	X	X
Delete device			X
Create new device	X		X
Reset user list	X	X	X

# 21 PC Setup Program

---

## 21.4 QuickStart agent

### Installation

During installation of the PC setup program, an additional program with the description "QuickStart agent" is installed. This program starts automatically and appears as a symbol in the Windows taskbar.

Example:



- (1) "Show icons" button
- (2) Taskbar
- (3) QuickStart agent link

## 21 PC Setup Program

---

### Quick-start of programs

The QuickStart agent monitors removable media on the PC and responds if, for instance, a device or USB flash drive is connected to the PC. It lists all PC programs associated with the device found.

The user can decide which PC program should be started. This is done by highlighting the program in the list and then launching it by pressing the "Start" button. If there is only one program, it starts immediately.

Pressing the "Close" button switches the QuickStart agent to the background.

### Adjustments

The "Settings" button can be used to change the following QuickStart agent options:

- National language used by the QuickStart agent
- Selection of programs that can be started by the QuickStart agent
- Autostart of the QuickStart agent when starting the PC

### QuickStart agent in the foreground or background

Left- or right-clicking on the icon in the Windows taskbar opens a selection list. Here, the user has the option of bringing the QuickStart agent to the foreground or background by selecting the relevant entry in the list.

If autostart is inactive, i.e. the symbol does not appear in the taskbar, the QuickStart agent can be started manually from the Windows Start menu. The QuickStart agent is located in the same program group as the JUMO PC setup program.


### Ending the QuickStart agent

Selecting the entry "End" closes the QuickStart agent. It can be restarted from the Windows Start menu.

# 21 PC Setup Program

## 21.5 User interface

### 21.5.1 Elements of the user interface



- (1) Menu bar
- (2) Toolbar
- (3) Working area – navigation tree
- (4) Work area – Display window
- (5) Connection status
- (6) Online data

#### Menu bar

The individual functions of the PC setup program are launched from the menu bar.

⇒ Chapter 21.6 "Menu bar", page 269

#### Toolbar


The toolbar contains selected functions from the menu bar. These can be launched by left-clicking on them. Hovering the mouse pointer over one of the icons displays the name of the function after a few seconds.

# 21 PC Setup Program

---

## Moving the toolbar

The user can change the position of the toolbar:

Step	Action
1	Position the mouse pointer between two icon groups 
2	Left-click with the mouse button
3	While holding down the left mouse button, move the toolbar to the desired location
4	Release the left mouse button

Possible positions of the toolbar:

- Along the left or right window border (vertical alignment)
- Below the menu bar (horizontal alignment),
- Along the lower edge above the user information (horizontal alignment)
- Any position (its own window - any alignment by changing the window size)

## Closing the toolbar

If the toolbar was moved, it can be closed by clicking the cross at the right upper corner of the toolbar window. To display the toolbar again, it must be activated (set checkmark) in the "Standard Settings" menu under "User Interface".

File > Standard Settings

The toolbar that appears at the location to which it was previously moved.

## Work area

The working area consists of the navigation tree (at left) and the display window (at right)

and displays the current settings of a configuration file (setup file).

⇒ Chapter 21.5.3 "Editing the setup file", page 267

The way the working area is divided can be changed by moving the border between the navigation tree and display window sideways with the aid of the left mouse button.

## Connection status

The "Connection status" line indicates whether a connection to a device exists. In addition, some interface data are displayed, e.g., the IP address.

The "Window" menu can be used to show or hide the line.

The height of the line can be changed by moving the border of the online data window with the aid of the left mouse button.

# 21 PC Setup Program

---

## Online data

The "Online data" function displays current process data in the PC setup program.


The "Window" menu can be used to show or hide the online data window.

File > Online Data

The height of the window can be changed by moving the border of the working area or the "Connection status" line with the aid of the left mouse button.

## 21.5.2 Display protection

Display protection can be activated in the basic settings of a device setup file. To activate display protection, a password must be entered in the "Display protection" field.






## 21 PC Setup Program


---

When display protection is activated, all device settings in the PC setup program are concealed the next time the setup file is opened.



To show the device settings in the PC setup program again, double-click the entry "Display protection" in the display window or the navigation tree. Enter the display protection password in the following dialog. After the correct password has been entered, the entire device setup in the PC setup program appears again and can be edited.

# 21 PC Setup Program



# 21 PC Setup Program


## 21.5.3 Editing the setup file

In the "File" menu, create or open an existing setup file.

Create a new file:  
File > New

Open an existing file:  
File > Open

The working area (navigation tree and display window) shows the menu structure with the individual setting options for the JUMO AQUIS touch P from within the JUMO PC setup program.



(1) Navigation tree  
(complete menu structure of the  
PC setup program)

(2) Display window  
Pop-up overviews of the sub-  
menus with their configuration  
data

(3) Active setup window

(4) Inactive setup window

# 21 PC Setup Program

---

## Navigation tree

Left-clicking (once) on the entry "Project" or on a certain module displays the associated subitems in the display window. Clicking on the ("-") symbol closes a menu, clicking on the ("+") symbol opens a menu. Double-clicking on an entry (e.g. "Hardware configuration") opens a corresponding dialog for editing the individual configuration data. Alternatively, it is possible to access the individual menu levels via the "Edit" menu.

## Display window

Double-clicking on an entry in the display window opens a dialog for editing the corresponding configuration data. Clicking once on the right-arrow symbol preceding the entry lists the current settings in the display window. Clicking once on the down-arrow symbol hides the settings again.

## Setup window

If several setup windows are open simultaneously, clicking once on the name at the lower edge of the inactive window makes it the active window.

### 21.6 Menu bar

This chapter describes the menu bar functions. The order of the subchapters corresponds to the location of the menus in the menu bar (from left to right).

#### 21.6.1 File menu

##### **New**

Creates a new setup file in the working area. After selecting the "New" command, the user can select from the following options:

- **User-Defined Setting**  
Extra codes and optional boards can be selected for the new setup file. This option is used to create a new setup without having a device connected.
- **Automatic Detection**  
The configuration (extra codes and optional boards) of the connected device are written to the new setup file. If desired, the "Read setup file from device" checkbox can also be selected. The current configuration is then written to the new setup file from the device and is available for editing.  
This option is used to edit or create the setup for an existing or new device.

##### **Open ...**

Opens an existing setup file and displays the content in the working area.

##### **Save**

Saves the settings shown in the work area in a setup file. The file name must only be entered once. When the file is saved again, no prompt for the file name appears.

##### **Save as ...**

Saves the settings shown in the work area in a setup file. In contrast to the "Save" function, a prompt for the file name always appears in this case.

##### **Close**

Removes the settings shown in the work area from the work area and closes the Setup window. The user has the opportunity to save changes that have not yet been saved.

##### **Export as RTF**

Saves the current setting as an RTF file on the PC.  
This function is useful for documenting a device configuration.

##### **Print ...**

Prints the setup settings of the project or module (depending on the item highlighted in the navigation tree). The menus to be printed can be selected beforehand.

## 21 PC Setup Program

---

### **Print preview (page view) ...**

The print results are displayed on screen. Several pages can be displayed and the view can be scaled.

### **Printer setup ...**

Allows the printer settings to be changed. When a program starts, the Windows default printer is always used as the active printer.

### **Standard Settings ...**

Allows the default settings of the setup program to be changed. Many changes are not enabled until you restart the setup program.

### **Last Files ...**

Displays the file names of the setup files last saved. Clicking once on the file name opens the setup file or displays an already opened setup file as the active window.

### **End**

Quits the setup program. The user has the opportunity to save changes that have not yet been saved.

### 21.6.2 Data Transfer menu

#### **Establish Connection ...**

Opens the device connections list. The content of the device connections list is project-dependent. The device connections list contains all devices to which a connection can be established via the setup program. Devices can be added to or removed from the list. The settings for the connection are also made in the device connections list.

⇒ Chapter 21.7.1 "Device connections list", page 277

#### **Break connection ...**

Terminates all connections of the active project, i.e. the selected setup file.

#### **Data transfer to the device ...**

Sends the setup data to the device. An existing connection to the device is a requirement. If there is no connection, the device connections list is opened automatically.

#### **Data transfer from the device ...**

Reads the configuration from the device. An existing connection to the device is a requirement. If there is no connection, the device connections list is opened automatically.

## 21 PC Setup Program

---

### **Data Transfer to Ext. Medium ...**

Exports the setup file in SET format to external mass storage (USB flash drive). This file can be loaded directly into the device via the USB interface.

### **Data Transfer from Ext. Medium ...**

Imports a setup file in SET format from external mass storage (USB flash drive) into an open setup file. In this way, an SET file that was previously copied from the device to a USB flash drive can be opened for editing with the JUMO PC set-up program.

Detailed information on loading and saving SET files via the USB interface on the device:

⇒ Chapter 8.4 "Memory Manager (USB flash drive)", page 104



### 21.6.3 Extras

#### Activation of program options

Activates optional functions of the PC setup program (entry of additional license numbers). Using this function, the PC setup program can also be registered with a valid license number at a later date (30-days test version or full version) if a valid license number was not entered during the installation (demo mode).

#### Renew login / Change password

Opens a window to activate user login. After the JUMO PC setup program has been installed, prompts for the user name and password do not appear until user login has been activated. The user is initially logged in as "Specialist" with an empty password. This function activates the user and password prompt when the program starts and the current password is changed.

#### Text library...

Opens a window for editing the text library. The various operating languages for the device are saved in the text library. When a new setup file is generated, the languages are copied to the setup file. If necessary, they can be edited there in the "Country settings" menu. The order of the languages can be changed and also is observed during transfer to the setup file. The first two languages (language 1 and language 2) are transferred to the device and can be selected there. In various submenus, the "Language" button permits editing of the respective language.

⇒ Chapter "Language button", page 297

## 21 PC Setup Program

---

### Version library

Shows the content of the version library. The list contains the standard versions of the device software and the compatible hardware versions provided by the device manufacturer together with the PC setup program. Additional software versions that were imported subsequently (e.g. customer-specific versions) are also contained.

### 21.6.4 Windows

#### **Cascaded**

Arranges all open setup windows in an overlapping arrangement. Left-clicking on a window brings it to the foreground.

#### **Tiled**

Arranges all open setup windows in a tiled arrangement. Left-clicking on a window makes it the active window.

#### **Arrange icons**

Arranges the symbols for all minimized setup windows in the lower region of the user interface. This function has an effect only if a symbol was previously moved out of the lower region.

#### **Online data**

Alternately shows/hides the online data window. A checkmark preceding the menu item indicates that the window is shown.

#### **Connection status**

Alternately shows/hides the line for displaying the connection status. A check mark preceding the menu item indicates that the line is shown.

#### **Opened windows**

Displays the names of all opened setup files as a list. Clicking on the name in the list makes the associated window the active window. A check mark preceding the name indicates the active window.

## 21 PC Setup Program

---

### 21.6.5 Info

#### Setup info

Displays information about the setup program, incl. the version number. The version number is important, for instance, when contacting the service hotline.

#### Registered license numbers ...

Shows all registered license numbers and any active options. The license numbers and the information about active options are important, for instance, when contacting the service hotline.

#### Program folder ...

Shows the various folders (directories) that are being used on the hard drive or in the network by the setup program. Clicking on the button (to the right of the folder path) displays the content of the folder.

#### Memory info

Displays the memory information. The memory information is provided for diagnostic purposes. It is requested when needed by the device manufacturer's service technician.

### 21.7 Connection to device

This chapter describes the various ways to establish a connection between the JUMO PC setup program and the device. A connection is possible via:

- LAN interface (HTTP or HTTP proxy)
- USB interface




#### NOTE!

The USB interface is not intended for a permanent connection, since unintentional removal of the USB connector cannot be prevented due to the lack of a captive connection.

An existing connection is a requirement for data transfer between the JUMO PC setup program and system. In the menu bar, open:  
Data transfer > Establish Connection ...

#### 21.7.1 Device connections list

The device connections list contains all devices for which a connection has been configured. The user can add connections to new devices, change the properties of existing connections (interface parameters) as well as remove connections.



#### Connection settings assistant

The "Use connection settings assistant" function assists the user with creating a new entry, i.e. a new connection, and with editing existing entries. The assistant is always active after opening the device connections list (check mark set). It is started whenever a new entry is to be added to the device connection list.

⇒ Chapter 21.7.2 "Configuring the connection with the assistant", page 279

The assistant can be deactivated by removing the check mark. If a new entry is to be added to the device connections list then, the user must select the individual configuration steps on their own. If the device connections list is reopened, the assistant will again be active.

⇒ Chapter 21.7.3 "Configuring the connection without the assistant", page 286

#### Establishing a connection

If the user wishes to establish a connection (or start data transfer when

## 21 PC Setup Program






---

there is no connection), the PC setup program opens the device connection list. The user must first highlight the device concerned in the device connection list and then press the "Establish connection" button. If a device should not be connected, the corresponding dialog ("Device connection list" window) should be closed by means of the "Exit" button or by clicking the "X" at the upper right corner of the dialog window.

### Toolbar

The user has access to various functions via the toolbar for the device connections list.



Explanation	Button
New entry Creates a new connection entry	
Edit properties Opens a settings dialog for a connection	
Permanently remove entry Deletes a connection entry permanently	
Open connection Establishes a connection to the device highlighted in the list	
Exit Closes the device connections list	

### 21.7.2 Configuring the connection with the assistant

The connection settings assistant assists the user with configuring a new connection. The assistant is always active after opening the device connections list (check mark set). It is started whenever a new entry is to be added to the device connection list.

⇒ Chapter 21.7.1 "Device connections list", page 277




**NOTE!**

Configuring a new connection "with the assistant" is the preferred method. It can also be used by a user without expert knowledge.

# 21 PC Setup Program

## Setup dialog - Device and type of connection



### Adjustments

Setting item	Selection/ setting option	Explanation
Device version	Selection from dropdown list	Device version of the device to be connected ⇒ Chapter 8.2.4 "Device information", page 91
Connection pre-sets	Setup or ring memory via TCP/IP	LAN interface (HTTP protocol), connection to device in an intranet (or VPN)
	Setup or ring memory <sup>a</sup> via HTTP proxy	LAN interface (HTTP protocol), connection to device via proxy server and Internet
	Connection via USB	USB interface
Description	Text	Description of the connection
Define as default device in the device connection list	Checkboxes	Accesses a default device automatically, other devices must be connected via the device connections list.
Check whether a connection can be established	Checkboxes	With this option active, the program checks whether the selected device can be accessed via the selected interface upon completion of configuration.

<sup>a</sup> Ring buffer = Read out measurement data

After the user clicks on the "Next" button, the assistant opens the next setup dialog.



## Setup dialog - Device login



## Adjustments


Setting item	Selection/ setting option	Explanation
Do not log in	Checkboxes	Activate option (set checkmark) if connection to the device takes place without login. Without logging in, some functions probably will not be available. The deciding factor is the authorizations that have been defined for a user who has not logged in. ⇒ Chapter 8.1.1 "Passwords and user rights", page 73
Save ID and password	Checkboxes	Saves the user ID and password for automatic login to the device when establishing a connection the next time
User ID	Text	User name for device login
Device password	Text (is hidden during entry)	Password for device login

After the user clicks on the "Next" button, the assistant opens the next setup dialog.

# 21 PC Setup Program

## Setup dialog - TCP/IP port settings

This dialog depends on the selected connection preset. The figure shows the case "Setup or ring buffer via HTTP proxy". Except for the parameters "Proxy" and "Proxy Port", the description applies also for the case "Setup or ring buffer via TCP/IP".



### Adjustments

Setting item	Selection/ setting option	Explanation
Device: IP address / Host name	Enter IP address or name. Or click on the "Search" button and select the device from the list by dou- ble-clicking on it.	IP address or host name of the device  The search function (telescope button) finds all devices on the local network and displays them in a selection list. ⇒ Chapter 21.7.4 "Searching for a device in the network", page 288
Check and change host name	Open by pressing the button	Button to change the host name into the IP address of the device. All host names regis- tered to an address as well as alternative addresses are displayed when appropriate
Device: Port number-/ Port name	The port number and port name can be changed only in the expanded settings (see below).	Port number or port description of the device  Default port: 80
Extended	Open by pressing the button	Advanced settings for communication These settings should be changed only in unusual circumstances.

## 21 PC Setup Program


After the user clicks on the "Next" button, the assistant opens the next setup dialog.

### Setup dialog - Overview of the settings

To complete the configuration, the user is presented with an overview of the settings. If the "Connection via USB" connection setting was selected, this overview appears immediately after the "Device Login" dialog, since normally no settings are required for the USB connection or only a device of the same type is connected.

⇒ Chapter "Setup dialog - USB interface settings on the PC", page 284

An incorrect setting can be corrected by pressing the "Exit" button to reopen the setup dialog concerned and making the correction there. Clicking on the "Finish" button closes the assistant and enters the new connection in the device settings list.




# 21 PC Setup Program

## Setup dialog - USB interface settings on the PC

If several devices are connected via a USB interface, one device must be selected here. Furthermore, various test criteria can be activated so that the connection to the device is established only after a successful test.

This dialog depends on the selected connection preset. The figure shows the case "Connection via USB". To access this dialog, it is necessary to click on the "Next" button twice – starting from the "Device Login" dialog – while holding down the "Ctrl" + "Shift" keys.



### Adjustments


Setting item	Selection/ setting option	Explanation
Connected devices	Selection from dropdown list	Devices connected via the USB interface are displayed.
Name	Text (entry field active only when checkbox activated)	With checking active, the device is connected only if the device name matches.
Ser. No.		With checking active, the device is connected only if the device serial number matches.
CPU		With checking active, the device is connected only if the serial number of the CPU matches.
Path		With checking active, the device is connected only if the USB path matches.
Extended	Open by pressing the button	Extended settings for communication These settings should be changed only in exceptional situations.

Clicking on the "Finish" button closes the assistant and enters the new connection in the device connections list.

## Setup dialog - Overview of the settings

## 21 PC Setup Program

To complete the configuration, the user is presented with an overview of the settings. An incorrect setting can be corrected by pressing the "Exit" button to re-open the setup dialog concerned and making the correction there.



Clicking on the "Finish" button closes the assistant and enters the new connection in the device connections list.

# 21 PC Setup Program

## 21.7.3 Configuring the connection without the assistant

The assistant can be deactivated in the device connections list (remove the checkmark).



⇒ Chapter 21.7.1 "Device connections list", page 277

During configuration, the user is not guided to the next step - as with an active assistant - but instead must select the individual steps of the configuration on their own. The following example shows the basic procedure. The parameters in the individual setup dialogs are largely the same as when configuring with an assistant so that a description is not provided here. However, additional protocols and interfaces are available for the settings used to establish communication.




**NOTE!**

Configuring a new connection "without the assistant" requires expert knowledge and is provided only for service purposes.

Step	Action
(1)	<p>Make the settings for the new device and click on "Interface"</p> 
(2)	<p>Make the login settings and click on "Properties"</p> 


## 21 PC Setup Program

Step	Action
(3)	<p>Make the protocol and interface settings and click on OK. If necessary, click on the "Extended" button beforehand to make additional settings for communication.</p> 
(4)	<p>Close all previously opened setup dialogs (windows) by clicking on the "OK" button. When the last setup dialog closes, the new connection is entered in the device connections list.</p>


# 21 PC Setup Program

## 21.7.4 Searching for a device in the network

This function assists the user with selecting the IP address or the host name for the device of interest. A "Search" button is located to the right of the entry field in the dialog for entering the IP address or host name.




Clicking on this button automatically finds all potentially suitable devices in the local network and displays them in a list.



The listed devices are located in the same subnet as the PC from which the search was initiated. Specifying the software version in the "SW Base" field limits search to specific devices and versions.

If devices in a different subnet are to be searched, the address range of the device must be known. This address range must be entered into the field "IP-Adr.". The first 3 bytes of the IP-address must be known, only the last byte can be entered as the range (e.g. 10.13.3.50-150).




The device concerned can be highlighted with the mouse pointer (by clicking on the cell) and accepted by pressing **OK** (or by double-clicking on the cell). This



## 21 PC Setup Program

---

enters the host name (DNS name) in the input field.



You can use the "Check and convert host name" function to establish the IP address and transfer it to the input field (subsequent editing may be necessary in the input field). Depending on the version, there may be an option to select the host name or IP address from a dropdown list.

## 21 PC Setup Program

---

### 21.8 Setting up the device with the JUMO PC setup program

#### 21.8.1 Identification


##### Identifying the device version

All configuration data and the hardware installed in a connected or network-accessible device can be read and displayed here. In addition, the hardware installed in a device can be specified manually in order to create a setup file for a device that is not connected (e. g. a planned new device).

This function is accessed in the navigation tree of the work area by double-clicking on:

Identification > Device Version

A window opens where you must select whether you wish to import the option boards installed in a connected device into a new setup file (Automatic Detection), or manually enter the hardware configuration data for a new setup file (User-defined Settings).




In the next window, you select the device for which the setup file is being created/exported:

- Surface-mount device (JUMO AQUIS touch P)
- Control cabinet device (JUMO AQUIS touch P)

## 21 PC Setup Program

After you have selected the desired device and clicked the "Next" button, the graphical overview showing the installed option boards opens. If "User-defined settings" was selected, the option boards installed can be manually specified for the setup file here. In this case, use drag and drop to select the desired option board symbols from the menu bar above and place them on the intended expansion slots marked in green. The expansion slots available for installation are marked in green while dragging. If "Automatic detection" was selected, the menu bar with option board symbols is not available; instead, the actual configuration of the device read is displayed.



Clicking on the "Next" button opens a dialog window where you can activate extra codes for the setup file:

- Math/Logic
- Recording
- Digital sensors

Activate the extra codes that you wish to configure in the setup file. When you wish to transfer the created setup file to a device, you must activate the selected extra codes for this device.

⇒ Chapter 21.10.4 "Enabling of extra codes", page 337

# 21 PC Setup Program

---

## Connection diagram

A graphical connection diagram is saved here. The JUMO PC setup program reads which option boards are installed and the pin assignment from the configuration data in the setup file. The connection diagram can be printed out and used for wiring the device associated with the setup file. Double-clicking on the "Connection Diagram" menu opens a dialog in which the margins for the connection diagram printout can be set. The contents of the title block below the connection diagram can either be synchronized with the information in the "File Info" menu, or filled in with your own text. If the option "Synchronize Texts with File Info Header" has been activated in the settings dialog for the connection diagram, this file info is displayed there and can also be edited here.

### 21.8.2 Configuring and parameterizing

All parameters at the configuration level and the parameter level can be set both on the device itself and with the JUMO PC setup program.

⇒ Chapter 10 "Configuration", page 129

⇒ Chapter 9 "Parameterization", page 123

### 21.8.3 User list


The factory-entered user names, passwords, and user rights (see Chapter 8.1.1 "Passwords and user rights", page 73) can be changed with the JUMO PC setup program.

Configuration point	Selection/ setting option	Explanation
Password rules	Password rules	The re-authentication time can be set here. This time counts down as soon as the user has logged in to the device. Once this time elapses, the logged-in user is logged off automatically. If the re authentication time is set to a value of 0 s, re-authentication is inactive. The user then remains logged in for the entire length of the session. ⇒ Chapter 8.2.1 "Logon/Logoff", page 87
Character table	⇒ "Character table for passwords", page 293	Character set available for passwords
Public rights	⇒ "Configuring public Rights", page 294	User rights for users who are not logged in
ID	up to 10 text characters	User name for user login
Description	up to 30 text characters	Name of the user account
Password	up to 10 text characters	Password for user login
Rights	⇒ "Configuring public Rights", page 294	User rights for each individual user account

## 21 PC Setup Program

### Character table for passwords

Characters for user login can be added or changed in character tables 5 to 16. Character tables 1 to 4 cannot be changed.



- (1) Classification selection field
- (2) Visualization of the keyboard layout in the Device menu
- (3) Entry field for character set
- (4) Header character set for labeling the tab in the device settings menu
- (5) Table 1 to 16 selection field  
for selecting the character table to be edited

To add password characters, select an editable character table 5 to 16 (5) and enter the desired characters as a string without spaces in the entry field (3). The new or modified character table is available on the device for changing passwords. The tab label for the virtual keyboard in the device settings menu is entered in the "Header char. set" field.


# 21 PC Setup Program

## Configuring public Rights

The access rights for all users who are not logged in are set here.

Open Settings:

Only Setup > User List > Public Rights



## 21 PC Setup Program


### Configuring user rights

The user rights for each individual user account are set here. A corresponding user login is required to exercise the respective user rights.

- ⇒ Chapter 8.1.1 "Passwords and user rights", page 73
- ⇒ Chapter 8.2.1 "Logon/Logoff", page 87

Open Settings:


Only Setup > User List > Rights



### 21.8.4 Country settings

The country settings (language and country-specific settings such as date format and decimal point) are taken from the text library by the setup program when creating a setup file. A country setting can be moved to another position in the list ("Sort language"). The country settings in the list are sent to the device and are available there for changing the language.

# 21 PC Setup Program



Setting item	Selection/ setting option	Explanation
Specification	No entry possible Assigned automatically	Internal Specification (only for service purposes to identify the language)
National language	Use factory-set text or enter a different text	Description of the language
Date format	DDMMYYYY MMDDYYYY YYYYMMDD	Display format for the date
Decimal character	The following characters are possible: . ,	e. g. "comma" for German number format or "Point" for American
Separator (date)	The following characters are possible: . , ; - / \	Separator for configuring the date format
Separator (time)	The following characters are possible: . , ; - / \	Separator for configuring the time format
Character entry	2 characters  1st standard character (e. g. lower-case letter)  2nd with Shift key (e. g. upper-case letter)	The assignment of characters to the individual keyboard fields of the virtual on-screen keyboard of the device can be changed here if necessary. ⇒ Chapter 21.8.5 "Device character set", page 301



## 21 PC Setup Program

---

### Language button

Languages can be created, edited, and deleted with the "Language" button. New languages can be created on the basis of already existing languages. Available languages as well as languages from libraries can be selected as a template for new languages in the open setup. It is further possible to import available languages from a saved setup file as the new language. In this way, it is possible to transfer languages from one device to other devices with the aid of a device's setup file

### Creating a new language

#### From an available language in the PC setup program

Step	Action
(1)	Open Country Settings: Only Setup (double-click) > Country Settings (double-click)
(2)	Select and highlight a language as the template
(3)	Copy the selected language: Button "Language" > New Language > Create
(4)	The new language can now be edited and loaded into the device with the next data transfer.

#### From an available language in a saved setup file

Step	Action
(1)	Open Country Settings: Only Setup (double-click) > Country Settings (double-click)
(2)	Select setup file for language import: Button "Language" > New Language > From Setup File
(3)	Select and open desired setup file in Explorer
(4)	Set checkmark in the checkbox for the selected language and accept
(5)	The new language can now still be edited if necessary and loaded into the device with the next data transfer

## 21 PC Setup Program

---

**From a language in the current library (internal library of the JUMO PC set-up program)**

Step	Action
(1)	Open Country Settings: Only Setup (double-click) > Country Settings (double-click)
(2)	Open the current library: Button "Language" > New Language > From Current Library
(3)	Set checkmark in the checkbox for the selected language and accept
(4)	The new language can now still be edited if necessary and loaded into the device with the next data transfer

**From a language in another library (library file stored on the hard drive)**

Step	Action
(1)	Open Country Settings: Only Setup (double-click) > Country Settings (double-click)
(2)	Select the library file: Button "Language" > New Language > From Another Library
(3)	Select and open desired library file in Explorer
(4)	Set checkmark in the checkbox for the selected language and accept
(5)	The new language can now still be edited if necessary and loaded into the device with the next data transfer

# 21 PC Setup Program

## Editing languages




### NOTE!

Standard languages cannot be edited.

Only languages created by the user can be edited with the JUMO PC setup program.

⇒ Chapter "Creating a new language", page 297

The following figure shows the source language text on the left and the target language text on the right. "Source language" dropdown list: Selection of the language in the left column. This language cannot be edited. "Target language" drop-down list: Selection of the language in the right column. Editing possible only in this column.



Texts displayed in red characters on a white background have not yet been edited (equivalent to not translated). The other forms of display are listed below in the "Toolbar" section. To change a text, it is only necessary to left-click once in the text field. The selected field is then displayed with a black frame. If the text has been changed, it appears in black characters on a white background upon leaving the field. The text is then considered edited (translated).



### NOTE!

Static texts, e. g. the names of parameters that are too long to be displayed on the screen of the device, are automatically shortened in the menus ("..."). However, in the dialog window for setting the parameter concerned, the text is displayed in its full length. Texts should generally be kept as short and clear as possible. Longer texts that appear in the same menu should already differ at the beginning of the text.

# 21 PC Setup Program

## Toolbar

The toolbar gives the user access to various functions for editing text.



Explanation	Button
Search text	
Replace text with other text	
Use filter to reduce the number of texts in the list	
Sort texts alphabetically	
Display text ID (instead of Row number)	
Mark text as "not edited closed votes (red text)	
Mark text as "to be checked" (blue text)	
Mark text as "edited" (translated) (black text)	
Bookmark text	
Open next entry with a bookmark	
Write-protect text (gray background)	

## Errors during Text input


Errors that occur during Text input are signaled by a colored background.

Explanation	Background
Too little memory space available. The total number of characters in a text is too large and must be reduced (shorten text).	Blue
The entered text is too long; it does not fit in the window provided.	Yellow
The text entered contains characters that cannot be displayed on the device.	Violet
Errors while editing a placeholder (#). The "#" symbol serves as a placeholder. Text is generated automatically by the device software at the location of the placeholder. Example: "Device ID #1.100". "Device ID" may be changed, "#1.100" <b>not</b> .	Brown

# 21 PC Setup Program

## 21.8.5 Device character set

When creating a new language, it is also possible to specify the characters available on the device for Text inputs (virtual keyboard).



- (1) Entry field for character selection  
The characters that are entered here are offered for selection by the virtual keyboard on the device later upon pressing the corresponding key.
- (2) Selection on the device keyboard  
In the example, the key for the plus sign was pressed on the virtual device keyboard.

## 21 PC Setup Program

---

To edit the character set for the device keyboard, proceed as follows:

Step	Action
(1)	Left-click the virtual key in the "Character entry" field (example: "+"). The characters assigned to the key appear in the text field. The first character from the left corresponds to the key identifier.
(2)	Change the key assignment in the text field as necessary (if invalid characters are entered, the background changes to violet).

# 21 PC Setup Program

## 21.8.6 User level


The user-defined parameter and settings list at the User level of the Device menu are created in this menu.

Explanation of the User level:

⇒ Chapter 8.2.2 "User level", page 88

Open Settings:

Only setup > User level



# 21 PC Setup Program

## 21.8.7 Formula


Formula must be created with the JUMO PC setup program. During data transfer to the device, the formula are then loaded into the JUMO AQUIS touch P together with the setup. For formula that have already been loaded into the device, the configuration data below the formula entry field can also be set on the device as an alternative.

Explanation of the configuration data for "Formula":

⇒ Chapter 10.19 "Formula", page 179

Open Settings:

Only Setup > Formula > Formula 1 to 8



To create formula, open the Formula Editor by pressing the button. With the aid of the Formula Editor, you can select variables from the analog and binary selectors as well as available operators to add them to the mathematical expression in the text window by pressing the corresponding "Add" button.

If necessary, the formula can also be edited by entering characters with the keyboard.



# 21 PC Setup Program

## 21.8.8 Logic formula


Logic formula must be created with the JUMO PC setup program. During data transfer to the device, the formula are then loaded into the JUMO AQUIS touch P together with the setup. For formula that have already been loaded into the device, the description below the formula entry field and the alarm configuration can also be set on the device as an alternative.

Explanation of the configuration data for "Logic formula":

⇒ Chapter 10.20 "Logic formula", page 180

Open Settings:

Only Setup > Logic Formula > Formula 1 to 30



To create formula, open the Formula Editor by pressing the button. With the aid of the Formula Editor, you can select variables from the Binary selection as well as available operators in order to add them to the logic expression in the text window by pressing the corresponding "Add" button.

If necessary, the formula can also be edited by entering characters with the keyboard.

# 21 PC Setup Program


## 21.8.9 Customer-specific linearization

Value tables and formula for customer-specific linearization must be created with the JUMO PC setup program. During data transfer to the device, the linearization is then loaded into the JUMO AQUIS touch P together with the setup. After the linearizations have been loaded into the device, they can be used when configuring the following types of analog inputs:

- Universal inputs with a standard signal (except pH/T-compensated chlorine measurement)  
⇒ Chapter 10.5.2 "Universal inputs of base unit and optional boards", page 137
- Temperature inputs for RTD temperatures probes with a customer-specific characteristic curve (up to 400 Ω, 4000 Ω or 100 kΩ)  
⇒ Chapter 10.5.1 "Base unit temperature inputs", page 135
- Analysis measuring inputs for electrolytic conductivity  
⇒ Chapter 10.5.5 "CR/Ci measuring ranges", page 143





Open Settings:

Only Setup > Customer-Specific Linearization > Tabs 1 to 8



## 21 PC Setup Program


### Symbol buttons – Basic values table

"Insert line" Inserts a new line above the highlighted line <sup>a</sup>	
"Delete line" Deletes the highlighted line from the Basic values table <sup>a</sup>	
"Delete table" Delete all entries in the Basic values table	
"Generate formula" Generates an approximation formula from the values in the basic values table	

<sup>a</sup> Lines are highlighted by clicking the Row numbers.

### Display graphic

The linearization characteristic curve is displayed by tapping the "Display graphic" button. By entering the "Lower limit" and "Upper limit" and then pressing the "Update" button, the display range of the Measuring value axis can be specified.



## 21 PC Setup Program

### Settings for customer-specific linearizations 1 to 8

Setting item	Selection/ setting option	Explanation
Description	up to 15 text characters	Linearization name
Linearization type	Grid points Formula	Way of entering linearization data  In order to display a measurement characteristic curve, the customer-specific linearization can be entered as a value table with discrete value pairs or as a formula (fourth-degree polynomial).
Start measur. range	-99999 to +99999	<b>only with "Formula" as "Linearization type":</b> Value range limits for the Y-column  The signal values from the sensor (X-values) are converted by the formula to values of the process variable (Y-values). The Y-values function as measuring values for input at the analog inputs of the AQUIS touch P.
End measur. range		
Grid points	Table with discrete value pairs	<b>only for "Supporting values" as "Linearization type":</b> Entry of discrete value pairs of a measurement characteristic curve  The signal values from the sensor can be entered in the X-column of the values table and the associated values of the process variable in the Y-column. The intervals between two value pairs are calculated internally by linear interpolation. The Y-values function as measuring values for input at the analog inputs of the AQUIS touch P.
Formula	Coefficients of a 4th degree polynomial	<b>only with "Formula" as "Linearization type":</b> Approximation formula for displaying a measurement characteristic curve  Formula are entered as a fourth-degree polynomial and used to convert the signal values from the sensor (X-values) into the corresponding values of the process variable (Y values). The Y-values function as measuring values for input at the analog inputs of the AQUIS touch P. The "Generate formula" button can be used to generate an approximation formula on the basis of the Basic values entered in the table.

# 21 PC Setup Program

## 21.8.10 Buffer set tables

Three buffer set tables are created in the JUMO AQUIS touch P. Buffer set tables are needed for calibration of pH sensors when using automatic buffer detection.

⇒ Chapter 13 "Calibrating a pH measuring chain", page 199


These Buffer set tables can be changed as often as necessary here.

The factory settings for the Buffer set tables are as follows:

- **Buffer set 1:** Reference buffer solutions for calibrating pH measuring instruments acc. to DIN 19266
- **Buffer set 2:** Technical buffer solutions, preferably for calibrating and adjusting technical pH measuring instruments acc. to DIN 19267
- **Buffer set 3:** No data

Open Settings:

Only Setup > Buffer Set Tables > "Buffer Set Table 1 to 3" tab



The screenshot shows a software window titled "Buffer set tables" with three tabs: "Buffer set table 1", "Buffer set table 2", and "Buffer set table 3". The "Buffer set name:" field is set to "Buffer set 1". Below this is a table with 12 rows and 7 columns. The columns are: "Temperature °C", "Buffer value 1 pH", "Buffer value 2 pH", "Buffer value 3 pH", "Buffer value 4 pH", "Buffer value 5 pH", and "Buffer value 6 pH". The table contains the following data:

	Temperature °C	Buffer value 1 pH	Buffer value 2 pH	Buffer value 3 pH	Buffer value 4 pH	Buffer value 5 pH	Buffer value 6 pH
1	0.0 °C	1.67	4.01	6.95	9.46	13.42	
2	10.0 °C	1.67	4.00	6.92	9.33	13.00	
3	20.0 °C	1.67	4.00	6.88	9.23	12.63	
4	25.0 °C	1.68	4.01	6.86	9.18	12.45	
5	30.0 °C	1.68	4.01	6.85	9.14	12.29	
6	40.0 °C	1.69	4.03	6.84	9.07	11.98	
7	50.0 °C	1.71	4.06	6.83	9.01	11.70	
8	60.0 °C	1.72	4.09	6.84	8.96	11.45	
9	70.0 °C	1.74	4.13	6.84	8.92	11.21	
10	80.0 °C	1.77	4.16	6.86	8.89	10.99	
11	90.0 °C	1.79	4.20	6.88	8.85	10.79	
12	95.0 °C	1.81	4.23	6.89	8.83	10.69	

At the bottom right of the window are "OK" and "Cancel" buttons.

# 21 PC Setup Program

---

## 21.8.11 Process screens

A "Process screen" can be created in the Operation loop of the JUMO AQUIS touch P in order to design a dynamic overview display of a system or a process. The Process screen must be created with the JUMO PC setup program and loaded into the JUMO AQUIS touch P together with the configuration.

Components of the Process screen:

- **Background color:** Selectable color of the background  
⇒ "Background color", page 314
- **Background:** Any image in bitmap format  
(the dimensions of the Process screen are 316 × 182 pixels)  
⇒ "Background", page 315
- **Objects:** Graphical elements for visualizing the operating state of the equipment in a system (e.g. pumps, valves, heating elements etc.)  
⇒ "Objects", page 317



**NOTE!**

Operation screens can be shown/hidden in the configuration. Check the Process screen setting in the configuration.

Device Menu > Display > General > Display Process Screen


Open Settings (Process screen Editor):

Only Setup > Process Screens (double-click) > "Process screen 1" tab

# 21 PC Setup Program

## Process screen editor

Process screens for the JUMO AQUIS touch P must be created with the JUMO PC setup program. These are then transferred from the PC to the device together with the setup.











- (1) Description of the Process screen (appears in the title bar of the Process screen)
- (2) Setting for the background color of the Process screen
- (3) Buttons for editing objects in the Process screen  
⇒ "Process screen Editor buttons", page 312
- (4) Object list with 50 objects  
The list shows all 50 objects. The objects can be configured, formatted, and activated with the editor. Objects shown as "Off" are not active in the Process screen. Objects with higher numbers cover objects with lower numbers in the Process screen.
- (5) "Preview" button  
Opens the preview window with the concept for the Process screen  
⇒ "Preview", page 313
- (6) Background  
Clicking this button opens a dialog for selecting an image from the image list.  
It is also possible to import user-defined images into the image list.  
⇒ "Background", page 315
- (7) The "Active" option is used to activate and display the screen with the Process screen in the Operation loop.

## 21 PC Setup Program

---

### Process screen Editor buttons

"Cut" Copies the highlighted object to the clipboard and deletes it from the list	
"Copy" Copies the highlighted object to the clipboard	
"Insert" Inserts an object from the clipboard at the highlighted position in the list; the highlighted object and all objects below it are shifted downward	
"New" Inserts a new object at the highlighted position in the list, the highlighted object and all objects below it are shifted downward	
"Remove" Removes the highlighted object from the highlighted position in the list; objects below it are shifted upward	
"Move up" Moves the highlighted object up one position in the list (corresponds to moving to the back in the Process screen)	
"Move down" Moves the highlighted object down one position in the list (corresponds to moving to the front in the Process screen)	
"Edit" Opens a dialog for editing the highlighted object ⇒ Chapter "Objects", page 317	



## 21 PC Setup Program


### Preview

The "Preview" button in the Process screen Editor opens the preview. The concept for the Process screen can be viewed here. The Process screen is displayed as it will appear later on the device.







Objects can be repositioned via drag and drop. The size of object can be changed by dragging the corners and edges.

Using the buttons in this window, objects can be repositioned, aligned with one another, formatted, and simulated.

The X-position axis runs from left to right; the Y-position axis from top to bottom. The origin of the coordinate system is the top left edge of the Process screen.








### Buttons in the preview

"Frame type" Changes the frame format of a framed object	
"Font size" Changes the font size in an object with text	
"Alignment" Changes the alignment of the lettering in objects with text	
"Object type" Changes the orientation of the object (horizontal/vertical)	
"One step forward" Moves an object on the graphic levels one step forward	
"One step back" Moves an object on the graphic levels one step back	

## 21 PC Setup Program

---

"Move" Opens a window with arrow buttons from moving objects one step at a time  Single arrow: Move by 1 pixel Double arrow: Move by 10 pixels	
"Align left" Simultaneously aligns several highlighted objects along the left edge of the object highlighted first <sup>a</sup>	
"Align right" Simultaneously aligns several highlighted objects along the right edge of the object highlighted first <sup>a</sup>	
"Align top" Simultaneously aligns several highlighted objects along the top edge of the object highlighted first <sup>a</sup>	
"Align bottom" Simultaneously aligns several highlighted objects along the bottom edge of the object highlighted first <sup>a</sup>	

<sup>a</sup> Several objects can be highlighted simultaneously by holding down the Shift key and left clicking with the mouse.

### Background color

The background color on the level behind all objects and the background image can be selected in the Process screen Editor.


### Background

The next level in front of the background color level is reserved for the background. Any image in the image list can be selected and displayed here in front of the background color level.

User-defined images can be imported into the image list. The images must be created in bitmap format. The dimensions of the Process screen are 316 × 182 pixels.

Open the "Background" dialog:

Only Setup > Process Screens > "Process screen 1" tab > "Background" button



(1) "Image List" button

This button opens a further dialog that is used to select an image as the background, and to import/export user-defined bitmaps into the image list.

⇒ "Selecting an image as the background", page 315

⇒ "Importing/exporting images", page 316

(2) Show/hide the background in the Process screen to provide a better overview of the objects in the Process screen during editing

(3) Center the background in the Process screen (the "Center" option has higher priority than the coordinate information)

(4) X-coordinate of the top left corner of the background image

(5) Y-coordinate of the top left corner of the background image

### Selecting an image as the background

Step	Action
1	Open the image list  Only Setup > Process Screens > "Process screen 1" tab > "Background" button > "Image List" button
2	Highlight the desired image in the list
3	Confirm by pressing "OK"


## 21 PC Setup Program

### Importing/exporting images

Step	Action
1	Open the image list  Only Setup > Process Screens > "Process screen 1" tab > "Background" button > "Image List" button
2	<b>Import:</b> Highlight an image in the list that you wish to overwrite with the new one and click the "Replace" button.  <b>Export:</b> Highlight an image in the list that you wish to export and click the "Replace" button.
3	<b>Import:</b> In the Explorer window, select the new image file and click on "Open".  <b>Export:</b> In the Explorer window, select the location where you wish to save the exported image, enter a file name and click on "Save".
4	The import/export process is now complete. You can close all windows that were opened in step 1 by pressing "OK" or "Cancel".

**Tip:** We recommend that you create an image that contains all static elements of your system representation and then use this as the background. The next step, all dynamic visualization elements are placed at the intended locations in the Process screen in the form of objects (e.g. pictograms for valves and pumps or analog displays).

**Example:** A Process screen for a CIP system is needed. In the first step, the representation of all static elements (pipes, tanks etc.) is created as a bitmap. The bitmap is imported into the image list and selected as the background. In the next subchapter (Chapter "Objects", page 317), objects are added to the sample Process screen.



### Objects

The object list of the Process screen Editor contains 50 empty objects. Double-clicking on an entry or clicking the "Edit" button in the Process screen Editor opens a dialog for configuring, designing, and formatting the corresponding object in detail. For greater clarity, the size, location in the Process screen, type, and visibility are shown in the list for each object.

The object number in the object list is also the display priority of an object. Objects with higher object numbers cover those with lower object numbers.

The buttons in the Process screen Editor can be used to copy, cut, insert, move, and delete object list entries.

⇒ Chapter "Process screen Editor buttons", page 312

### Object types

#### Pictograms:

A binary signal has two images associated with it. Depending on the value of the binary signal, one of the two images is displayed.

Example: An indicator light needs to be visualized. The image of a green indicator light is displayed for "TRUE" and a gray image (light off) is displayed for "FALSE".

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Digital signal	Selection from the binary selector	Binary signal for switching between the two images configured (see the following two lines)
Image Digital signal = TRUE	Selection from the image list	Image displayed when the binary signal = "TRUE" (on-signal)
Image Digital signal = FALSE	Selection from the image list	Image displayed when the binary signal = "FALSE" (Off-signal)

## 21 PC Setup Program

---

### Analog signals:

The numerical value of an analog signal is displayed in the Process screen.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Analog signal	Selection from the analog selector	Analog signal source whose value is to be displayed
Background color	Selection from color palette	Background color of the analog display
Transparent	Checkmark in the checkbox	Hide the background color; only the numeric display is visible
Frame type	None Fine Bold Upper case Lower case	Selection of a frame format
Foreground color	Selection from color palette	Font color of the numeric display
Font size	12/13/15/24/33/37/48/ 64 pixels	Font size in the numeric display
Alignment	Left align Right align Centered	Character alignment in the numeric display
Object type	horizontal vertical	Orientation of the analog display
Decimal place	Auto, Fixed comma format	Decimal points in the display

## 21 PC Setup Program

### Digital signals:

A binary signal has two plain texts associated with it. Depending on the value of the binary signal, one of the two plain texts is displayed.

Example: A manual / automatic selector switch needs to be visualized. Depending on the switch position, either "Manual mode" or "Automatic mode" text is displayed.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Digital signal	Selection from the Binary selection	Binary signal source for the Digital display
Background color	Selection from color palette	Background color of the analog display
Transparent	Checkmark in the checkbox	Hide the background color; only the numeric display is visible
Frame type	None Fine Bold Upper case Lower case	Selection of a frame format
Color (low)	Selection from color palette	Font color for binary value = 0
Text for low	up to 30 text characters	Text for binary value = 0
Color (high)	Selection from color palette	Font color for binary value = 1
Text for high	up to 30 text characters	Text for binary value = 1
Font size	12/13/15/24/33/37/48/ 64 pixels	Font size in the numeric display
Alignment	Left align Right align Centered	Character alignment in the numeric display
Object type	horizontal vertical	Orientation of the analog display

## 21 PC Setup Program

---

### Universal display:

Display of configuration settings, e.g. units or identifiers of an internal analog signal source for the JUMO AQUIS touch P.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Analog signal	Selection from the analog selector	Analog signal source whose value is to be displayed
Background color	Selection from color palette	Background color of the analog display
Transparent	Checkmark in the checkbox	Hide the background color; only the numeric display is visible
Frame type	None Fine Bold Upper case Lower case	Selection of a frame format
Foreground color	Selection from color palette	Font color of the numeric display
Font size	12/13/15/24/33/37/48/ 64 pixels	Font size in the numeric display
Alignment	Left align Right align Centered	Character alignment in the numeric display
Object type	horizontal vertical	Orientation of the analog display
Display type	Description Scale start Scale end Unit Limit value alarm 1 Limit value alarm 2 Window range alarm 1 Window range alarm 2	Selection of the configuration setting for the selected analog signal that is to be displayed



## 21 PC Setup Program

### Text:

Plain text for labeling of visualization elements.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Background color	Selection from color palette	Background color of the analog display
Transparent	Checkmark in the checkbox	Hide the background color; only the numeric display is visible
Frame type	None Fine Bold Upper case Lower case	Selection of a frame format
Foreground color	Selection from color palette	Font color of the numeric display
Font size	12/13/15/24/33/37/48/ 64 pixels	Font size in the numeric display
Alignment	Left align Right align Centered	Character alignment in the numeric display
Object type	horizontal vertical	Orientation of the analog display
Text	up to 30 text characters	Plain text for the identification field

### Frames and rectangles:

Design elements for emphasizing or delimiting visualization elements of the Process screen. Rectangles are always transparent for objects. Every object is visible at all times regardless of the location of a rectangle in the object list.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	

## 21 PC Setup Program

---

Configuration item	Selection/ setting option	Explanation
Color	Selection from color palette	<b>For rectangles only:</b> Fill color of the rectangle (transparent for objects)
Frame type	None Fine Bold Upper case Lower case	Selection of a frame format



### Bar graph:

Vertical or horizontal bar for visualizing analog values.

Configuration item	Selection/ setting option	Explanation
Visible	Checkmark in the checkbox	Checkmark set: Object is displayed Empty checkbox: Object is hidden
X position	0 to 315 pixels	X-coordinate of the top left corner of the pictogram
Y position	0 to 181 pixels	Y-coordinate of the top left corner of the pictogram
Width	1 to 316 pixels	Dimensions of the analog display
Height	1 to 182 pixels	
Transparent	Checkmark in the checkbox	Hide the background color; only the bar is visible
Frame type	None Fine Bold Upper case Lower case	Selection of a frame format
Color (off)	Selection from color palette	Background color of the bar graph display
Color (on)	Selection from color palette	Bar color in the bar graph display
Object type	horizontal vertical	Orientation of the bar graph display

## 21 PC Setup Program

**Example:** Objects now need to be added to the sample Process screen from the previous chapter (Chapter "Background", page 315). Valves and pumps are represented by pictograms. Two analog displays serve as the process value display.



# 21 PC Setup Program

## 21.8.12 E-mail




### NOTE!

The prerequisite for the e-mail function to operate is that the settings for the e-mail server and Ethernet are configured correctly. In particular, the DNS server and standard gateway entries must be correct.

- ⇒ Chapter "Setting up the e-mail server", page 327
- ⇒ Chapter 21.10.3 "Ethernet", page 336

The JUMO AQUIS touch P can be configured for event-controlled sending of e-mail notifications. Up to 5 e-mail templates can be stored in the JUMO AQUIS touch P. Sending of the e-mail is triggered by a rising edge of the binary signal in the "Alarm signal" field.

### Typical networking and company networks



### Function of the individual nodes

#### Gateway:

Separates local subnets from each other and thus filters the packets. Not all packets are received in every subnet. Packets from outside the local subnet must be addressed to the gateway.

#### DHCP server:

Can automatically assign IP address, subnet mask and gateway address to other nodes when switching on. These parameters can also be entered manually; a DHCP server is then no longer needed.

#### DNS server:

Converts symbolic names into IP addresses. Example: The query "www.na-me.de" is answered with "www.name.de has IP=10.12.32.45".

#### POP3 server:

used to read e-mails received in an e-mail account. The POP3 mail account is accessed by logging in with the user name and password. Successful login also frequently activates the sending authorization of the associated SMTP server.

**SMTP server:**

Used to send e-mails. In many networks, the authorization to send e-mails via a mail account must be released by previously logging in at the corresponding POP3 server.

**Proxy:**

Serves as a gateway from the local company network to the worldwide Internet. This is also where the conversion of "local" IP addresses (in the company network being used) into "unique" IP addresses (used on the Internet) takes place. The device software cannot address a proxy! There are, however, also "transparent proxies" that make worldwide IP addresses addressable without a special protocol.

### 21.8.13 SMS gateway


If present, e-mail messages can be redirected to your mobile phone through the SMS gateway of your wireless service provider. For e-mail forwarding through an SMS gateway, contact your wireless service provider.

# 21 PC Setup Program

## Setting up e-mail templates

Open Settings:

Only Setup > e-mail (double-click) > "e-mail 1 to 5" tab



The following table explains the settings for event-controlled sending of e-mails.


Configuration point	Selection/ setting option	Explanation
E-mail addresses 1 to 3	Enter a valid e-mail address	Up to 3 e-mail addresses to each of which a particular e-mail is sent can be entered in each e-mail template. Sending is triggered by the indicated alarm signal.
Alarm signal	Select from the binary selection	A rising flank of the selected alarm signal triggers sending of the particular e-mail to the listed e-mail addresses.
E-mail subject	Input text	Text for the subject line of each e-mail
E-mail text	Input text	Text of each e-mail

## 21 PC Setup Program

### Setting up the e-mail server

To send messages, you must specify the data for the outgoing mail server. Open the server settings window and enter the information here. You can obtain the server settings from your e-mail service provider or network administrator.

Open the dialog for the server settings:  
Only Setup > e-mail (double-click) > "e-mail Server" button



The following table explains the settings for the e-mail server.

Configuration point	Selection/ setting option	Explanation
Authentication	None SMTP-After-POP SMTP-Auth	Authentication process (login) for the e-mail server  You receive the configuration data for the e-mail server from the operator of the e-mail service that you use to send e-mail.
E-mail user name	Input text	User name of the e-mail account for the device for authentication (logging on to the e-mail servers)
E-mail password	Input text	Password of the e-mail account for the device for authentication (logging on to the e-mail servers)
Server URL POP3	Input text	URL (Internet address) or IP address of the incoming mail server (POP3 server) e. g. pop.provider.com
Server URL SMTP	Input text	URL (Internet address) or IP address of the outgoing mail server (SMTP server) e. g. smtp.provider.com
E-mail sender	Input text	E-mail address of the e-mail account for the device e. g. Anlage@provider.com

## 21 PC Setup Program

---



**NOTE!**


An e-mail server within the company network must be entered (not on the Internet or accessible without proxy addressing)! This mail server should be able to also forward e-mails to the Internet.



# 21 PC Setup Program

## Procedure for sending an e-mail over the Internet

To better understand the process of sending an e-mail and correct any errors in the configuration of e-mail servers and Ethernet, a graphical representation of the processes is presented in the following.



## 21 PC Setup Program

---

### Checking the e-mail function

Proper execution of the e-mail sending process can be checked in the event list. When an e-mail is sent successfully, a corresponding entry is made in the event list. Entries are made in the event list even in the case of a fault and can be helpful when diagnosing a problem.

⇒ Chapter 8.3 "Alarm/Event list", page 98

### 21.8.14 Web server

As an alternative to online visualization, the webserver can be activated with a customer-specific website. If the webserver is activated, its website automatically replaces the online visualization.

⇒ Chapter 8.7 "Online visualization", page 118



**NOTE!**

Creating websites requires the appropriate knowledge about website programming and specifying the webserver In the JUMO AQUIS touch P.


Customer-specific websites can be imported into the configuration of the webserver. To edit an already saved website, it can be exported. Data from the memory of the AQUIS touch P can also be displayed in the web document.

## 21 PC Setup Program

---

Open Settings:

Only Setup > Webserver Configuration (double-click)



- (1) "Import Web" button
- (2) "Export Web" button
- (3) "Delete Web" button
- (4) Window with tree view of the saved website
- (5) "HTML Tags" button  
Opens a dialog for copying the IDs of internal data from the device memory  
These IDs are needed to request the internal data from the web document.
- (6) "Security" button  
Opens a dialog to configure the webserver password

### 21.9 Diagnostics

#### 21.9.1 Calibration logbooks

The calibration logbooks for all analysis inputs can be displayed on both the device and under this menu item in the JUMO PC setup program.

⇒ Chapter 12.3 "Calibration logbook", page 201

#### 21.9.2 Digital sensor calibration logbooks

The calibration logbooks for all digital sensors can be displayed on both the device and under this menu item in the JUMO PC setup program.

⇒ Chapter 12.3 "Calibration logbook", page 201

#### 21.9.3 Digital sensor connection list

If the JUMO AQUIS touch P must be replaced, e.g. because of a defect in the device, and a backup of the configuration is available as a setup file, the configuration can be loaded into the new device. However, the original links of the digital sensors to the corresponding inputs for the digital sensors must be reestablished manually. The information required to do this can be displayed with the PC setup program. The setup file backup from the original device contains the list of link data. Open this setup file and click in the navigation area of the PC setup program:

Diagnosis > Digital Sensor Connection List

The link data is displayed in this list. By comparing this data, the sensors can be reassigned to their original inputs and linked manually.

⇒ Chapter 8.2.7 "Digital sensors", page 101

## 21 PC Setup Program

---

### Procedure for linking digital sensors following device replacement:

Step	Action
1	Using the JUMO PC setup program, load the originally backed up configuration into the device.
2	Press the "Print" button or File > Print
3	In the print selection list, select "Digital Sensor Connection List".
4	Print out the list (confirm the selection with "OK")
5	On the device, open the menu Device Menu > Digital Sensors, scan, and link all connected sensors. ⇒ Chapter 8.2.7 "Digital sensors", page 101

## 21.10 Online parameters

To set online parameters in the device, the software accesses the device memory directly. The device must thus be connected via a USB or Ethernet port to the PC on which the JUMO PC setup program is installed, and a connection between the JUMO PC setup program and device must be established.


⇒ "Configuring and parameterizing", page 292

### 21.10.1 Date and time

Here, the current date and the current time in the device are obtained from the JUMO PC setup program.

Open Settings:

Online Parameters > Date and Time (double-click)



- (1) "Read Continuously" button  
Starts continuous synchronization of the date / time in the software with the device
- (2) "Stop" button  
Stops continuous synchronization of the date / time in the software with the device
- (3) "Synchronize" button  
Synchronizes the device time with the time set in the PC setup program  
The time in the device is matched to the set time as long as the difference is not more than 30 s. This function is used primarily to synchronize the PC time with the device time.
- (4) "Set" button  
Sets the time in the device to match the setting in the PC setup program
- (5) Time setting  
The PC time can be used or a time may be entered. The specified time is set in the device by clicking the "Synchronize" or "Set" button.

### 21.10.2 Screenshot


This function can be used to transfer the current display on the device to the PC.

## 21 PC Setup Program

Screenshots can be printed out or saved on the PC in common image formats, e.g. bitmap, tiff, JPEG etc.

Open:

Online Parameters > Screenshot (double-click)



### 21.10.3 Ethernet

This menu item in the online parameters permits configuration of the Ethernet interface from the PC setup program.

Open Settings:

Online Parameters > Ethernet (double-click)

The Ethernet settings are explained in the configuration.

⇒ See chapter 10.17 "Ethernet", page 177



#### **NOTE!**

The Ethernet settings are entered in the online parameters in the JUMO PC setup program.

The IP configuration of the device can also be changed from the PC if the PC and device are connected via Ethernet. In this case, changing the IP address or subnet mask can interrupt the PC-device connection.



### 21.10.4 Enabling of extra codes

This function allows the customer to enable extra codes in the device software (recording function, math, and logic module). After purchasing an extra code in the device software, you must generate a code number with the aid of the PC setup program. This is needed by JUMO to generate an individual activation code that you as a customer need to enable the desired device functions. After opening "Enable extra codes", you have 3 options available:

- **Generate code number**  
If you wish to purchase an extra code in the device software, you must generate a device- and option-specific code number and send it to JUMO. After it receives this code number, JUMO provides you with the activation code with which you can enable the desired option.
- **Enter activation code**  
After you have sent the code number for the desired extra code to JUMO, you receive the activation code for this option. Following correct entry of the activation code, this option is available for use in the device.
- **Reset the extra codes**  
All software-based extra codes in your device can be deactivated with this option.

Open "Enable Extra Codes":  
Online Parameters > Enable Extra Codes (double-click)

### 21.10.5 Deleting internal measurement data

Upon executing this function, data are **deleted completely** and **permanently** from the measurement memory of the data monitor and recording function. Following this, recording of measurement data is started anew.

Delete internal measurement data:  
Online Parameters > Delete Internal Measurement Data (double-click)

## 21 PC Setup Program

---

### 21.10.6 Adjusting / Testing

**CAUTION!**

When "Adjusting / Testing" is opened, the outputs assume undefined states. For this reason, "Adjusting / Testing" may not be opened during operation of equipment being controlled by the JUMO AQUIS touch P.

Numerous testing functions that are available in similar form in the device settings menu at the "Functional level" or under "Device info" can be found under "Adjusting / Testing". The contents and functions of the individual tabs in the "Adjusting / Testing" window are described in the following.

**Hardware / Software**

This is used to query the version information for the device software and hardware, e.g. which optional boards are installed.

Open:

Online Parameters > Adjusting / Testing (double-click) > Hardware / Software tab

**Calibration constants**

Displays characteristic curve date (e. g calibration values for analysis inputs) for each analog input and output.

Open:


Online Parameters > Adjusting / Testing (double-click) > Calibration Constants tab

### Analog inputs

Proper operation of the analog inputs of the device can be checked here. In addition to selecting the analog input and signal type, the line frequency of the power supplied to the device must be set in order to test an analog input correctly. Pressing the "Test" button displays a connection diagram for the test signal. Ensure that a valid test signal acc. to the connection diagram is present at the input. Confirming the connection diagram starts the test. The measuring values coming from the analog input concerned can be viewed in the actual-value display and in the measuring value table. To stop the test, press the "Stop" button.

Open:

Online Parameters > Adjusting / Testing (double-click) > Analog Inputs tab




- (1) "Stop" button  
Stops a test
- (2) "Test" button  
Starts a test
- (3) Measured value display  
Displays the actual analog value at the input
- (4) Measuring value table  
Lists the measuring values over the course of time
- (5) "Supply frequency" setting
- (6) Selection of the analog input to test
- (7) Selection of the signal type to test

# 21 PC Setup Program

## Analog outputs

Proper operation of the analog outputs of the device can be checked here. A desired output value can be specified in the "Setpoint value" field for the selected output and signal type set. Pressing the "Test" button starts the test. During the test, a window for monitoring the output signal is displayed. Here, you can enter the actual output value that you may have obtained with a measuring instrument as a way to check the output signal value. The test is stopped by pressing the "Stop" button.

Open:  
Online Parameters > Adjusting / Testing (double-click) > Analog Outputs tab



- (1) "Stop" button  
Stops a test
- (2) Dialog window for checking the measuring value during the test
- (3) "Test" button  
Starts a test
- (4) Selection of the analog output to test
- (5) Selection of the signal type to test
- (6) Setpoint value  
Desired output value during the test


## 21 PC Setup Program

### Binary outputs

Proper operation of the Digital outputs of the device can be checked here. After setting checkmarks in the option fields, the Digital outputs of the device can be controlled manually via the PC setup program. The "Set All" and "Delete All" buttons allow all Digital outputs to be switched on and off at once.

Open:

Online Parameters > Adjusting / Testing (double-click) > Digital Outputs tab



# 21 PC Setup Program

## Digital inputs


Proper operation of the Digital inputs of the device can be checked here. The "Read Continuously" button starts a continuous test that can be stopped by pressing the "Stop" button. During this test, the binary values of the device inputs are read continuously and displayed in acc. with the checkmarks in the option fields.

Pressing the "Read Once" button captures and displays the momentary binary values of the inputs.

By clicking on individual binary input entries, the binary value of the entry can be updated selectively.

Open:

Online Parameters > Adjusting / Testing (double-click) > Digital Inputs tab



The screenshot shows a window titled "User level" with a table of configuration parameters. The table has four columns: "Parameter", "Description", "Limit value mi...", and "Limit value m...". Row 7 is highlighted in blue.

Parameter	Description	Limit value mi...	Limit value m...
1 Configuration selector\Basic settings\Memory alarm limit	Memory alarm limit	20 %	100 %
2 Configuration selector\Temperature inputs\IN4 ...	Filter time const.	3.0 s	25.0 s
3 Configuration selector\Temperature inputs\IN4 ...	Offset	-5.0 °C	999.0 °C
4 Configuration selector\Ethernet\Config. IP address	Config. IP address	0	1
5 Configuration selector\Ethernet\DNS device name	DNS device name		
6 Configuration selector\Setpoint values\Setpoint ...	Setpoint value 1	20.0	30.0
7 Configuration selector\Setpoint values\Setpoint ...	Setpoint value 2	20.0	30.0
8 Configuration selector\No selection		0	100
9 Configuration selector\No selection		0	100
10 Configuration selector\No selection		0	100
11 Configuration selector\No selection		0	100
12 Configuration selector\No selection		0	100
13 Configuration selector\No selection		0	100
14 Configuration selector\No selection		0	100
15 Configuration selector\No selection		0	100

Buttons: Edit, OK, Cancel

# 21 PC Setup Program

---

## Battery

The **voltage of the buffer battery** and the **circuit board temperature** in the device are displayed in the JUMO PC setup program.

Open:

Online Parameters > Adjusting / Testing (double-click) > Battery tab



### CAUTION!

A buffer battery is built into the device. Its purpose is to maintain data when the device is switched off or if the voltage supply is interrupted. If the battery approaches the end of its operating life (approximately 7 years) then a battery prealarm will indicate that status. When the battery is empty a battery alarm will indicate that status. The battery must be exchanged before it is empty. The battery must be exchanged by the JUMO Service department! In this case, send in the device!

## Touch

In this view, touchscreen calibration (see "Calibrating the touchscreen", page 93) can be started from the JUMO PC setup program. In addition, the calibration data for the touchscreen are displayed in detail. These are used to diagnose problems with touch operation together with JUMO Service.

Open:

Online Parameters > Adjusting / Testing (double-click) > Touch tab

## Display

Four different test images can be activated on the device display on this tab. These are used to diagnose display problems together with JUMO Service.

Open:

Online Parameters > Adjusting / Testing (double-click) > Display tab

## Various process values

Process data are selected here for display in the online window.

In addition to tabs with standard selections of process data, the online window contains the "Selected Process Data" tab. The process data selected here are displayed on this tab.



### NOTE!

Process data from the internal device memory can be displayed in real time in the online window.

⇒ Chapter "Online data", page 264

A requirement for real-time display of process data is an existing connection between the JUMO PC setup program and the device.

# 21 PC Setup Program

---



### 22.1 Analog inputs base unit

#### 22.1.1 Temperature measuring input (IN 4)

Probe-/Signal type	Connection type	Measuring range	Measuring accuracy	Ambient temperature influence
Pt100 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.05% of MR <sup>a</sup>	≤ 50 ppm/K
Pt1000 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.1% of MR <sup>a</sup>	≤ 50 ppm/K
RTD temperature probe with customer-specific characteristic line <sup>b</sup>				
up to 400 Ω	2-wire/3-wire	0 to 400 Ω	≤ 0.1% of R <sub>max</sub> <sup>c</sup>	≤ 100 ppm/K
to 4000 Ω	2-wire/3-wire	0 to 4000 Ω	≤ 0.1% of R <sub>max</sub> <sup>c</sup>	≤ 100 ppm/K
Sensor lead resistance	maximal 30 Ω per line with 3-wire circuit			
Lead compensation	Not required for 3-wire circuit. With a 2-wire circuit, lead calibration can be executed at the respective input by means of an measured value correction with the aid of the "Offset" setting.			

<sup>a</sup> MR: measuring range span

<sup>b</sup> Customer-specific linearization can be used to enter a sensor characteristic line.

<sup>c</sup> R<sub>max</sub>: maximal resistance across the measuring range (400 Ω, or 4000 Ω)

## 22 Technical data

### 22.1.2 Temperature measuring input (IN 5)

Probe-/Signal type	Connection type	Measuring range	Measuring accuracy	Ambient temperature influence
Pt100 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.05% of MR <sup>a</sup>	≤ 50 ppm/K
Pt1000 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.1% of MR <sup>a</sup>	≤ 50 ppm/K
Resistance transmitter/ Resistance potentiometer	3-wire	0 to 100 kΩ	0.5% of R <sub>Tot</sub> <sup>b</sup>	≤ 100 ppm/K
RTD temperature probe with customer-specific characteristic line <sup>c</sup>				
up to 400 Ω	2-wire/3-wire	0 to 400 Ω	≤ 0.1% of R <sub>max</sub> <sup>d</sup>	≤ 100 ppm/K
to 4000 Ω	2-wire/3-wire	0 to 4000 Ω		
to 100 kΩ	2-wire/3-wire	0 to 100 kΩ		
NTC 8k55	2-wire/3-wire	0 to 150 °C	≤ 0.1% of R <sub>max</sub> <sup>d</sup>	≤ 100 ppm/K
NTC 22k	2-wire/3-wire	0 to 150 °C		
Sensor lead resistance	maximal 30 Ω per line with 3-wire circuit			
Lead compensation	Not required for 3-wire circuit. With a 2-wire circuit, lead calibration can be executed at the respective input by means of an measured value correction with the aid of the "Offset" setting.			

<sup>a</sup> MR: measuring range span

<sup>b</sup> R<sub>Tot</sub>: total resistance of the resistance transmitter/Resistance potentiometer

<sup>c</sup> Customer-specific linearization can be used to enter a sensor characteristic line.

<sup>d</sup> R<sub>max</sub>: maximal resistance across the measuring range (400 Ω, 4000 Ω or 100 kW)

### 22.1.3 Universal input (IN 6)

Signal type	Measuring range	Measuring accuracy	Ambient temperature influence
Current signal	0(4) to 20 mA	0.1% of MR <sup>a</sup>	100 ppm/K

<sup>a</sup> MR: measuring range span

### 22.1.4 Measuring circuit monitoring base unit

Inputs	Underrange/ overrange
Temperature input	Yes
Universal input (current signal)	Yes

### 22.2 Analog inputs optional boards

#### 22.2.1 Universal input (IN 11, IN 12)

Probe-/Signal type	Connection type	Measuring range	Measuring accuracy	Ambient temperature influence
Pt100 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.05% of MR <sup>a</sup>	≤ 50 ppm/K
Pt1000 DIN EN 60751	2-wire/3-wire	-200 to +850 °C	≤ 0.1% of MR <sup>a</sup>	≤ 50 ppm/K
Resistance transmitter/ Resistance potentiometer	3-wire	100 to 4000 Ω	0.5% of R <sub>Tot</sub> <sup>b</sup>	≤ 100 ppm/K
RTD temperature probe with customer-specific characteristic line <sup>c</sup>				
up to 400 Ω	2-wire/3-wire	0 to 400 Ω	≤ 0.1% of R <sub>max</sub> <sup>d</sup>	≤ 100 ppm/K
to 4000 Ω	2-wire/3-wire	0 to 4000 Ω	≤ 0.1% of R <sub>max</sub> <sup>d</sup>	≤ 100 ppm/K
Voltage signal	-	0 to 10 V	0.2% of MR <sup>a</sup>	100 ppm/K
Current signal	-	0(4) to 20 mA	0.1% of MR <sup>a</sup>	100 ppm/K
Sensor lead resistance <sup>e</sup>	maximal 30 Ω per line with 3-wire circuit			
Lead calibration <sup>e</sup>	Not required for 3-wire circuit. With a 2-wire circuit, lead calibration can be executed at the respective input by means of an measured value correction with the aid of the "Offset" setting.			

<sup>a</sup> MR: measuring range span

<sup>b</sup> R<sub>Tot</sub>: total resistance of the resistance transmitter/Resistance potentiometer

<sup>c</sup> Customer-specific linearization can be used to enter a sensor characteristic line.

<sup>d</sup> R<sub>max</sub>: maximal resistance across the measuring range (400 Ω or 4000 Ω)

<sup>e</sup> Specification does not apply for standard signals

#### 22.2.2 Analysis input: pH/Redox/NH<sub>3</sub>

Measurand	Measuring range	Temperature compensation	Measuring accuracy	Ambient temperature influence
pH-value (standard electrode)	-2 to +16 pH	-10 to +150 °C	≤ 0.3% of MR <sup>a</sup>	0.2%/10 K
pH-value (ISFET electrode)	-2 to +16 pH	through electrode <sup>b</sup>		
Redox voltage	-1500 to +1500 mV	None		
NH <sub>3</sub> (ammonia)	0 to 20000 ppm	-10 to +150 °C		

<sup>a</sup> MR: measuring range span

<sup>b</sup> ISFET electrodes supply a temperature-compensated pH-measured value.

## 22 Technical data

### 22.2.3 Analysis input: CR (resistive conductivity)

<b>Units</b>	$\mu\text{S}/\text{cm}$ $\text{mS}/\text{cm}$ $\text{k}\Omega \times \text{cm}$ $\text{M}\Omega \times \text{cm}$
<b>Display ranges<sup>a</sup></b>	0.0000 to 9.9999 00.000 to 99.999 000.00 to 999.99 0000.0 to 9999.9 00000 to 99999
<b>Temperature compensation</b>	TC-linear, natural water DIN EN 27888, natural water with expanded range, TDS <sup>b</sup> , ASTM D-1125-95 for neutral (NaCl), acidic (HCl) and alkaline (NaOH) impurities
<b>Cell constant</b>	0.01 to 10 $\text{cm}^{-1}$
<b>Measuring range selection<sup>c</sup></b>	4 configurable measuring ranges
<b>Measuring accuracy</b>	$\leq 0.6\%$ of MR <sup>d</sup> + 0.3 $\mu\text{S} \times \text{cell constant (C)}$
<b>Ambient temperature influence</b>	0.2%/10 K

<sup>a</sup> The display range is scalable. The Comma format is freely configurable. In addition, an automatic Comma format can be set.

<sup>b</sup> TDS (Total Dissolved Solids)

<sup>c</sup> In the Configuration up to 4 different measuring ranges with separate display range limits, units, temperature compensation methods, and alarm functions can be configured. The respective active measuring range is selected via binary signals.

<sup>d</sup> MR: measuring range span

### 22.2.4 Analysis input: Ci (conductivity, inductive)

<b>Units</b>	µs/cm ms/cm
<b>Measuring/display ranges<sup>a</sup></b>	0.0000 to 9.9999 00.000 to 99.999 000.00 to 999.99 0000.0 to 9999.9 00000 to 99999
<b>Temperature compensation</b>	TC linear <sup>b</sup> TC curve natural water natural water with expanded temperature range NaOH 0 to 12% NaOH 25 to 50% HNO <sub>3</sub> 0 to 25% HNO <sub>3</sub> 36 to 82% H <sub>2</sub> SO <sub>4</sub> 0 to 28% H <sub>2</sub> SO <sub>4</sub> 36 to 85% H <sub>2</sub> SO <sub>4</sub> 92 to 99% HCl 0 to 18% HCl 22 to 44%
<b>Cell constant</b>	4.00 to 8.00 cm <sup>-1</sup>
<b>Measuring range selection<sup>c</sup></b>	4 configurable measuring ranges
<b>Measuring accuracy</b>	for 0 to 999 µS/cm: 1.5% of the MRE <sup>d</sup> for 1 to 500 mS/cm: 1% of the MBE <sup>d</sup> for 500.1 to 2000 mS/cm: 1.5% of the MBE <sup>d</sup>
<b>Ambient temperature influence</b>	0.1%/K

<sup>a</sup> The display range is scalable. The Comma format is freely configurable. In addition, an automatic Comma format can be set.

<sup>b</sup> TC: temperature coefficient

<sup>c</sup> In the Configuration up to 4 different measuring ranges with separate display range limits, units, temperature compensation methods and alarm functions can be configured. The respective currently active measuring range is selected via binary signals.

<sup>d</sup> MRE: Measuring range end value

## 22 Technical data

---

### 22.2.5 Temperature compensations

Compensation type	Compensation range
TC linear <sup>a</sup>	-50 to +250 °C
TC curve	-50 to +250 °C
TDS	-50 to +250 °C
natural water according to DIN EN 27888	0 to 36 °C
natural water with expanded temperature range <sup>b</sup>	0 to 100 °C
ASTM D-1125-95 (neutral, alkaline, and acidic impurities)	0 to 100 °C
NaOH 0 to 12%	0 to 90 °C
NaOH 25 to 50%	10 to 90 °C
HNO <sub>3</sub> 0 to 25%	0 to 80 °C
HNO <sub>3</sub> 36 to 82%	-20 to +65 °C
H <sub>2</sub> SO <sub>4</sub> 0 to 28%	-17 to +104 °C
H <sub>2</sub> SO <sub>4</sub> 36 to 85%	-17 to +115 °C
H <sub>2</sub> SO <sub>4</sub> 92 to 99%	-17 to +115 °C
HCl 0 to 18%	10 to 65 °C
HCl 22 to 44%	-20 to +65 °C

<sup>a</sup> TC: temperature coefficient

<sup>b</sup> The temperature compensation "natural water with expanded temperature range" extends beyond the standardized temperature thresholds of DIN EN 27888.

### 22.2.6 Measuring circuit monitoring, optional boards

Input/Sensor	Underrange/ overrange	Short circuit/ sensor break	Open circuit	Special fea- tures
pH-value (glass elec- trode)	Yes	Configurable Impedance mea- surement <sup>a</sup>	Configurable Impedance mea- surement <sup>a</sup>	-
pH-value (ISFET)	Yes	No <sup>b</sup>	No <sup>b</sup>	-
Resistive conductivity	Yes	No <sup>b</sup>	Configurable	Only with 4-wire circuit <sup>a</sup>
Inductive conductivity	Yes	No <sup>b</sup>	No <sup>b</sup>	-
Universal input for con- nection of: voltage/cur- rent signal, RTD temperature probe	Yes	No <sup>b</sup>	No <sup>b</sup>	-
Universal input for con- nection of: resistance potentiometer	No <sup>b</sup>	No <sup>b</sup>	No <sup>b</sup>	-

<sup>a</sup> With impedance monitoring and detection of deposits, the sensor alarm is tripped in case of a fault. Monitoring via impedance measurement can also be activated.

The following points should be observed to ensure correct function:

- Impedance measurements are possible only with glass-based sensors.
- Sensors must be connected directly to an analysis input for pH/Redox/NH<sub>3</sub> on the device.
- Impedance converters must not be installed in the measuring circuit.
- The maximal admissible cable length between sensor and device is 10 m.
- Liquid resistance has a direct impact on the measurement result. It is therefore advisable to activate the impedance measurement in liquids at a minimum conductivity of approx. 100 µS/cm.

<sup>b</sup> Errors in the measuring circuit (short circuit or line break) lead to display errors (underrange or overrange or inadmissible value).

## 22 Technical data

### 22.3 Analog outputs of base unit and optional boards

Signal type	Signal range	Admissible load resistance	Accuracy	Effect of ambient temperature
Voltage signal	0 to 10 V	> 500 Ω	≤ 0.25 %	≤ 100 ppm / K
Current signal	0/4 to 20 mA	< 450 Ω	≤ 0.25 %	≤ 100 ppm / K

### 22.4 Binary inputs base unit

Description	Input frequency ranges	Min. pulse duration		Signal type	Switching thresholds <sup>a</sup>	
		On	Off		On	Off
IN 1 <sup>b</sup>	≤ 1 Hz	300 ms	300 ms	Configurable as: potential-free contact, or ext. voltage supply (maximal 28 V)	> 8 V	< 5 V
IN 2 to 3 <sup>b,c</sup> Switching signal	≤ 1 Hz	30 μs	30 μs		> 1.8 mA	< 1.2 mA
IN 2 to 3 <sup>b,c</sup> Flow	3 to 300 Hz 300 Hz to 10 kHz	30 μs	30 μs			

<sup>a</sup> This specification is relevant only if the Ext. voltage supply is selected under the "Contact" point in the Configuration. Sensors and transmitters should be supplied from voltage supply outputs on the JUMO AQUIS touch P. An externally supplied voltage signal must not have a voltage over 28 V.

<sup>b</sup> All digital inputs IN 1 to 3 are suitable for connecting proximity switches. Recommended types are: Wachendorff P2C2B1208NO3A2 and Balluff BES M12EG-PSC80F-BP03.

<sup>c</sup> Digital inputs IN 2 and IN 3 can be used for impeller flow-through sensors (water meters) or magnetic-inductive flow-through meters (square-wave signal), for example. The input frequency depends on the configured measuring principle in the flow-through function.

### 22.5 Binary inputs optional boards

Max. number of retrofittable digital inputs	Max. pulse frequency	Min. pulse duration		Signal type
		On	Off	
max. 2 optional boards with 3 digital inputs each	1 Hz	300 ms	300 ms	Potential-free contact

### 22.6 Binary outputs, power supply unit board

Description	Switching output	Ampacity at ohmic load	Contact life <sup>a</sup>
OUT 1	Relay, change-over contact	3 A at AC 250 V	150,000 switching cycles
OUT 2	Relay, change-over contact		

<sup>a</sup> The maximal ampacity of the contacts must not be exceeded.



### 22.7 Binary outputs, optional boards

Optional card	Switching output	Ampacity at resistive load	Contact life <sup>a</sup>	Special features
Relay output, dual normally open contacts	2 normally open contacts <sup>b</sup>	3 A at AC 250 V	150,000 switching cycles	-
Relay output, single changeover contact	1 changeover contact			-
Solid state relay triac	Switching output with triac (protected by varistor) <sup>c</sup>	1 A at AC 230 V	Wear-free	-
PhotoMOS® <sup>e</sup> solid state relay	Switching output with PhotoMOS® <sup>d</sup>	200 mA at DC 50 V and/or AC 35 V	Wear-free	not short-circuit-proof max. voltage DC 50 V AC 35 V
Logic output 0/12 V	High/low signal	20 mA <sup>e</sup>	Wear-free	-
Logic output 0/22 V	High/low signal	30 mA <sup>e</sup>	Wear-free	-

<sup>a</sup> The maximal ampacity of the contacts must not be exceeded.

<sup>b</sup> Combining a mains voltage circuit with a protective low-voltage circuit on the "dual normally open contact" option is not admissible.

<sup>c</sup> A varistor protects the triac against excessive voltages such as those that can occur during switching.

<sup>d</sup> PhotoMOS® is a registered trademark of Panasonic.

<sup>e</sup> Current limiting via the logic output of the device

### 22.8 Voltage supply outputs, optional board

Description	Output voltage	Ampacity	Connection
DC 24 V voltage supply for external transmitters <sup>a</sup>	DC 24 V +17 / -5%	42 mA	Screw terminals
±5 V DC voltage supply (e.g. for ISFET pH-sensors)	+5 V DC +10 / -4 % (between terminals 3 and 4)	150 mA	
	-5 V DC ±15% (between terminals 5 and 4)	30 mA	

<sup>a</sup> An optional board for voltage supply outputs accommodates all the outputs listed in this table. A maximum of 1 such optional board can be integrated into a device.

## 22 Technical data

### 22.9 Interfaces

#### 22.9.1 Serial interface RS485 (base unit )

Protocol	Data formats <sup>a</sup>	Device addresses	Baud rates in baud	Connection
Modbus (slave) Modbus digital sensors	8 - 1 - no parity 8 - 1 - odd parity 8 - 1 - even parity	1 to 254	9600 19200 38400	Spring-cage terminals


<sup>a</sup> Specification in useful bit - stop bit - parity format. Therefore, the frame always comprises 8 useful bits and 1 stop bit. Only the parity is differentiated.

#### 22.9.2 Serial Interface RS422/485 (optional board)

Protocol	Data formats <sup>a</sup>	Device addresses	Baud rates in baud	Connection
Modbus (slave) Modbus digital sensors	8 - 1 - no parity 8 - 1 - odd parity 8 - 1 - even parity	1 to 254	9600 19200 38400	Screw terminals

<sup>a</sup> Specification in useful bit - stop bit - parity format. Therefore, the frame always comprises 8 useful bits and 1 stop bit. Only the parity is differentiated.

#### 22.9.3 PROFIBUS-DP (optional board)

Protocol	Data formats <sup>a</sup>	Device addresses	Baud rates	Connection
DP-V0	Big Endian Little Endian	0 to 127	9.6 kBaud to 12 MBaud	D-sub socket 9-pole 

<sup>a</sup> Big Endian corresponds to the Motorola<sup>®</sup> data format and Little Endian to Intel<sup>®</sup> data format.


#### 22.9.4 Sampling rate for digital sensors

At baud rate > 9600 baud (only possible for sensors with JUMO digiLine electronics)	500 ms
At baud rate = 9600 baud and more than 2 digital sensors in the bus <sup>a</sup>	1 s

<sup>a</sup> For sensors of the type JUMO ecoLine O-DO the sampling rate is configurable (1 bis 999 s).

## 22 Technical data

### 22.9.5 Ethernet optional board (10/100Base-T)

Function	Use	Application protocol/ program	Special features	Connection
Web server	Online visualization via web browser	HTTP	Editable via HTML Editor	RJ 45 socket 
E-mail/SMS text message <sup>a</sup>	E-mail dispatch via SMTP server Transmission as SMS text message	SMTP	5 e-mail templates can be stored, up to 3 recipients for each e-mail template	
Modbus TCP/IP	Process data exchange with Modbus users <sup>b</sup>	Modbus TCP/IP	TCP Port: 502	
Automatic IP-configuration	Network administration <sup>c</sup>	DHCP	-	
Setup via PC	Device settings via PC setup program	JUMO PC setup program (HTTP)	-	
Recording function <sup>d</sup>	Extract, archive, evaluate measurement data	JUMO PCC and PCA 3000	-	

<sup>a</sup> The e-mail function allows the device, when triggered by internal and/or external binary signals, to send hard-programmed messages. This requires the data of an SMTP server (E-mail intermediate server) to be known. The e-mail function can be configured exclusively via the PC setup program.

<sup>b</sup> Modbus TCP/IP enables Modbus users to communicate via a LAN, provided this is connected to the LAN (e.g. via gateways). To configure Modbus communication you will require the interface description for the JUMO AQUIS touch P.



<sup>c</sup> Enlist the help of your network administrator or an IT specialist for the IP-configuration.

<sup>d</sup> The recording function stores measurement data in a ring buffer inside the device. Further details appear on Page 360.

## 22 Technical data

---

### 22.9.6 USB interfaces

Interface	Use	Support	Connection	Version
USB host interface	Extract measurement data memory <sup>a</sup> , Read/write device settings, Save Service data <sup>b</sup> , Update the firmware	USB flash drive	USB port Type A 	USB 2.0
USB device interface	Device setting via PC setup program, Extract, archive, evaluate measurement data	JUMO PC setup program, JUMO PCC/PCA 3000 software	USB port Type Mini-B 	

<sup>a</sup> The recording function stores measurement data in a ring buffer inside the device.

<sup>b</sup> Service data can be stored on a USB flash drive for diagnostic purposes.

### 22.10 Electrical data

Voltage supply (switch-mode)	AC 110 to 240 V +10/-15%; 48 to 63 Hz or AC/DC 24 V +30/-25 %; 48 to 63 Hz
electrical safety	According to EN 61010, part 1 overvoltage category III, pollution degree 2
Max. power consumption AC 110 to 240 V AC/DC 24 V	27.9 VA (11,7 W at 230 V) 25.2 VA (14,7 W at DC 24 V)
Data backup	Flash memory
Electrical connection	at the back via screw terminals Specifications for conductor cross-sections ⇒ Chapter 6.2.2 "Conductor cross-sections for base unit and power supply unit", Page 37
electromagnetic compatibility (EMC): Interference emission Interference immunity	DIN EN 61326-1  Class A Industrial requirements

### 22.11 Screen Touchscreen

Type	TFT-touchscreen
Touchscreen sensors	Resistive (can also be operated wearing gloves)
Display protection	Front/design film for protection against damage and scratches
Size	3.5"
Resolution	320 × 240 pixel
Color depth	256 colors
Viewing angle	Horizontal: ±65° Vertical: -65 to +40°

## 22 Technical data

---

### 22.12 Case

Site altitude	maximum 2000 m above sea level
Case type	Plastic front frame with metal case barrel (for indoor use only)
Materials	Plastic front panel UL 94 V0 Case barrel from zinc-plated steel sheet
Dimensions of the front	96 mm × 96 mm
Dimensions of the panel cut-out	92 mm × 92 mm Tolerance = +0.8 mm
Depth behind panel without Ci-conductivity sensor with Ci-conductivity sensor	130.9 mm 283.3 mm (including maneuvering space for sensor cable)
Panel thickness	Max. 5 mm
Minimum distance to other operating equipment	from edge of the panel cut-out horizontal 35 mm, vertical 80 mm
Ambient temperature	-5 to +50 °C
Storage temperature	-30 to +70 °C
Resistance to climatic conditions	Relative humidity < 85% annual average, no condensation
Operating position	Any (with due consideration for the viewing angle of the screen)
Protection type Case front in panel insertion Metal case barrel	According to DIN EN 60529 IP66 IP20
Weight (fully fitted)	approx. 1000 g

### 22.13 Functions

#### 22.13.1 Controller channels

Number	4
Controller type	Two-state controllers Three-state controllers Continuous controller Coarse/fine controller Modulating controllers Proportional controller with integrated actuator driver
Controller structure	P, PI, PD, PID
Controller outputs	For each controller channel, 2 outputs configurable as: pulse length output, pulse frequency output, (maximal 240 pulses per minute), continuous output
Disturbance feedforward control	multiplicative and/or additive <sup>a</sup>
Self-optimization	Step response method
Sampling rate	250 ms

<sup>a</sup> Ena. variable disturbance permits consideration of influencing variables in the process environment beyond the actual value alone. This keeps the controller behavior stable, even when fluctuations in such ambient conditions occur.

## 22 Technical data

### 22.13.2 Recording function

	Data monitor	Recording function (also available)
Number of groups <sup>a</sup>	2	2
Number of input variables per group	4× analog 3× binary	4× analog 3× binary
Recording / Memory rate	1 to 3600 s	1 to 3600 s
Memory values	Current value Average value Minimum value Maximum value	Current value Average value Minimum value Maximum value
Size of the ring buffer <sup>b</sup>	sufficient for 150 entries <sup>c</sup>	sufficient for approx. 31 million entries <sup>c</sup>
History function <sup>d</sup>	No	Yes
Archiving/evaluation	No	Yes, (with JUMO PCA 3000 evaluation software )

<sup>a</sup> A freely configurable set of input variables can be pooled in one group.

Each group has its own display screen. The group affiliation is considered for data storage to enable evaluation via PC.

<sup>b</sup> The measurement data are stored in a ring buffer. When the ring buffer is full, the recording function begins at the start of the ring buffer by overwriting the measuring value history.

<sup>c</sup> One entry contains 3 analog values and 3 binary values. The sum total of both groups is indicated.

<sup>d</sup> The history function allows the user to scroll the diagram back in the recording time period. All measured data stored in the ring buffer can thus be viewed on the device.

### 22.13.3 Customer-specific linearization

Number of support points <sup>a</sup>	up to 40 value pairs
Interpolation <sup>b</sup>	Linear
Formula entry <sup>c</sup>	4th degree polynomial

<sup>a</sup> Inputting grid points (value pairs from customer-specific characteristic curve) allows an approximate characteristic curve to be entered.

<sup>b</sup> Linear interpolation means forming a slope function from 2 support points.

<sup>c</sup> As an alternative to entering support points, a customer-specific characteristic curve can also be entered as a formula in the form of a polynomial.

## 22.14 Approvals/approval marks

Approval mark	Testing agency	Certificates/ inspection numbers	Inspection basis	Valid for
GL - hardware GL - software	Germanischer Lloyd	Approval submitted	Environmental Category C EMC 1	Type 202580/...
c UL us	Underwriters Laboratories	E201387	UL 61010-1 (3. Edition), CAN/CSA-C22.2 No. 61010-1 (3. Edition)	Type 202580/...







## 23.1 Troubleshooting and remedies for digital sensors

### 23.1.1 Possible faults on sensors with JUMO digiLine electronics

Fault symptom	Possible cause	Remedy
A sensor is not detected after being connected and is also not visible for manual linking (cf. Chapter "Submenu for linking", page 95).	The serial interface of the device concerned is configured incorrectly.	Check the following serial interface setting:  <b>Protocol:</b> Modbus digital sensors
	More than 6 digital sensors were connected.	Ensure that no more than 6 digital sensors are connected to a JUMO AQUIS touch P.
	The voltage supply for powering the sensor electronics is inadequate.	Ensure compliance with the specifications in the tables for planning the cabling for digital sensors.  ⇒ Chapter 23.2 "Planning the cabling for digital sensors", page 367
Sensors are not linked	The JUMO AQUIS touch P cannot unambiguously assign the sensors to specific inputs for digital sensors. Possible causes: <ul style="list-style-type: none"> <li>Several sensors with digiLine electronics of the same kind that were not yet been linked to the device were connected simultaneously.</li> <li>Several inputs were configured for digital sensors of the same kind and show the status "Installation".</li> </ul>	Follow the instructions in the operating manual for startup of digital sensors. JUMO sensors with digiLine electronics of the same kind must be put into operation individually. JUMO sensors with digiLine electronics can only be linked to inputs for digital sensors if the configuration of the input matches the type of sensor. If "TAG check" is activated in the configuration of an input for digital sensors, the "Sensor TAG" must match the "TAG number" in the configuration of the digiLine electronics to be linked.
	"TAG check" is activated in the configuration of the input for digital sensors concerned and the "Sensor TAG" does not match the "TAG number" in the configuration of the digiLine electronics to be linked.	⇒ Chapter 7.2 "Digital sensors", page 66
	No suitably configured input for digital sensors is available for the type of sensor (status "Installation").	⇒ Chapter 8.2.7 "Digital sensors", page 93
	The interface configuration of the digiLine electronics concerned does not match the interface settings of the JUMO AQUIS touch P (baud rate or data format)	Perform a manual bus scan (see Chapter "Submenu for linking", page 95).

## 23 Annex

Fault symptom	Possible cause	Remedy
<p>Some of the connected sensors malfunction sporadically.</p> <p>("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")<sup>a</sup></p>	<p>Poor contact in the bus cabling</p>	<p>Check for reliable contact at all plug connectors and terminals in the JUMO AQUIS touch P. Inspect the cabling for damage. The occurrence and clearing of bus faults is recorded in the "Event list". This allows you to use the entries to investigate sporadic bus faults.</p>
<p>Individual sensors malfunction continuously.</p> <p>("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")</p>	<p>Poor contact in the bus cabling</p>	<p>Check for reliable contact at all plug connectors and terminals in the JUMO AQUIS touch P. Inspect the cabling for damage.</p>
<p>All sensors connected to the bus simultaneously malfunction continuously.</p> <p>("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")</p>	<p>The bus voltage supply has failed.</p>	<p>Diagnose the failure of the voltage supply with a multimeter and replace the faulty voltage source or correct the short-circuit in the voltage supply.<sup>b</sup></p>

<sup>a</sup> See Chapter 8.3.1 "Alarm list", page 99 if a "Bus fault" is signaled.

<sup>b</sup> A JUMO digiLine M12 connecting cable (see Accessories) can be used to measure the voltage supply at the outputs of a JUMO digiLine hub. The conductor assignment can be found in the connection diagram for the serial interface (see Chapter 6.4.10 "Interfaces", page 59).

### 23.1.2 Possible faults on digital JUMO sensors from product groups 2026xx

Fault symptom	Possible cause	Remedy
<p>A sensor is not detected after being connected and is also not visible for manual linking (cf. Chapter "Untermenü zum Verlinken", page 105).</p>	<p>The serial interface of the device concerned is configured incorrectly.</p>	<p>Check the following serial interface setting:</p> <p><b>Protocol:</b> Modbus digital sensors</p> <p><b>Baud rate:</b> 9600</p>
	<p>Two or more sensors of the same kind were connected.</p>	<p>Follow the instructions in the operating manual for startup of digital sensors.</p> <p>JUMO sensors from the product groups 2026xx must be put into operation individually.</p> <p>⇒ Chapter 7.3 "Digitale Sensoren", page 74</p> <p>⇒ Chapter 8.2.7 "Digitale Sensoren", page 103</p>
	<p>Several digital sensors from the product groups 2026xx were connected to the same device address, causing collisions during bus communication.</p>	
	<p>More than 6 digital sensors were connected.</p>	<p>Ensure that no more than 6 digital sensors are connected to a JUMO AQUIS touch P.</p>
	<p>The voltage supply for powering the sensor electronics is inadequate.</p>	<p>Ensure compliance with the specifications in the tables for planning the cabling for digital sensors.</p> <p>⇒ Chapter 23.2 "Planning the cabling for digital sensors", page 367</p>
	<p>The device address of the sensor is outside the range provided for the sensor type.</p>	<p>The device address must be set to the base address for the particular sensor type using the JUMO DSM software. Then, the sensor must be put into operation at the JUMO AQUIS touch P (initial startup).</p> <p><b>Base addresses</b> ecoLine O-DO: 10 ecoLine NTU: 40</p>
<p>Sensors are not linked</p>	<p>No suitably configured input for digital sensors is available for the type of sensor (status "Installation").</p>	<p>JUMO sensors from the product group 2026xx can only be linked to inputs for digital sensors if the configuration of the input matches the type of sensor.</p>

## 23 Annex

Fault symptom	Possible cause	Remedy
<p>Some of the connected sensors malfunction sporadically.</p> <p>("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")</p>	<p>Poor contact in the bus cabling</p>	<p>Check for reliable contact at all plug connectors and terminals in the JUMO AQUIS touch P. Inspect the cabling for damage</p> <p>The occurrence and clearing of bus faults is recorded in the "Event list". This allows you to use the entries to investigate sporadic bus faults.</p>
<p>Individual sensors malfunction continuously.</p> <p>("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")</p>	<p>Poor contact in the bus cabling</p>	<p>Check for reliable contact at all plug connectors and terminals in the JUMO AQUIS touch P. Inspect the cabling for damage.</p>
	<p>Defect in the sensor electronics</p>	<p>Replace the sensor electronics.</p>
<p>All sensors connected to the bus simultaneously malfunction continuously.</p> <p>("Bus fault" is signaled in the title bar of the user interface and in the "Alarm list")</p>	<p>The bus voltage supply has failed.</p>	<p>Diagnose the failure of the voltage supply with a multimeter and replace the faulty voltage source or correct the short-circuit in the voltage supply.<sup>a</sup></p>

<sup>a</sup> A JUMO digiLine M12 connecting cable (see Accessories) can be used to measure the voltage supply at the outputs of a JUMO digiLine hub. The conductor assignment can be found in the connection diagram for the serial interface (see Chapter 6.4.10 "Schnittstellen", page 65).

## 23.2 Planning the cabling for digital sensors

### 23.2.1 When supplying the bus from a JUMO AQUIS touch P

The line length specifications in this subchapter apply when supplying the bus with DC 5 V from a voltage supply output on the JUMO AQUIS touch P. In this case, stub lines can also be supplied from a JUMO digiLine hub or through use of JUMO Y-splitters. If a digiLine hub is used, the slide switch on the digiLine hub must be set to the position for DC 5 V as the input voltage. With the switch in this position, the input voltage of DC 5 V is fed through to the outputs of the digiLine hub.

#### Bus cabling in line topology

Type of sensor/electronics	Maximum length of bus line	Maximum length of stub lines	Maximum number of connectable sensors
JUMO digiLine pH/ ORP/T	40 m	10 m	6
	50 m	10 m	5
	60 m	10 m	4
	80 m	10 m	3
	100 m	10 m	2
	100 m	10 m	1
O-DO Turbidity	–	–	0

#### Bus cabling in star topology

Type of sensor/electronics	Maximum length per branch	Maximum number of connectable sensors
JUMO digiLine pH/ ORP/T	50 m	6
JUMO ecoLine O-DO JUMO ecoLine NTU	–	0

## 23 Annex

---

### 23.2.2 When supplying the bus from a JUMO digiLine hub

The line length specifications in this subchapter apply when supplying the bus with DC 5 V from a JUMO digiLine hub. In this case, the digiLine hub must be supplied with DC 24 V. The slide switch on the JUMO digi-Line hub must be set to the position for DC 24 V as the input voltage. The electronics of the digiLine hub generate the bus supply voltage of DC 5 V internally and supply its outputs with this voltage.

#### Bus cabling in line topology

Type of sensor/electronics	Maximum length of bus line	Maximum length of stub lines	Maximum number of connectable sensors
JUMO digiLine pH/ ORP/T	100 m	10 m	6
JUMO ecoLine O-DO JUMO ecoLine NTU	100 m	10 m	6

#### Bus cabling in star topology

Type of sensor/electronics	Maximum length per branch	Maximum number of connectable sensors
JUMO digiLine pH/ ORP/T	50 m	6
JUMO ecoLine O-DO JUMO ecoLine NTU	30 m	6







**JUMO GmbH & Co. KG**

Street address:  
Moritz-Juchheim-Straße 1  
36039 Fulda, Germany  
Delivery address:  
Mackenrodtstraße 14  
36039 Fulda, Germany  
Postal address:  
36035 Fulda, Germany  
Phone: +49 661 6003-0  
Fax: +49 661 6003-607  
Email: mail@jumo.net  
Internet: www.jumo.net

**OneTemp<sup>o</sup>** pty ltd  
MEASURE | CONTROL | RECORD  
[www.onetemp.com.au](http://www.onetemp.com.au)  
1300 768 887

**JUMO Instrument Co. Ltd.**

JUMO House  
Temple Bank, Riverway  
Harlow, Essex CM 20 2DY, UK  
Phone: +44 1279 63 55 33  
Fax: +44 1279 62 50 29  
Email: sales@jumo.co.uk  
Internet: www.jumo.co.uk

**JUMO Process Control, Inc.**

6733 Myers Road  
East Syracuse, NY 13057, USA  
Phone: +1 315 437 5866  
Fax: +1 315 437 5860  
Email: info.us@jumo.net  
Internet: www.jumousa.com