

CYCLOPS L

QUICK START GUIDE

PUBLICATION N° 809626


LANGUAGE: ENGLISH



🔍 Cyclops 100L, Cyclops 160L, Cyclops 390L, Cyclops 055L



1 Thermometer Description







- | | | | |
|---|------------------------|----|---------------------------------------|
| 1 | LCD display panel | 8 | USB connector |
| 2 | Keypad | 9 | Tripod mounting hole |
| 3 | Optical focusing ring* | 10 | Adjustable wrist strap (in packaging) |
| 4 | Protective window | 11 | Protective cover |
| 5 | Lens cap | 12 | Adjustable eyepiece |
| 6 | ON/OFF buttons | 13 | Battery compartment cover |
| 7 | Trigger | | |


* Optical Focus Ring is not fitted to Cyclops 055L Thermometers

Heat Protection Jacket (Part N° 811279) not illustrated


2 Insert the Battery




3 Remove the Lens Cap



4 Switch ON



5 View the Target




Target being measured is defined by the circle in the viewfinder.
Use the focus ring* to bring the target into focus.

**not fitted to Cyclops 055L (fixed focus) Thermometers*

In areas exposed to high temperatures, you can fit the Heat Protection Jacket (Part N° 811279).

The Cyclops Long Eye Relief (LER) adaptor (Part N° 804685) is ideal for users wearing helmets, goggles or other eye protection devices.

6 Take a Measurement



7 Download the FREE Software

Download software for PC and mobile devices from:
www.landinst.com/software-downloads

or



Download the AMETEK LAND CYCLOPS LOGGER
mobile software from:

Google Play Store




User Documentation

User Guides are available for each model in the Cyclops L Range. See the **Documentation** tab on the web page for your model.


Logger Software


Multiple Languages



User Documentation








CYCLOPS

A FAMILY OF HIGH PRECISION PORTABLE
NON-CONTACT THERMOMETERS



Land Instruments International

Dronfield, S18 1DJ,
England

Tel: +44 (0) 1246 417691

Email: land.enquiry@ametek.com

www.landinst.com

AMETEK Land - Americas

150 Freeport Road, Pittsburgh,
PA 15238, U.S.A.

Tel: +1 (412) 826 4444

Email: irsales@ametek.com

www.ametek-land.com

AMETEK Land China Service

Part A, 1st Floor No. 460
North Fute Road,
Waigaoqiao Free Trade Zone 200131
Shanghai, China

Tel: +86 21 5868 5111 ext 122

Email: land.enquiry@ametek.com

www.landinst.com

AMETEK Land India Service

Divyasree N R Enclave, Block A,
4th Floor, Site No 1, EPIP Industrial Area
Whitefield, Bangalore- 560066
Karnataka, India

Tel: +91 - 80 67823240

Email: land.enquiry@ametek.com

www.landinst.com



Applies in the UK



Applies in the US



Applies in India

For a full list of international offices, please visit our website www.landinst.com

Copyright © 2008-17 LAND Instruments International. Continuous product development may make it necessary to change these details without notice.

Cyclops L Quick Start Guide, Issue 5, 25 May 2017