

Barometric Pressure Smart Sensor (S-BPA-CM10) Quick Start

Connecting to a Station

1. Stop the station if it is logging.
 2. Plug the smart sensor jack into an open smart sensor port on the station.
 3. Start logging. See the station manual at www.onsetcomp.com/resources/documentation/6122-man-s-bpa for details on operating stations with smart sensors.
-

Mounting the Smart Sensor

- The barometric pressure smart sensor must be used inside the logger enclosure. Use the hook-and-loop tape to affix it to the inside of the logger enclosure.
 - The sensor measures air pressure inside the logger enclosure. The vent in the enclosure must be free from obstructions for the sensor to function correctly.
-



For more information about this smart sensor, refer to the full product manual. Scan the code at left or go to www.onsetcomp.com/resources/documentation/6122-man-s-bpa.
